

[Manuals.plus](#) /

> [JUMMICO](#) /

> JUMMICO Gaming Chair, Desk Chair with Massage Function, Office Chair Ergonomic with Footrest, 150 kg, Grey User Manual

JUMMICO Chaise Gaming 0564

JUMMICO Gaming Chair User Manual

Model: Chaise Gaming 0564

INTRODUCTION

Thank you for choosing the JUMMICO Gaming Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new chair. Please read this manual thoroughly before assembly and use, and retain it for future reference.





Image: The JUMMICO Gaming Chair positioned in a modern gaming environment, showcasing its design and presence.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or damaged.
- Follow the assembly instructions carefully. Incorrect assembly can lead to instability and injury.
- Do not stand on the chair. Use it only for sitting.
- Do not exceed the maximum weight capacity of 150 kg (330 lbs).
- Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- Avoid exposing the chair to direct sunlight or extreme temperatures to prevent material degradation.
- When adjusting the chair, ensure hands and fingers are clear of moving parts to prevent pinching.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present in your package. If any parts are missing or damaged, please contact customer support.

- Backrest

- Seat Cushion
- Armrests (2)
- Base (5-star)
- Casters (5)
- Gas Lift Cylinder
- Gas Lift Cover
- Mechanism Plate
- Lumbar Support Cushion (with massage function)
- Headrest Pillow
- Footrest Assembly
- Hardware Pack (screws, washers, Allen key)
- Instruction Manual (this document)

SETUP AND ASSEMBLY

Assembly is designed to be straightforward and can typically be completed in under 30 minutes. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the 5-star base. Push firmly until they click into place.
2. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the assembled base. Cover it with the gas lift cover.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the screw holes on the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat. Secure with screws using the provided Allen key.
4. **Attach Armrests to Seat:** Secure the armrests to the sides of the seat cushion using the designated screws. Do not overtighten initially.
5. **Connect Backrest to Seat:** Attach the backrest to the seat cushion using the remaining screws. Once all screws are in place for the armrests and backrest, tighten them securely.
6. **Mount Seat Assembly onto Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered.
7. **Install Footrest:** Slide the footrest assembly into the designated slots under the seat.
8. **Attach Cushions:** Place the headrest pillow and lumbar support cushion onto the chair. The lumbar cushion typically has straps to secure it to the backrest.

Lang anhaltender Komfort

51 cm extrabreites Sitzkissen – kein beengtes Gefühl mehr
10 cm dickes Kissen – keine Härte mehr



Image: An exploded view diagram highlighting key components and features of the JUMMICO Gaming Chair, such as the electric lumbar massage, wide backrest, integrated armrests, quiet 360-degree casters, stable metal base, and footrest.

OPERATING INSTRUCTIONS

Chair Adjustments

- **Height Adjustment:** Pull the lever located under the right side of the seat upwards to raise the chair. To lower, remain seated and pull the lever upwards. Release the lever at the desired height.
- **Backrest Recline:** Pull the lever on the right side of the chair (near the armrest) upwards to recline the backrest. Lean back to the desired angle (between 90 and 150 degrees) and release the lever to lock it in place. To return to an upright position, pull the lever and lean forward.
- **Footrest Extension:** Pull the footrest handle located under the front of the seat to extend the footrest. Push it back in to retract.
- **Rocking Function:** The chair may have a rocking function. If present, a knob under the seat controls the tension of

the rocking motion. Turn clockwise to increase tension, counter-clockwise to decrease. A lever may also be present to lock/unlock the rocking function.



Image: A visual guide demonstrating the adjustable reclining angles of the chair, from 90 degrees for focused work, 110 degrees for relaxed gaming/watching, to 145 degrees for comfortable napping.

Massage Function (Lumbar Support)

The lumbar support cushion features a massage function to help relax your lower back. Connect the USB cable from the lumbar cushion to a suitable USB power source (e.g., computer USB port, power bank, or USB wall adapter). The massage function will activate upon connection.

5 ergonomische Zonen

langanhaltender Komfort
ohne Ermüdung



Image: An illustration detailing the five ergonomic support zones of the chair: headrest, neck support, shoulder support, back support, and lumbar support, emphasizing long-lasting comfort.

MAINTENANCE

- **Cleaning:** Wipe the chair with a soft, damp cloth. For stubborn stains, use a mild soap solution and then wipe with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Casters:** Keep the casters clean and free of debris (hair, dust) to ensure smooth movement.
- **Storage:** If storing the chair for an extended period, keep it in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift may need replacement.
Backrest does not recline or lock.	Recline mechanism jammed or lever not engaged.	Check if the recline lever is fully engaged. Ensure no obstructions are preventing movement.
Chair is wobbly.	Loose screws or uneven floor.	Tighten all assembly screws. Ensure the chair is on a flat, even surface.
Casters do not roll smoothly.	Debris caught in casters.	Remove any hair, dust, or debris from the caster wheels.
Massage function not working.	USB cable disconnected or power source issue.	Ensure the USB cable is securely connected to both the lumbar cushion and a working USB power source. Try a different USB port or power source.

SPECIFICATIONS

Brand	JUMMICO
Model Number	Chaise Gaming 0564
Color	Grey
Product Dimensions (D x W x H)	15.16"D x 20.08"W x 49.8"H (38.5 cm D x 51 cm W x 126.5 cm H)
Item Weight	18.7 Kilograms (41.2 lbs)
Maximum Weight Recommendation	150 Kilograms (330 lbs)
Seat Material	Foam
Reclining Angle	90 to 150 degrees
Included Components	Cushion (Headrest, Lumbar with Massage)
Indoor/Outdoor Usage	Indoor
Required Assembly	Yes
UPC	788418912992



Image: A detailed diagram illustrating the key dimensions of the JUMMICO Gaming Chair, including height, seat width, and backrest height, along with recommended user height and maximum weight capacity.

WARRANTY AND SUPPORT

JUMMICO is committed to providing high-quality products. For any issues encountered during use, please contact JUMMICO customer support via Amazon. Your satisfaction is our priority.

Please refer to your purchase documentation for specific warranty terms and conditions.

© 2026 JUMMICO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F6MY24M6>

More documents and user manuals: <https://manuals.plus/>