



[Manuals.plus](#) /

> [OUVR](#) /

> [OUVR Rattan Pendant Light \(Model KP-5092-3\) Instruction Manual](#)

OUVR KP-5092-3

OUVR Rattan Pendant Light (Model KP-5092-3) Instruction Manual

Brand: OUVR | Model: KP-5092-3

[Introduction](#) [Product Overview](#) [Package Contents](#) [Setup & Installation](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the OUVR Rattan Pendant Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before beginning installation and retain them for future reference.

Important Safety Information

- Always disconnect power at the circuit breaker before installing, cleaning, or servicing the fixture.
- All wiring connections must be in accordance with local and national electrical codes. If you are unsure about wiring, consult a qualified electrician.
- Do not exceed the maximum wattage specified for the bulb (E26 base, max 60W).
- This fixture is designed for indoor use only. Do not expose to moisture or outdoor elements.
- Handle glass components and bulbs with care.

2. PRODUCT OVERVIEW

The OUVR Rattan Pendant Light is a versatile 2-in-1 fixture designed to enhance various interior styles, including farmhouse, bohemian, vintage, and industrial. It features a unique design with two removable shades, allowing for customizable lighting effects.

Key Features:

- **2-in-1 Design:** Includes a woven rattan outer shade (5.87 inches) and a linen inner shade (4.75 inches). These can be used individually or combined for layered lighting.

- **Stylish Boho Design:** Blends natural rattan weaving with a linen fabric shade, adding organic texture and soft, diffused lighting.
- **Sturdy Iron Rods:** Constructed with durable iron hanging rods for a rigid, stable installation.
- **Adjustable Height:** Comes with four iron rods (3 x 12 inches and 1 x 6 inches) allowing height adjustment from 5.87 inches to 51.87 inches.
- **Sloped Ceiling Compatible:** The iron canopy ensures secure installation on both flat and sloped ceilings.
- **Premium Quality:** Made from high-quality rattan, linen, and iron materials for durability.
- **Dimmable:** Compatible with dimmable E26 base bulbs and dimmer switches (sold separately).



Figure 2.1: The 2-in-1 design allows for three distinct lighting effects by combining or separating the rattan and linen shades.




Figure 2.2: Details of the premium materials and dimmable functionality.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, do not proceed with installation and contact customer support.

- Pendant Light Fixture (with pre-wired canopy)
- Woven Rattan Outer Shade
- Linen Inner Shade
- Iron Hanging Rods: 3 x 12 inches, 1 x 6 inches
- Mounting Hardware (screws, wire nuts, etc.)
- Instruction Manual

Note: E26 base bulbs are not included and must be purchased separately.

4. SETUP AND INSTALLATION

Before installation, ensure the power is turned off at the circuit breaker. It is recommended to have a second person assist with installation.

4.1 Preparing for Installation

1. Unpack all components and lay them out on a clean, flat surface.
2. Review the parts list to ensure all items are present.
3. Determine the desired hanging height. You can combine the provided iron rods (3 x 12 inches, 1 x 6 inches) to adjust the height from 5.87 inches to 51.87 inches.




Figure 4.1: Adjusting the hanging height using the provided iron rods.

4.2 Mounting the Fixture

1. **Turn off power:** Locate the circuit breaker controlling the light fixture's power and turn it off.
2. **Attach mounting bracket:** Secure the mounting bracket to the junction box in the ceiling using the

provided screws. Ensure it is firmly attached.

3. Connect wiring:

- Connect the fixture's black wire to the house's black (live) wire.
- Connect the fixture's white wire to the house's white (neutral) wire.
- Connect the fixture's ground wire to the house's ground wire (bare copper or green).
- Secure all connections with wire nuts and wrap with electrical tape for added safety.

4. **Secure canopy:** Carefully push the wires into the junction box and secure the fixture's canopy to the mounting bracket using the provided screws. Ensure the canopy is flush against the ceiling.



Figure 4.2: Top view of the canopy with mounting plate.



Figure 4.3: Bottom view of the canopy.



Figure 4.4: Installation on flat and sloped ceilings.

4.3 Attaching Shades and Bulb

1. **Choose shade configuration:** Decide whether to use the rattan shade alone, the linen shade alone, or both combined.
2. **Install shades:** Attach your preferred shade combination to the fixture. The linen shade typically fits inside the rattan shade if both are used.
3. **Insert bulb:** Screw an E26 base bulb (max 60W, not included) into the socket.



Figure 4.5: Woven Rattan Outer Shade.



Figure 4.6: Linen Inner Shade.



Figure 4.7: E26 bulb compatibility (bulbs not included).

5. OPERATING INSTRUCTIONS

Once installed, the OUVR Rattan Pendant Light is ready for use.

- **Power On:** Restore power at the circuit breaker.
- **Light Control:** Operate the light using your wall switch.
- **Dimmable Function:** If you wish to use the dimmable function, ensure you have installed a dimmable E26 bulb and a compatible dimmer switch (both sold separately). Adjust the dimmer switch to achieve your desired brightness level.
- **Shade Customization:** You can change the shade configuration (rattan only, linen only, or both) at any time by carefully removing and reattaching the shades. Ensure the power is off before making any changes.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your pendant light.

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth to wipe the fixture. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish. For the rattan and linen shades, a soft brush or vacuum with a brush attachment can be used to remove dust.
- **Bulb Replacement:** Ensure power is off and the bulb has cooled before replacing. Screw in a new E26 base bulb, ensuring it does not exceed 60W.

7. TROUBLESHOOTING

If you encounter issues with your pendant light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	Power is off at the circuit breaker. Loose wire connections. Faulty bulb. Wall switch is off.	Check the circuit breaker and turn it on. Ensure all wire connections are secure (with power off). Replace the bulb with a new one. Turn on the wall switch.
Light flickers.	Loose bulb. Incorrect bulb type for dimmer. Faulty dimmer switch.	Tighten the bulb. Ensure dimmable bulbs are used with a dimmer switch. Consult an electrician to check the dimmer switch.
Fixture is unstable or sags.	Mounting bracket not securely fastened. Rods not properly connected.	Ensure the mounting bracket is tightly secured to the junction box. Verify all iron rods are firmly screwed together and to the canopy/fixture.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Brand	OUVR
Model Number	KP-5092-3
Material	Rattan, Linen, Metal (Iron)
Color	Black (canopy/rods), Natural (rattan), White/Cream (linen)
Fixture Type	Pendant Light, Chandelier
Shade Dimensions (Rattan)	Approximately 5.87 inches diameter
Shade Dimensions (Linen)	Approximately 4.75 inches diameter
Adjustable Height Range	5.87 inches to 51.87 inches

Bulb Base	E26
Max Wattage	60W
Compatible Bulb Types	LED, Incandescent, Halogen, CFL
Dimmable	Yes (with dimmable bulb and dimmer switch, sold separately)
Indoor/Outdoor Usage	Indoor Only
Mounting Type	Ceiling Mount (Flat or Sloped)
Item Weight	2.89 Kilograms (for 3-pack)

9. WARRANTY AND SUPPORT

9.1 Manufacturer Warranty

Note: The provided product data indicates a general manufacturer warranty. Please consult your purchase receipt or contact OUVR directly for detailed warranty terms and conditions.

9.2 Customer Support

If you have any questions, require assistance with installation, or need to report a missing/damaged part, please contact OUVR customer support. You can typically find contact information on the product packaging, the seller's website, or through your purchase platform.

For online support, you may visit the OUVR store on Amazon: [OUVR Store](#)