Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Black Shark X Pro

Black Shark Watch X Pro Smartwatch User Manual

Model: X Pro

Introduction

This user manual provides comprehensive instructions for the Black Shark Watch X Pro Smartwatch. Please read this manual carefully before using your device to ensure proper operation and to maximize its features.
The Black Shark Watch X Pro is a feature-rich smartwatch designed for independent communication, health tracking, and entertainment. It runs on Android, offering a versatile and responsive user experience.

Package Contents

Upon unboxing your Black Shark Watch X Pro, please ensure all items are present:

- Black Shark Watch X Pro Smartwatch
- Charging Cable
- User Manual (this document)



Image: The Black Shark Watch X Pro Smartwatch with its included charging cable and an extra watch strap.

Device Overview

Familiarize yourself with the key components of your Black Shark Watch X Pro.



Image: An overview highlighting the smartwatch's features: 4G independent calling with SIM slot, Android operating system, app download capability, 1.75-inch AMOLED display, seamless Wi-Fi connectivity, and a 180-degree rotating camera.

- **1.75" AMOLED Display:** Vibrant screen with 466x466 resolution and 60Hz refresh rate.
- **Rotating Camera:** 2MP high-definition camera that rotates 180 degrees for versatile photo and video capture.
- **SIM Card Slot:** Supports Nano-SIM for independent 4G communication.
- **Physical Buttons:** Power button and menu button for navigation and control.
- **Optical Sensors:** Located on the back for health tracking.

Setup

1. Initial Charging

Before first use, fully charge your Black Shark Watch X Pro. Connect the magnetic charging cable to the charging contacts on the back of the watch and plug the USB end into a compatible power adapter (not included) or a computer's USB port.



Image: The smartwatch display indicating a full 100% charge, demonstrating the magnetic charging contacts.

2. Powering On/Off

- **To Power On:** Press and hold the Power button until the Black Shark logo appears.
- **To Power Off:** Press and hold the Power button, then select "Power Off" from the options on the screen.

3. SIM Card Installation (Optional)

The Black Shark Watch X Pro supports independent 4G communication via a Nano-SIM card. To install:

1. Locate the SIM card slot on the side of the watch.
2. Carefully insert a Nano-SIM card into the slot with the gold contacts facing down, ensuring it clicks into place.
3. To remove, gently press the SIM card to eject it.



Image: A close-up of the Black Shark Watch X Pro showing a Nano-SIM card being inserted into the dedicated slot, illustrating its 4G independent communication capability.

4. Initial Configuration

Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account login (if desired for app downloads).

Operating the Smartwatch

Navigation

- **Touchscreen:** Swipe up, down, left, or right to navigate through menus and notifications. Tap to select items.
- **Power Button:** Short press to return to the watch face or wake the screen. Long press for power options.
- **Menu Button:** Short press to access the app drawer or specific functions depending on the context.

Key Features

4G Independent Communication

With a Nano-SIM card installed, you can make and receive calls, send texts, and use online applications directly from your watch without needing a paired smartphone. The watch supports 2G/3G/4G full-band compatibility.

Rotating Camera

The 2MP camera can rotate 180 degrees, allowing you to capture photos and videos from various angles. Access the camera app from the app drawer and twist the camera module to adjust its orientation.



Image: The Black Shark Watch X Pro demonstrating its 180-degree rotating camera, positioned to capture a scene, alongside a visual representation of various downloadable applications like Instagram, TikTok, Gmail, Netflix, and Facebook.

Health and Fitness Tracking

The watch features optical sensors for continuous monitoring of heart rate, blood oxygen, steps, and calories. It supports multiple sports modes (running, cycling, badminton) and multi-system GPS for accurate activity tracking.



Image: A visual representation of the smartwatch's fitness tracking capabilities, showing icons for Heart Rate, Blood Oxygen, Steps, and Calories, with a person engaged in running, indicating its use as a fitness companion.

App Downloads and Entertainment

With 4GB RAM and 32GB ROM, the Android-powered watch allows you to download and store a wide range of applications, music, and videos. Enjoy streaming content from platforms like TikTok and YouTube, or play games directly on your wrist.

Customizable Watch Faces

Choose from over 300 free watch faces, including mechanical, minimalist, and dynamic designs, to personalize your device's appearance.



Image: A collection of diverse watch faces displayed on the Black Shark Watch X Pro, illustrating the wide range of customization options available to users.

Maintenance

Cleaning

Wipe the watch and strap with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as they may damage the device.

Water Resistance

The watch has an IPX5 water resistance rating and IP6X dust protection. This means it is splash-proof and suitable for wearing during exercise (sweat exposure), in the rain, and when washing hands. *It is not designed for swimming, snorkeling, diving, hot water showers, hot springs, saunas, or high-speed water activities.* Water resistance is not permanent and may decrease with wear. Please avoid using the watch in conditions beyond its intended use.

Battery Care

To prolong battery life, avoid exposing the watch to extreme temperatures. Charge the device regularly, but avoid leaving it fully charged or fully discharged for extended periods.

Troubleshooting

Problem	Possible Solution
Watch does not power on.	Ensure the watch is fully charged. Connect it to the charging cable and a power source for at least 30 minutes.
Cannot make calls with SIM card.	Check if the Nano-SIM card is correctly inserted and activated. Verify network signal strength. Ensure your plan supports 4G communication.
Screen is unresponsive.	Restart the watch by holding the Power button until the power options appear, then select restart. If unresponsive, force restart by holding the Power button for approximately 10-15 seconds.
Battery drains quickly.	Reduce screen brightness, disable unnecessary background apps, turn off Wi-Fi/Bluetooth/GPS when not in use, or limit notifications.

Specifications

Feature	Detail
Model Name	Watch X Pro
Brand	Black Shark
Screen Size	1.75 Inches AMOLED
Resolution	466x466
Refresh Rate	60Hz
Operating System	Android 8.1
RAM	4 GB
Storage	32 GB
Camera	2MP, 180° Rotating
Connectivity	4G (Nano-SIM), Bluetooth, Wi-Fi
GPS	Built-in GPS
Battery Life	Up to 75 hours (typical use)
Water Resistance	IPX5 (splash-proof)
Dust Protection	IP6X

Feature	Detail
Item Weight	9.5 ounces
Dimensions (Watch Body)	56mm (width)
Strap Width	22mm
Wrist Circumference	150-205mm




Image: A technical diagram illustrating the physical dimensions of the Black Shark Watch X Pro, including the watch body width (56mm), strap width (22mm), and the adjustable wrist circumference range (150-205mm).

Warranty and Support

Information regarding product warranty and customer support is typically provided with your purchase documentation or on the manufacturer's official website. Please refer to those resources for detailed warranty terms and contact information for support.

For further assistance, you may visit the official Black Shark website or contact their customer service department.

Note: Specific warranty details were not available in the provided product data.

© 2025 Black Shark. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is the rotating crown on my Black Shark Watch X Pro not working?

Based on the Black Shark Watch X Pro user manual, the device features two physical buttons: a Power button and a Menu button. If the rotating crown (Menu button) is not responding or performing...

Read full answer

How can I reset my Black Shark Watch X Pro if I have forgotten the password and do not have the original box?

Since the Black Shark Watch X Pro runs on the Android operating system, a forgotten screen lock password typically requires a factory reset. Because you cannot access the settings menu, you must attempt a...

Read full answer

Open the live page

https://manuals.plus/asin/B0F6N2G4WC

More documents and user manuals: **https://manuals.plus/**