

- Manuals.plus /
- > [YiJYi](#) /
- > YiJYi 2025 Wireless Charger for Samsung: 6-in-1 Charging Station User Manual

YiJYi Y23

YiJYi 2025 Wireless Charger for Samsung: 6-in-1 Charging Station User Manual

Model: Y23

1. INTRODUCTION

Thank you for choosing the YiJYi 2025 Wireless Charger. This 6-in-1 charging station is designed to efficiently charge your Samsung smartphone, Galaxy Watch, and Galaxy Buds simultaneously. It also features a 12-hour adjustable clock and a 7-color night light, providing a versatile solution for your charging and bedside needs.

Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.



Image 1.1: The YiJYi 6-in-1 Wireless Charging Station in use, showing a smartphone, smartwatch, and earbuds being charged simultaneously. A 30W power adapter is also visible.

2. PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x YiJYi 6-in-1 Wireless Charger Station
- 1 x 30W Charging Adapter
- 1 x Type-C Charging Cable (for USB port connection)
- 1 x User Manual

3. PRODUCT DIAGRAM

Familiarize yourself with the components of your charging station:

1. **Phone Charging Stand (Vertical):** For wireless charging of compatible smartphones.
2. **Galaxy Watch Charging Area:** Dedicated magnetic charging for Samsung Galaxy Watches.
3. **Earbuds Charging Pad:** For wireless charging of compatible earbuds.
4. **Phone Charging Pad (Horizontal):** For wireless charging of a second compatible smartphone.

5. **Digital Clock Display:** Shows time in 12-hour format.
6. **Control Buttons:** For adjusting clock, night light, and brightness.
7. **USB-C Input Port:** Connects to the power adapter.
8. **Night Light:** Provides ambient illumination.



Image 3.1: An overhead view of the charging station, illustrating the placement of devices and the integrated clock display.

4. SETUP INSTRUCTIONS

Follow these steps to set up your charging station:

1. **Connect Power:** Insert the provided Type-C charging cable into the USB-C input port on the back of the charging station. Connect the other end of the cable to the included 30W Quick Charger 3.0 power adapter.
2. **Plug In:** Plug the power adapter into a wall outlet. The digital clock display will illuminate, indicating the station is powered on.
3. **Placement:** Place the charging station on a flat, stable surface, such as a desk or nightstand. Ensure there is adequate ventilation around the device.

30W Ultra Fast Wireless Charging

Charge 4 Devices at The Same Time



Image 4.1: The charging station receiving power from the 30W adapter, demonstrating the fast charging capability for multiple devices.

5. OPERATING INSTRUCTIONS

5.1 Charging Devices

This station supports simultaneous wireless charging for up to two smartphones, one Samsung Galaxy Watch, and one pair of Galaxy Buds.

- **Smartphones:** Place your wireless charging-enabled smartphone on either the vertical charging stand or the horizontal charging pad. Ensure the phone is centered over the charging coil. The charging indicator light will activate. Output: Up to 15W per phone.
- **Samsung Galaxy Watch:** Place your compatible Samsung Galaxy Watch onto the dedicated magnetic charging area. The watch will automatically align and begin charging. Output: Up to 3W.
- **Galaxy Buds:** Place your wireless charging-enabled Galaxy Buds case onto the earbuds charging pad. Output: Up to 5W.

For optimal and safe charging, always use the included 30W Quick Charger 3.0 power adapter and charging cable. A full charge for devices typically takes about 2 hours.

5.2 Clock Settings

The built-in digital clock displays time in a 12-hour format.

- **Setting Time:** Refer to the specific control buttons on your device (usually marked with a clock icon or 'M' for Mode) to enter time setting mode. Use the '+' and '-' buttons to adjust hours and minutes.
- **Adjusting Brightness:** The clock display offers 3 adjustable brightness levels. Use the designated button (often a sun icon or 'L' for Light) to cycle through brightness levels or turn the display off for an undisturbed sleep.

5.3 Night Light Settings

The ambient night light features 7 color modes and adjustable brightness.

- **Changing Colors:** Press the night light button (often a light bulb icon) to cycle through the 7 available color modes.
- **Adjusting Brightness:** Hold down the night light button to adjust the brightness from 10% to 100%. Release the button when the desired brightness is reached.

6. COMPATIBILITY

The YiJYi 6-in-1 Wireless Charging Station is designed for wide compatibility with Samsung devices and other wireless charging-enabled devices.

6.1 Compatible Devices

- **Samsung Phones:** Samsung S25 Ultra/S25+/S25, S24 Ultra/S24+/S24, S23 Ultra/S23+/S23, S22 Ultra/S22+/S22, S21 FE/S21 Ultra/S21, S20 Ultra/S20, S10, Note 10, Note 9, and other Android devices with wireless charging capability.
- **Samsung Galaxy Watch:** Galaxy Watch Ultra/7/6/6 Classic/5/5 Pro/4/4 Classic/3/Active 1/2.
- **Samsung Galaxy Buds:** Galaxy Buds Pro 2, Buds Live, Buds Plus (wireless version), and other earbuds that support wireless charging.

6.2 Important Notes on Compatibility

- **Incompatible Watches:** Not compatible with Samsung Galaxy Watch 1, Samsung Gear Series, Google Pixel Watch 2/3, or Apple Watch.
- **Phone Cases:** Avoid using thick phone cases (greater than 5mm) or cases with metal, magnets, or pop sockets, as these can interfere with wireless charging.

Compatibility and Important Notices

Please check your phone and watch model before buying!



Support for all wireless charging phones

Other: Wireless charging-enabled phones

15W Max

- ✓ Samsung S25 Ultra/S25+/S25
- ✓ Samsung S24 Ultra/S24+/S24
- ✓ Samsung S23 Ultra/S23+/S23
- ✓ Samsung S22 Ultra/S22+/S22
- ✓ S21/S21+/S21 Ultra/S21 FE 5G
- ✓ S20/S20+/s20 Ultra
- ✓ Galaxy Z Flip4/Galaxy Z Fold4
- ✓ Galaxy Z Fold3/Galaxy Z Fold2
- ✓ Galaxy Z Flip3/Galaxy Z Flip2
- ✓ S10/S10e/s10+
- ✓ S9/S9+/S8/S8+/S7/s7 edge
- ✓ Note20/20 Ultra
- ✓ Pixel 6/Pixel 6 Pro
- ✓ Pixel 5A/Pixel 4A/LG V60/LG G8
- ✓ iPhone 16/16 Plus/16 Pro /16 Pro Max
- ✓ iPhone 15/15 Plus/15 Pro /15 Pro Max
- ✓ iPhone 14/14 Plus/14 Pro /14 Pro Max
- ✓ iPhone 13/13 Pro/13 Pro Max/13 Mini
- ✓ iPhone 12/12 Pro/12 Pro Max/12 Mini
- ✓ iPhone 11/11 Pro/11 Pro Max
- ✓ iPhone X/XR/XS/XS Max
- ✓ iPhone 8/8 Plus/ iPhone SE 2



For Earbuds with wireless charging case

Other: Wireless charging-enabled Buds

5W Max

- ✓ Samsung Galaxy buds+, live, pro, 2, 3
- ✓ AirPods Pro 2/Pro, AirPods 4, 3, 2
- ✓ Samsung Galaxy with wireless charging case
- ✓ Other earbuds with wireless charging case
- ✗ Earbuds without wireless charging function



For Galaxy Watch

3W Max

- ✓ Galaxy Watch FE
- ✓ Galaxy Watch Ultra
- ✓ Galaxy Watch 6 Classic
- ✓ Galaxy Watch 6
- ✓ Galaxy Watch 5 Pro
- ✓ Galaxy Watch 5
- ✓ Galaxy Watch 4 Classic
- ✓ Galaxy Watch 4
- ✓ Galaxy Watch 3
- ✓ Galaxy Watch Active 2
- ✓ Galaxy Watch Active
- ✗ Other brand watches

Avoid thick phone case (> 5mm)



Multi-layer like Otterbox defender series, Popsockets, Cardholder, Merallic etc.

Image 6.1: Visual guide to device compatibility, including specific models for phones, watches, and earbuds, and warnings about case thickness.

7. SAFETY INFORMATION

To ensure safe operation and prevent damage to your devices or the charging station, please observe the following safety guidelines:

- This charging station incorporates intelligent charging current control, voltage control, temperature control, and foreign object detection.
- Heat dissipation holes on the back of the station help prevent overheating.
- Do not disassemble, modify, or repair the device yourself.
- Keep the device away from water, moisture, and extreme temperatures.
- Avoid placing metal objects or foreign materials on the charging pads, as this can trigger foreign object detection and prevent charging.
- Use only the provided 30W power adapter and cable for optimal performance and safety.

8. TROUBLESHOOTING

If you encounter issues with your charging station, refer to the following common problems and solutions:

- **Device not charging:**
 - Ensure your device is wirelessly charging-enabled and compatible (refer to Section 6).
 - Check if the device is properly aligned on the charging coil.
 - Remove any thick phone cases (over 5mm) or cases containing metal/magnets.
 - Verify that the power adapter is securely connected and plugged into a working outlet.
 - Ensure no foreign objects are on the charging pad.
- **Slow charging:**
 - Confirm you are using the included 30W Quick Charger 3.0 power adapter. Lower wattage adapters will result in slower charging.
 - Ensure proper device alignment on the charging coil.
 - Close unnecessary background applications on your device.
- **Clock display not working or dim:**
 - Check power connection.
 - Adjust the brightness settings using the designated button (refer to Section 5.2).
- **Night light not working or changing colors:**
 - Ensure the device is powered on.
 - Press the night light button to activate or cycle through colors (refer to Section 5.3).

9. SPECIFICATIONS

Feature	Specification
Model Number	Y23
Input Voltage	9 Volts
Output Voltage	9 Volts
Output Current	4 Amps
Phone Charging Output	Up to 15W (each)
Watch Charging Output	Up to 3W
Earbuds Charging Output	Up to 5W
Power Adapter	30W Quick Charger 3.0 (9V - 3A)
Clock Display	12-hour format, 3 brightness levels
Night Light	7 color modes, 10%-100% adjustable brightness
Connector Type	USB Type C

Item Weight	0.45 Kilograms
Dimensions	23.2 x 17.2 x 3.5 cm (Parcel Dimensions)

10. MAINTENANCE

To maintain your charging station in optimal condition:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surface of the charging station. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the charging station in a cool, dry place away from direct sunlight. The foldable design allows for compact storage.



Image 10.1: The magnetic folding stand feature, illustrating how the station can be adjusted for different viewing angles or folded flat for portability and storage.

11. WARRANTY AND SUPPORT

Your YiJYi 6-in-1 Wireless Charger comes with a standard warranty. For specific warranty details, please refer to the product packaging or contact your retailer.

If you have any questions, require technical assistance, or experience issues not covered in this manual, please do not hesitate to contact YiJYi customer service. Contact information can typically be found on the product packaging or the seller's official website.

© 2025 YiJYi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question