Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wkzay SM-03

Wkzay SM-03 2-in-1 Sound Machine Alarm Clock User Manual

Model: SM-03 | Brand: Wkzay

Introduction

The Wkzay SM-03 is a versatile 2-in-1 device combining a sound machine and an alarm clock, designed to enhance sleep, relaxation, and focus. It features 30 non-looping soothing sounds, 7 gentle alarm sounds, a 7-color night light with 5 brightness levels, and a dimmable clock display. Its compact design makes it suitable for home, office, or travel use.



Image: The Wkzay 2-in-1 Sound Machine Alarm Clock, a compact device for sleep and relaxation.

Safety Information

Avoid electric shock by handling the device properly. Not intended for use as a toy.

Product Overview

The Wkzay SM-03 integrates multiple functions into one compact unit:

- **Sound Machine:** Offers 30 non-looping sounds including white noise, brown noise, pink noise, fan, rain, ocean waves, storms, lullabies, and campfire.
- **Alarm Clock:** Features 7 gentle alarm sounds for a pleasant wake-up experience.
- **Night Light:** Provides 7 color options and 5 adjustable brightness levels.
- **Dimmable Display:** Clock display brightness can be adjusted or turned off completely.
- **Smart Timer:** Auto-shut-off timer from 5 to 480 minutes, or continuous play.
- **Memory Function:** Remembers your last sound, volume, and light settings.



Image: Overview of the 3-in-1 features: sound machine, alarm clock, and night light.

Control Panel Layout

Familiarize yourself with the buttons on the top panel for easy operation.



Image: Detailed view of the control panel buttons and their functions.

Setup

1. **Power Connection:** Connect the provided USB cable to the device and a compatible USB power adapter (not included). Plug the adapter into a wall outlet.
2. **Initial Power On:** The device will typically power on automatically or require a press of the power button.

Operating Instructions

1. **Power On/Off:** Press the power button to turn the device on or off.
2. **Select Sound:** Use the sound selection button (often labeled with music notes or waves) to cycle through the 30 soothing sounds. These include white noise, brown noise, pink noise, fan, rain, ocean waves, bird, brook, bonfire, and lullabies.
3. **Adjust Volume:** Use the volume control buttons (usually labeled "M/-" and "M/+" or similar) to set your desired sound level. There are 30 volume levels available.

4. **Set Sleep Timer:** Press the timer button to set the auto-shut-off timer. Options typically range from 5 to 480 minutes, or continuous play. The device will automatically turn off after the selected duration.
5. **Night Light Operation:** If the device has a built-in night light, press the light button (often labeled with a sun icon) to turn it on/off and cycle through the 7 color options. Use the brightness control (often combined with the light button or a separate button) to adjust the 5 brightness levels.
6. **Alarm Clock Setup:** Press the alarm button (bell icon) to enter alarm setting mode. Use the sound selection or volume buttons to adjust the alarm time and choose from the 7 gentle wake-up sounds. Press the alarm button again to confirm settings.
7. **Display Brightness:** Adjust the clock display brightness using the dedicated dimmer button or a combination of buttons. This allows for 5 levels of brightness, including turning the display off for zero light pollution.
8. **Memory Function:** The device automatically saves your last sound, volume, and light settings. When powered on, it will resume with these personalized settings.

Your browser does not support the video tag.

Video: Official product video demonstrating the features and operation of the Wkzay White Noise Sound Machine with Alarm Clock.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place when not in use.
- **Avoid Water:** Keep the device away from water and high humidity.

Troubleshooting

Problem	Solution
Device does not power on.	Ensure the USB cable is securely connected to both the device and a working power adapter/outlet. Try a different power source.
No sound or low volume.	Check the volume level and increase it using the volume up button. Ensure a sound is selected.
Alarm does not sound.	Verify that the alarm is set correctly and enabled. Check the alarm volume.
Clock display is too bright/dim or off.	Adjust the display brightness using the dimmer function.
Unexpected loud noise from the device.	If the device emits sudden, sharp electrical-type noises, discontinue use immediately and contact customer support. This may indicate a malfunction.

Specifications

Feature	Detail
Model Number	SM-03
Dimensions	4.06 x 3.5 x 3.46 inches
Weight	10.23 ounces (0.29 kg)

Feature	Detail
Power Source	USB-powered (Battery Powered - 1 Nonstandard Battery included for backup)
Material Type	Acrylonitrile Butadiene Styrene (ABS)
Sound Options	30 Non-Looping Sounds
Alarm Sounds	7 Gentle Wake-up Sounds
Night Light	7 Colors, 5 Brightness Levels
Display Dimmer	5 Levels (including off)
Timer Options	5-480 minutes, or Continuous

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Wkzay customer service through the retailer where the product was purchased. Keep your purchase receipt for proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6NF1Y5V

More documents and user manuals: **https://manuals.plus/**