

[Manuals.plus](#) /

› [Ajazz](#) /

› Ajazz AF84 Wireless Typewriter Keyboard User Manual

Ajazz AF84

Ajazz AF84 Wireless Typewriter Keyboard User Manual

Model: AF84

Brand: Ajazz

INTRODUCTION

Thank you for choosing the Ajazz AF84 Wireless Typewriter Keyboard. This keyboard combines a classic retro typewriter aesthetic with modern wireless connectivity, offering a unique and efficient typing experience. It features dual-mode connectivity (Bluetooth and 2.4G wireless) and an integrated stand for tablets and smartphones, making it versatile for various devices and environments.

Please read this manual thoroughly to understand the keyboard's features, setup, and operation, ensuring optimal performance and longevity.



The Ajazz AF84 Wireless Typewriter Keyboard, showcasing its retro design and pink color.

PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- Ajazz AF84 Wireless Typewriter Keyboard
- 2.4G USB Receiver
- User Manual
- (Batteries are not included and must be purchased separately)



The compact 2.4G USB receiver, essential for wireless connection.

SETUP

1. Battery Installation

The Ajazz AF84 keyboard requires **two AAA batteries** (not included). To install:

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

Note: Fresh AAA batteries typically provide over 6 months of usage.

2. Connecting the Keyboard

The keyboard supports two connection modes: 2.4G Wireless and Bluetooth 5.0.

2.1. 2.4G Wireless Connection

This mode uses the included USB receiver and is ideal for devices without Bluetooth or for a stable, direct connection.

1. Locate the 2.4G USB receiver, usually stored in a compartment on the keyboard itself or within the packaging.

2. Plug the USB receiver into an available USB port on your computer or device.
3. Turn on the keyboard using the power switch (location may vary, typically on the side or back).
4. The keyboard should automatically connect to the receiver. A status indicator light may illuminate briefly.

2.2. Bluetooth Connection

This mode allows connection to Bluetooth-enabled devices like laptops, tablets, and smartphones.

1. Ensure the keyboard is powered on.
2. Press and hold the **Fn + 1** (or **Fn + 2**, **Fn + 3** for additional Bluetooth profiles if available) key combination to enter Bluetooth pairing mode. The indicator light will typically blink rapidly.
3. On your device (computer, tablet, smartphone), go to Bluetooth settings.
4. Search for new devices. You should see "Ajazz AF84" or a similar name appear in the list.
5. Select "Ajazz AF84" to pair. If prompted for a passkey, enter "0000" or follow the on-screen instructions.
6. Once paired, the indicator light on the keyboard will stop blinking and remain solid or turn off.

Note: The keyboard can remember multiple Bluetooth devices. Refer to the specific key combinations for switching between paired devices if applicable (e.g., Fn+1, Fn+2, Fn+3).

3. Using the Integrated Stand

The Ajazz AF84 features an extended front ledge with a sturdy card slot designed to hold your tablet or smartphone securely.

- Simply place your device (up to 12.9 inches) into the slot.
- This allows for hands-free viewing while typing, enhancing productivity.

Bracket With Bayonet

Support For Smartphone Or Tablets



The integrated stand securely holding a tablet, demonstrating its utility for multi-device setups.



The keyboard in a workspace setup, showing a tablet in the stand and a smartphone nearby, highlighting its multi-device compatibility.

OPERATING INSTRUCTIONS

Basic Typing

Once connected, the keyboard functions like a standard QWERTY keyboard. The round keycaps provide a comfortable and tactile typing experience reminiscent of a classic typewriter.

Special Functions and Multimedia Keys

The Ajazz AF84 includes 84 keys, some of which have dual functions accessible via the **Fn** (Function) key. Look for icons or secondary labels on the F-keys (F1-F12) and other keys.

- **Fn + F1-F12:** These keys typically control multimedia functions (e.g., volume up/down, play/pause, next/previous track) or system functions (e.g., screen brightness, search). Refer to the keycap legends for specific functions.
- **Fn + Q/W/E:** Often used for switching between Bluetooth profiles or operating system modes (e.g., Windows, macOS, Android). Consult the keyboard's specific key legends for confirmation.

- **Adjustable Feet:** On the underside of the keyboard, you will find adjustable feet. Flip these out to change the typing angle for improved ergonomic comfort during long typing sessions.



The black variant of the Ajazz AF84 keyboard, illustrating its key features including wireless connectivity and multimedia key functionality.

MAINTENANCE

Cleaning the Keyboard

To maintain the keyboard's appearance and functionality:

- Turn off the keyboard before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaning solution to wipe the surface.
- For dust and debris between keycaps, use compressed air or a small brush.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the keyboard's finish.

Battery Replacement

When the keyboard's performance degrades or it stops responding, it's likely time to replace the AAA batteries. Follow the battery installation steps outlined in the "Setup" section.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding	Low batteries, not powered on, not connected.	Replace batteries, ensure power switch is ON, re-establish 2.4G or Bluetooth connection.
Bluetooth pairing fails	Keyboard not in pairing mode, device Bluetooth off, interference.	Ensure keyboard is in pairing mode (blinking light), turn on device Bluetooth, move closer to device, try pairing again.
2.4G connection unstable	USB receiver not properly inserted, interference.	Re-insert USB receiver, try a different USB port, ensure no large metal objects are between keyboard and receiver.
Keys not typing correctly	Debris under keycap, software issue.	Clean under keycaps with compressed air, restart your device.

SPECIFICATIONS

Feature	Detail
Model Name	AJAZZ AF84
Connectivity Technology	2.4Ghz Wireless, Bluetooth 5.0
Number of Keys	84
Key Type	Round Keycaps (Membrane Keyboard)
Compatible Devices	Laptop, PC, Smartphone (Windows, macOS, Android)
Power Source	2 x AAA Batteries (not included)
Battery Life	Approx. 6+ months (depending on usage)
Material	Plastic
Color	Pink/White (other colors may be available)
Item Weight	1.85 pounds (approx. 0.84 kg)
Package Dimensions	14.57 x 8.27 x 2.56 inches (approx. 37 x 21 x 6.5 cm)
Country of Origin	China

WARRANTY AND SUPPORT

Ajazz products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the product packaging or visit the official Ajazz website. Keep your purchase receipt as proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question