

[Manuals.plus](#) /

› [Jimmyjane](#) /

› Jimmyjane Touch Me Pro Rechargeable Rabbit Vibrator User Manual

Jimmyjane Touch Me Pro

Jimmyjane Touch Me Pro Rechargeable Rabbit Vibrator User Manual

Model: Touch Me Pro (ASIN: B0F6NZMRKZ)

INTRODUCTION

The Jimmyjane Touch Me Pro is a rechargeable rabbit vibrator designed to provide a unique sensory experience. This device integrates Harmonic Touch Massage Action with Stereophonic Percussion Therapy, aiming to deliver a comprehensive stimulation. It features a main shaft with Dual Hyper-Pulse percussion massage points for targeted G-Spot stimulation and a clitoral stimulator with Come-Hither action.



Image: The Jimmyjane Touch Me Pro Rechargeable Rabbit Vibrator in magenta, showcasing its ergonomic design and dual stimulators.

SAFETY INFORMATION

- Clean the device with antibacterial cleaner and warm water only.

- Avoid use in or near water.
- Keep away from excessive heat and direct sunlight.
- Do not share the device with others to prevent cross-contamination.

SETUP

Before first use, ensure the device is fully charged and cleaned according to the maintenance instructions.

Charging the Device

To charge the Touch Me Pro, use the included Magnetic USB charger. Connect the charger to a USB power source and attach the magnetic end to the charging points on the device. The device will indicate when it is charging and when it is fully charged.



OPERATING INSTRUCTIONS

The Touch Me Pro features three control buttons for various functions:

- Top Button:** Press this button to control the 10 modes of Dual Hyper-Pulse percussion in the tip, targeting the G-Spot.
- Middle Button:** This button activates the unique Come-Hither action, offering 10 modes of clitoral stimulation.
- Bottom Button:** Use this button to cycle through 10 powerful vibration modes for the main shaft.

Travel Lock

For discreet travel, press the **top two buttons simultaneously for five seconds** to activate the travel lock. The device will unlock automatically upon charging.

Lubricant Use

Always use a water-based lubricant with this device to ensure optimal performance and material longevity.

MAINTENANCE AND CARE

Cleaning

After each use, clean the device thoroughly with an antibacterial cleaner and warm water. Ensure all surfaces are dry before storage.

Storage

Store the device in a clean, dry place away from direct sunlight and extreme temperatures. Ensure it is fully charged before long-term storage to maintain battery health.

TROUBLESHOOTING

If the device does not function as expected, please check the following:

- Ensure the device is fully charged. A low battery can affect performance.
- Verify that the travel lock is not activated. If it is, connect the charger to unlock it.

For persistent issues or technical support, please refer to the warranty and support information provided with your purchase.

SPECIFICATIONS

Feature	Detail
Brand	Jimmyjane
Model Name	Touch Me Pro
ASIN	B0F6NZMRKZ

Feature	Detail
Color	Magenta
Material	Plastic
Manufacturer	Pipedream Products
Package Dimensions	7 x 5 x 3 inches
Item Weight	1 Pound

WARRANTY AND SUPPORT

Warranty Information

The Jimmyjane Touch Me Pro is covered by a **1-Year Limited Warranty**. Please retain your proof of purchase for warranty claims.

Customer Support

For support, inquiries, or to make a warranty claim, please refer to the contact information provided with your product packaging or visit the official Jimmyjane website. The product also includes a 1-Year Discreet Shipping & Returns policy.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

