

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Losi](#) /
- › Losi Micro-T RC Car 1/28 2WD Silver RTR Instruction Manual

Losi LOS-1392T2

Losi Micro-T 1/28 2WD Silver RTR

INSTRUCTION MANUAL

Introduction

This instruction manual provides essential information for the safe and effective operation, maintenance, and care of your Losi Micro-T 1/28 2WD Silver RTR RC Stadium Truck. Please read this manual thoroughly before operating your vehicle to ensure proper function and to prevent damage or injury.

The Losi Micro-T is a high-performance 1/28 scale 2WD stadium truck designed for both new and experienced RC enthusiasts. It features a durable aluminum chassis, oil-filled shocks, and is capable of speeds above 13 mph. The included Spektrum SLT2 transmitter offers a "Rookie Mode" for controlled learning.



Image: The Losi Micro-T 1/28 2WD Silver RTR RC Stadium Truck displayed with its included accessories, including the battery and charger.

Safety Information

WARNING: Read the ENTIRE instruction manual to become familiar with the features of the product before operating. Failure to operate the product correctly can result in damage to the product, personal property, and cause serious injury. This is a sophisticated hobby product. It must be operated with caution and common sense and requires some basic mechanical ability. Failure to operate this Product in a safe and responsible manner could

result in injury or damage to the product or other property. This product is not intended for use by children without direct adult supervision. Do not use with incompatible components or alter this product in any way outside of the instructions provided by Horizon Hobby, LLC. The product manual contains instructions for safety, operation, and maintenance. It is essential to read and follow all the instructions and warnings in the manual, prior to assembly, setup, or use, in order to operate correctly and avoid damage or serious injury.

- Always operate your RC vehicle in open areas away from people, pets, and other obstacles.
- Avoid operating near water, power lines, or busy roads.
- Ensure the battery is fully charged and securely installed before operation.
- Always turn off the vehicle and transmitter when not in use.
- Keep hands, hair, and loose clothing away from moving parts.
- Do not attempt to modify or disassemble the electronic components.

What's in the Box

Your Losi Micro-T 1/28 2WD Silver RTR package includes the following items:

- Micro-T 1/28 2WD Silver RTR RC Stadium Truck (Fully assembled)
- Spektrum SLT2 Transmitter
- Rechargeable Battery Pack
- USB-C Charger Adapter
- 4 AA batteries (for transmitter)

Setup

1. Charge the Battery:

Connect the included rechargeable battery pack to the USB-C charger adapter. Plug the charger into a compatible USB power source. The battery typically recharges in approximately one hour. Ensure the charging indicator light (if present on charger) shows a full charge before proceeding.

2. Install Transmitter Batteries:

Open the battery compartment on the Spektrum SLT2 transmitter and insert the 4 AA batteries provided, ensuring correct polarity.

3. Install Vehicle Battery:

Carefully open the battery compartment on the Micro-T vehicle. Connect the fully charged battery pack to the vehicle's power connector. Securely close the battery compartment.

4. Power On Sequence:

Always turn on the transmitter *first*, then the vehicle. To power off, turn off the vehicle *first*, then the transmitter. This sequence prevents accidental runaway.



Image: A detailed view of the Losi Micro-T RC Car, showcasing its front and side profile, ready for operation.

Operating Instructions

The Losi Micro-T is designed for exciting performance. Familiarize yourself with the transmitter controls before driving at full speed.

- **Steering:** Use the steering wheel on the transmitter to control the direction of the vehicle (left/right).
- **Throttle:** Use the trigger on the transmitter to control forward and reverse movement. Pull the trigger for forward motion, push for reverse/brake.
- **Rookie Mode:** The Spektrum SLT2 transmitter features a "Rookie Mode" for new or inexperienced drivers. This mode limits the vehicle's speed to 50% or 75% of its full potential. To activate, locate the switch on the back of the transmitter and adjust as desired. This allows for safer learning and control development.
- **Driving Environment:** Operate the Micro-T on flat, clear surfaces. Its compact size makes it suitable for indoor use, but ensure adequate space to avoid collisions. For outdoor use, choose smooth, paved areas or short grass.



Image: The Losi Micro-T RC Car navigating a rocky outdoor environment, demonstrating its off-road capability.



Image: The Losi Micro-T RC Car positioned indoors on a carpeted surface, highlighting its suitability for indoor play.

Maintenance

Regular maintenance will extend the life and performance of your Micro-T.

- **Cleaning:** After each use, especially outdoors, clean the vehicle to remove dirt, dust, and debris. Use a soft brush or compressed air. Avoid using water directly on electronic components.
- **Inspecting Components:** Periodically check for loose screws, damaged wires, or worn parts. Pay attention to the wheels, suspension, and steering linkages.
- **Battery Care:** Always disconnect the battery from the vehicle when not in use. Store batteries in a cool, dry place. Do not overcharge or completely discharge the battery.
- **Lubrication:** Lightly lubricate moving parts like gears and bearings as needed with RC-specific lubricant.



Image: A clear side profile of the Losi Micro-T RC Car, useful for inspecting chassis and wheel components during maintenance.

Troubleshooting

Problem	Possible Cause	Solution
Vehicle does not respond	Low vehicle battery; Transmitter not powered on; Not properly bound.	Charge vehicle battery; Turn on transmitter first; Re-bind transmitter and receiver (refer to advanced manual if needed).
Short run time	Battery not fully charged; Old/damaged battery.	Ensure full charge; Consider replacing battery if performance degrades.
Vehicle pulls to one side	Steering trim incorrect; Damaged steering linkage.	Adjust steering trim on transmitter; Inspect and replace damaged parts.
Loss of range/control	Interference; Low transmitter battery.	Move to an area with less interference; Replace transmitter batteries.

Specifications

- **Model Number:** LOS-1392T2
- **Scale:** 1/28
- **Drive:** 2WD
- **Top Speed:** 13+ mph
- **Chassis:** Aluminum
- **Shocks:** Oil-filled
- **Product Dimensions:** 10.5 x 6 x 5.4 inches
- **Item Weight:** 1.63 pounds
- **Recommended Age:** 14 years and up
- **Batteries:** 4 AA batteries required (included for transmitter)
- **Manufacturer:** Horizon Hobby



Image: A direct front view of the Losi Micro-T RC Car, highlighting its compact size and robust design on a gravel surface.

Warranty and Support

For detailed warranty information and technical support, please refer to the documentation provided by the manufacturer, Horizon Hobby, or visit their official website. Keep your proof of purchase for warranty claims.

You can also visit the [Losi Store on Amazon](#) for additional product information and accessories.