

[manuals.plus](#) /

› [FONTOI](#) /

› [FONTOI TV Stand Model TV Stand002 Instruction Manual](#)

## FONTOI TV Stand002

# FONTOI TV Stand Model TV Stand002 Instruction Manual

Model: TV Stand002

Brand: FONTOI

## 1. INTRODUCTION

---

This manual provides essential information for the assembly, operation, and maintenance of your FONTOI TV Stand Model TV Stand002. This mid-century modern entertainment center is designed to accommodate televisions up to 59 inches and features a slatted sliding door with internal storage compartments.



Image: The FONTOI TV Stand Model TV Stand002, showcasing its mid-century modern design with a slatted sliding door and open shelving, integrated into a living room environment.

## 2. SAFETY INFORMATION

---

- Read all instructions carefully before beginning assembly and use.
- Ensure all connections are secure and tightened properly during assembly to prevent instability.
- Do not exceed the maximum weight capacity of 250 lbs (113 kg) for the TV stand.
- Place the TV stand on a level and stable surface to prevent tipping.
- Keep small parts and packaging materials away from children and pets to avoid choking hazards.
- Avoid placing hot items directly on the surface without protective padding.

## 3. PACKAGE CONTENTS

---

Before beginning assembly, verify that all components are present and undamaged. Refer to the parts list provided in your product packaging. Typical components include:

- Top Panel
- Bottom Panel

- Side Panels
- Back Panel
- Internal Shelves
- Sliding Door
- Legs
- Hardware (screws, dowels, cam locks, etc.)
- Assembly Tools (if included)

## 4. SETUP AND ASSEMBLY

---

Assembly is required for this product. Follow the detailed instructions provided in your product packaging. The general steps are outlined below:

1. **Unpack and Identify:** Carefully unpack all components and identify them against the parts list in your packaging.
2. **Attach Legs:** Securely attach the four legs to the designated points on the bottom panel of the TV stand.
3. **Assemble Frame:** Connect the side panels to the bottom and top panels to form the main frame of the unit.
4. **Insert Shelves:** Place the internal shelves into their respective positions within the frame.
5. **Install Sliding Door:** Mount the sliding door mechanism and then carefully insert the slatted door into its tracks.
6. **Secure Back Panel:** Attach the back panel to the rear of the unit.
7. **Final Placement:** Carefully move the assembled TV stand to its desired location, ensuring it is level.

# PRODUCT SIZE




Image: FONTOI TV Stand dimensions, showing overall size and internal shelf measurements. The stand measures 46 inches in length, 14.2 inches in depth, and 17.8 inches in height, with a leg height of 7 inches. The internal shelf height is 9.4 inches. Maximum weight capacity is 250 lbs.

# Suitable For Tvs Up To 59 Inches




Image: Visual representation of the FONTOI TV Stand's suitability for various TV sizes, up to 59 inches. This image illustrates how different TV sizes (32", 43", 50", 55", 59") fit above the stand.

## 5. OPERATING INSTRUCTIONS

The FONTOI TV Stand is designed for convenient storage and display.

- **Sliding Door Operation:** The TV stand features a slatted sliding door. To access the internal storage, gently slide the door horizontally along its track. The door can be positioned to cover either the left or right storage compartment as needed.
- **Storage Use:** The open shelves and concealed compartments are suitable for media devices such as DVD players, game consoles, and routers, as well as decorative items, books, and small ornaments.



## The door can move from side to side

Image: Demonstration of the sliding door mechanism on the FONTOI TV Stand. An arrow indicates the horizontal movement of the slatted door, allowing access to the internal storage compartments.

## 6. MAINTENANCE AND CARE

To maintain the appearance and longevity of your FONTOI TV Stand, follow these care instructions:

- **Cleaning:** Regularly dust the surface with a soft, dry cloth. For spills, wipe immediately with a damp cloth and then dry thoroughly with a clean, dry cloth.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- **Environmental Factors:** Keep the TV stand away from direct sunlight and excessive moisture to prevent warping or discoloration.
- **Protection:** Use coasters or protective pads under hot items or items that may scratch the surface.



Easy to Clean



Smooth Curved Edge



Large Storage Space

Image: Detailed view of the FONTOI TV Stand highlighting key features: an 'Easy to Clean' surface, 'Smooth Curved Edge' design, and 'Large Storage Space' with a cable management cutout.

## 7. TROUBLESHOOTING

If you encounter any issues with your FONTOI TV Stand, refer to the following common troubleshooting tips:

- **Door not sliding smoothly:** Check the tracks for any obstructions or debris. Ensure the door is properly seated in its runners. A small amount of silicone lubricant can be applied to the tracks if needed.
- **Unit wobbles:** Verify that all assembly screws are tightened securely. Ensure the stand is placed on a level surface. If the floor is uneven, consider using furniture pads or shims under the legs to stabilize the unit.
- **Missing parts or damaged components:** If you discover missing parts or damaged components upon unpacking, do not proceed with assembly. Contact customer support immediately with your purchase details.

## 8. SPECIFICATIONS

Feature	Specification
Brand	FONTOI
Model Name	TV Stand
Item Model Number	TV Stand002
Color	Wood Color
Mounting Type	Floor Mount
Door Style	Shutter
Item Weight	39.7 Pounds (18 kg)
Product Dimensions	46 x 14 x 17.5 inches (L x W x H)
Assembly Required	Yes
Base Type	Legs
UPC	683770291283

## 9. WARRANTY INFORMATION

---

Warranty information is not explicitly provided in the product details. Please refer to your purchase documentation or contact the retailer/manufacturer directly for specific warranty terms and conditions.

## 10. CUSTOMER SUPPORT

---

For further assistance, inquiries regarding missing parts, or warranty claims, please contact FONTOI customer support.

**Brand:** FONTOI

**Online Store:** [Visit the FONTOI Store on Amazon](#)

Please have your model number (TV Stand002) and purchase details ready when contacting support.