

- Manuals.plus /
- > PHILIPS /
 - > Philips 32-inch Tuner-less Google TV (Model PHH6569) User Manual

PHILIPS PHH6569

Philips 32-inch Tuner-less Google TV


Model: PHH6569
User Manual

1. PRODUCT OVERVIEW

The Philips 32-inch Tuner-less Google TV (Model PHH6569) is designed for streaming online content, eliminating the need for traditional antenna connections. This smart TV features a 720P HD display with HDR10 support, integrated Google TV for access to various streaming services, Bluetooth connectivity, and voice search capabilities. Please note that this TV does not include terrestrial, BS, or 110°CS tuners. An external tuner is required for these broadcasts.

PHILIPS × Google TV

充実な動画配信サービス シームレスなエンターテインメントを楽しむ



多彩なネット動画をお手軽に



※サービスの利用は別途登録・契約や料金が必要な場合があります。
※ご利用の際は、インターネットに接続されていることをご確認ください。

Front view of the Philips 32-inch Tuner-less Google TV.

The TV features a sleek, bezel-less design, enhancing immersion. It is lightweight, weighing approximately 3.9 kg without the stand, making it suitable for wall mounting.



The TV's bezel-less design for an immersive viewing experience.

2. SETUP

2.1 Unpacking and Assembly

Carefully remove all components from the packaging. The package includes:

- TV Unit
- 2x Stands (with 4 screws for attachment)
- Remote Control (requires 2 AAA batteries for operation)
- Power Cable
- Instruction Manual
- 2x Screws (ST4 x 7.5-8.5mm for bottom side)

Attach the two stands to the TV using the provided screws. Ensure they are securely fastened. Alternatively, the TV supports VESA 200x200mm wall mounting.



The Philips TV PHH6569, illustrating its compact design and connectivity features.

2.2 Initial Power On and Configuration

Plug the power cable into an electrical outlet. The TV will power on and guide you through the initial setup process. This typically includes:


1. Language selection.
2. Connecting to your Wi-Fi network.
3. Logging into your Google account.
4. Accepting terms and conditions.

An internet connection is required to use Google TV features. After establishing an internet connection, restart the TV for optimal performance.

3. OPERATING INSTRUCTIONS

3.1 Google TV Features

The Philips TV integrates Google TV, providing a centralized platform to access a wide range of streaming services and content. From the home screen, you can select movies, shows, and apps from your subscriptions. Google's recommendation engine suggests content based on your viewing habits. The TV supports multiple user profiles, allowing each family member to have a personalized experience.



The Google TV interface with popular streaming applications.

The Watchlist feature allows you to save content you're interested in, accessible from anywhere. You can add content to your Watchlist on the go and it will be saved to your TV's library at home.



The Watchlist feature for saving content across devices.

Multiple Google accounts can be registered on one TV, enabling personalized settings and content recommendations for each user.



Multi-account support for personalized user experiences.

3.2 Voice Control and Remote

The included remote control supports voice input via Google Assistant. Press the voice search button on the remote and speak your commands to search for movies, shows, apps, or control TV functions. The remote also features direct access buttons for popular streaming services like ABEMA, YouTube, Netflix, and Hulu.



The remote control with voice search and quick access buttons.

3.3 Google Cast Functionality

Mirror content from your smartphone or tablet directly to the TV using the built-in Google Cast feature. This allows you to view smartphone videos, photos, and games on the larger TV screen. It is compatible with both iPhone and Android devices.



Google Cast feature for mirroring content from mobile devices.

3.4 Picture Quality and Modes

The TV features a 720P HD display with a resolution of 1280x720 pixels, providing sharp and clear images. It supports High Dynamic Range (HDR10) technology, enhancing contrast and color accuracy for a more vibrant viewing experience.



使い勝手の良いリモコン
お気に入りのコンテンツを簡単に検索

OK Google 音声検索 | VOD対応

ボタン1つでスムーズにアクセス

ABEMA YouTube
NETFLIX hulu

天気はどうですか
音量を上げて

HDR10/HLG support for enhanced image detail and clarity.



高画質・高音質
次世代クアッドコアチップ搭載

HDR 10 | 4K | LED | Dolby Audio

High-definition display for sharp and vivid images.

The TV utilizes an LED direct backlight system for precise color management and clear, vibrant images.



HDR 10 | HLG

HDR 10/HLG対応
進化したHDR映像の表現力

映像の明暗部のディティールを
驚くほどクリアに再現。

HDR対応 | HDR非対応

LED direct backlight for precise color and clear images.

Optimize your viewing experience with various picture modes:

- **Standard Mode:** Default settings for balanced viewing.
- **Eco Mode:** Energy-saving mode, environmentally friendly.
- **Movie Mode:** Optimized for movies and dramas.
- **Gentle Mode:** Reduces eye strain.
- **Game Mode:** Optimizes response time for gaming.
- **Vivid Mode:** Enhances brightness and color for bright environments.
- **Personal Mode:** Customizable settings.
- **Sports Mode:** Reduces motion blur during sports broadcasts.
- **Dynamic Mode:** For vibrant images in bright environments.



多彩な映像モード

使用シーンに合わせて最適な視聴体験を



パーソナルモード

ユーザーが好みに合わせて設定をカスタマイズできます。



スポーツモード

スポーツ観戦中の残像感を低減させ、おうちで大迫力のスポーツ観戦を楽しめます。



ダイナミックモード

鮮やかでメリハリのある映像を映し出し、明るい環境での視聴に最適です。



スタンダードモード

デフォルト設定で、ほとんどのコンテンツに適したバランスの取れた視聴体験を提供します。




エコモード

省エネルギーを目的としたモードで、環境に優しいです。



ムービーモード

暗い環境で映画やドラマの視聴に最適です。




ジェントルモード

目の疲れを軽減し、快適な視聴を提供します。



ゲームモード

応答性を最適化し、FPSやアクションゲームの体験を最大化させます！



ビビットモード

明るい照明のある環境や、鮮やかで印象的な映像を好む方に適しています。

Multiple image modes to suit various content types and preferences.

3.5 Audio Features

The TV is equipped with Dolby Audio, providing an immersive sound experience with high-quality audio and enhanced sound reproduction. The maximum speaker output is 6W+6W.

Dolby Audio for an immersive sound experience.

With Bluetooth 5.0 support, you can connect wireless headphones, soundbars, or stereo speakers to the TV. This allows for private listening or enhanced audio output without disturbing others.



Bluetooth 5.0対応

ヘッドホンなどで音声が聴ける

ワイヤレス
イヤホン

ヘッドホン

サウンドバー

ステレオ
スピーカー

音漏れを気にすることなくテレビを楽しめる。

Bluetooth 5.0 connectivity for various audio devices.

4. MAINTENANCE

To ensure the longevity and optimal performance of your Philips TV, follow these maintenance guidelines:

- **Screen Cleaning:** Gently wipe the screen with a soft, dry, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-specific cleaning solution. Avoid using harsh chemicals, alcohol, or abrasive materials, as these can damage the screen.
- **Frame Cleaning:** Clean the TV frame and stand with a soft, dry cloth.
- **Ventilation:** Ensure that the ventilation openings on the TV are not blocked. Allow adequate space around the TV for proper airflow to prevent overheating.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, discontinue use and contact customer service.
- **Dust Removal:** Use a soft brush or a vacuum cleaner with a brush attachment to gently remove dust from the vents and ports.

5. TROUBLESHOOTING


If you encounter issues with your Philips TV, refer to the following troubleshooting tips:

- **Amazon Prime Video App Freezing:** If the Amazon Prime Video app freezes on the title screen, navigate to **Settings > Apps > Prime Video**, and select 'Clear Cache'. You may need to re-register your device after clearing the cache.
- **Remote Control Unresponsive:** If the remote control stops responding, remove the batteries and leave them out for 5-10 minutes to discharge. Reinsert fresh AAA batteries. If the issue persists, contact customer support.
- **Screen Freezing or Blue Screen:** If the screen freezes or displays a blue screen, unplug the TV from the power outlet, wait a few minutes, then plug it back in. This often resolves temporary software glitches.
- **Wi-Fi Connection Issues:** Ensure your TV is connected to the internet. After connecting to Wi-Fi, restart the TV for optimal performance. If problems persist, try restarting your router.
- **Poor Picture/Sound Quality:** Check all cable connections (HDMI, USB). Ensure the content source is of high quality. Adjust picture and sound settings in the TV menu.

For further assistance, refer to the Warranty and Support section.

6. SPECIFICATIONS

Feature	Specification
Brand	PHILIPS
Model Name	32PHH6569
Screen Size	32 inches
Display Technology	LCD
Resolution	1280 x 720 (HD)
Aspect Ratio	16:9
Refresh Rate	60 Hz
HDR Support	HDR10
Audio Encoding	DD (Dolby Digital)
Speaker Features	Dolby Audio
Max Speaker Output	6W + 6W
Speaker Channel Configuration	2.0
Connectivity Technology	Bluetooth, HDMI, USB, Wi-Fi
Bluetooth Version	5.0
Wireless Type	Bluetooth, Wi-Fi (2.4GHz/5GHz)
HDMI Ports	2
USB Ports	2
Screen Mirroring Technology	Google Cast
Power Consumption	55 Watts
Voltage	100 Volts
Product Dimensions (D x W x H)	19.4 x 71.7 x 46.6 cm (with stand)
Product Weight	3.9 kg (without stand)
Wall Mount Dimensions	200 x 200 mm (M4)
Included Components	Stands, Warranty Card, Power Cable, Remote Control
Remote Control Battery Type	AAA batteries (2 required)



Rear view of the TV showing available ports.

7. WARRANTY AND SUPPORT

All Philips products sold are genuine. This product comes with a **365-day manufacturer's warranty**. In the event of product defects under normal use, a free product exchange will be provided. This warranty does not cover malfunctions caused by customer intent or negligence.

If the product arrives damaged or scratched during delivery, please contact customer service immediately for a free exchange.

Customer Service Hours:

Monday - Friday: 10:00 - 12:00 / 13:00 - 17:00 JST

(Excluding Saturdays, Sundays, public holidays, summer holidays, and New Year holidays)

For common questions, refer to the Q&A below:

ブランド	フィリップス	光出力 ● USB 1 インターフェース ● USB 2 インターフェース ● イヤホンソケット ● AV入力 ● HDMI 1入力 ● HDMI 2入力 ● LAN端子 ●
品名	チューナーレステレビ	
品番	PHH6569	
画面サイズ	32V	
画素数	1366 x 768	
リフレッシュレート(倍速機能)	60 Hz	
壁掛け寸法	縦200 mm x 横200 mm (M4)	
外形寸法(幅x高さx奥行)	717 x 424 x 82 mm(スタンド無)	
外形寸法(幅x高さx奥行)	717 x 476 x 223 mm(スタンド有)	
質量(スタンド無)	3.9 kg	
質量(スタンド有)	4 kg	
最適視聴距離		100~150cm
推奨部屋サイズ		約6畳
視聴角度		±178°

Common questions and answers regarding TV functionality.

Frequently Asked Questions (FAQ):

Q: Is an internet connection required to use Google TV?

A: Yes, an internet connection is required. Please restart the TV after connecting to the internet.

Q: What languages does OK Google support?

A: OK Google supports over 40 languages. After logging into your Google account, you can preset languages with the language assistant.

Q: Is it necessary to connect to the same network as my smartphone to use Chromecast?

A: Yes, it is necessary to connect to the same network.

Q: How do I use the Chromecast feature?

A: Android users can utilize the Chromecast feature by downloading the Google Home app. Apple users can enable Chromecast by downloading the Videocast app or Aircscreen app from the App Store.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F6SZ7RQP>

More documents and user manuals: <https://manuals.plus/>