

ALLJOY HKXM-AJEHB22-L-2018-DE-05

ALLJOY Electric Heated Blanket 200x180cm - User Manual

Model: HKXM-AJEHB22-L-2018-DE-05

1. INTRODUCTION AND IMPORTANT SAFETY INFORMATION

Thank you for choosing the ALLJOY Electric Heated Blanket. This manual provides essential instructions for the safe and effective use, maintenance, and troubleshooting of your blanket. Please read this manual thoroughly before first use and keep it for future reference.

Important Safety Warnings:

- Do not use with infants, children, or persons insensitive to heat, or those unable to react to overheating.
- Do not use if wet.
- Do not use if folded or bunched.
- Do not insert pins or other sharp objects into the blanket.
- Always disconnect the power cord from the outlet when not in use or before cleaning.
- Regularly inspect the blanket for any signs of wear or damage. If damaged, do not use and contact customer support.
- Keep the control unit away from water or other liquids.
- This appliance is not intended for medical use in hospitals.




Image: The ALLJOY Electric Heated Blanket (200x180cm) laid out on a bed, illustrating the internal heating wire distribution for even warmth.

2. PRODUCT FEATURES

- **Generous Size:** 200 x 180 cm, suitable for large beds or comfortable use by two people.
- **Premium Material:** Crafted from ultra-soft imitation lambswool and flannel for maximum comfort and warmth.
- **9 Heat Levels:** Adjustable temperature settings ranging from approximately 25°C to 45°C ($\pm 5^{\circ}\text{C}$) to customize your warmth.
- **9 Automatic Shut-off Timers:** Programmable auto-off function from 20 to 180 minutes to conserve energy and ensure safety.
- **Rapid Heating:** Evenly distributed heating wire ensures quick and uniform warmth.
- **Long Power Cable:** An 8.5-foot (approximately 2.6 meters) power cord provides flexibility in placement.
- **Machine Washable:** Detachable controller and cable allow for easy machine washing at 30°C.

UPGRADED SUPER COZY DOUBLE-SIDED DESIGN

Thickened Fabric for Enhanced Warmth



Flannel

Imitation Lambswool

Image: Close-up of the blanket's double-sided design, featuring soft flannel and imitation lambswool for enhanced comfort.



Image: A detailed view highlighting the distinct textures of the flannel and imitation lambswool sides of the blanket.

3. SETUP

1. **Unpack:** Carefully remove the electric blanket from its packaging. Retain packaging for storage or future transport.
2. **Inspect:** Before first use, visually inspect the blanket and the control unit for any signs of damage, cuts, or frayed wires. Do not use if any damage is observed.
3. **Placement:** Lay the blanket flat on your bed or desired surface. Ensure it is not folded, bunched, or creased, as this can lead to localized overheating.
4. **Connect Controller:** Locate the connector on the blanket and the corresponding plug on the control unit. Firmly insert the control unit plug into the blanket connector until it clicks securely into place. Ensure the connection is tight.
5. **Power Connection:** Plug the power cord of the control unit into a standard electrical outlet. Ensure the outlet is easily accessible.

4. OPERATING INSTRUCTIONS

The ALLJOY Electric Heated Blanket features an intuitive LCD controller for easy operation.

4.1 Power On/Off

- To turn on, press the **Power button** on the controller. The LCD display will illuminate.
- To turn off, press the **Power button** again. The display will turn off, and the blanket will cease heating.

4.2 Adjusting Heat Levels

- Once powered on, use the "+" or "-" buttons to cycle through the 9 heat settings (1 being the lowest, 9 being the highest).
- The selected heat level will be displayed on the LCD screen.
- Start with a lower setting and adjust upwards to find your preferred comfort level.

9 TEMPERATURE SETTINGS

Adjustable Heat Levels to Personalized Warmth




Image: A couple using the blanket, with an overlay showing the 9 temperature settings and their approximate range (25°C - 45°C).



Image: Close-up of the temperature control interface and a diagram illustrating the blanket's internal heating wire and safety layers.

4.3 Setting the Automatic Shut-off Timer

- Press the **Timer button** on the controller.
- Each press will cycle through the available auto-off settings: 20, 40, 60, 80, 100, 120, 140, 160, and 180 minutes.
- The selected time will be displayed on the LCD screen. The blanket will automatically turn off after the set duration.
- If you require heat beyond 180 minutes, you will need to restart the blanket manually.



9 AUTO OFF SETTINGS

Customizable Timers for Personalized Use

alljoy | A HEALTHY
GIFT FOR JOY.

Mode 1: **20**min

alljoy | A HEALTHY
GIFT FOR JOY.

Mode 1: **40**min

alljoy | A HEALTHY
GIFT FOR JOY.

Mode 1: **60**min

alljoy | A HEALTHY
GIFT FOR JOY.

Mode 1: **80**min

alljoy | A HEALTHY
GIFT FOR JOY.

Mode 1: **100**min

alljoy | A HEALTHY
GIFT FOR JOY.

Mode 1: **120**min

alljoy | A HEALTHY
GIFT FOR JOY.

Mode 1: **140**min

alljoy | A HEALTHY
GIFT FOR JOY.

Mode 1: **160**min

alljoy | A HEALTHY
GIFT FOR JOY.

Mode 1: **180**⁰min

Image: A family enjoying the blanket, with an illustration of the 9 auto-off timer options (20 to 180 minutes).

5. MAINTENANCE AND CLEANING

Proper care ensures the longevity and safe operation of your electric blanket.

1. **Disconnect Power:** Always ensure the blanket is turned off and unplugged from the wall outlet before cleaning.

2. **Remove Controller:** Carefully detach the control unit from the blanket connector. Ensure the blanket is completely cool before doing so.
3. **Machine Washing:** The blanket is machine washable. Wash on a gentle cycle with cold water (maximum 30°C). Use a mild detergent.
4. **Drying:** Do not tumble dry. Air dry the blanket completely by hanging it or laying it flat. Ensure it is thoroughly dry before reconnecting the controller or storing.
5. **Do Not Iron:** Do not iron the electric blanket.
6. **Do Not Dry Clean:** Do not dry clean the electric blanket.
7. **Storage:** When not in use, store the blanket in a cool, dry place. Avoid folding it tightly or placing heavy objects on it, which could damage the internal wiring.

MACHINE WASHABLE



Cold water wash



Do not dry



Do not ironing



Image: A woman demonstrating how to place the blanket into a washing machine, highlighting the detachable power cable for safe cleaning.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blanket not heating.	Not plugged in. Controller not securely connected to blanket. Power button not pressed. Automatic shut-off activated.	Ensure power cord is firmly plugged into a working outlet. Check that the controller is securely connected to the blanket. Press the Power button to turn on. If the timer has expired, restart the blanket.
Blanket heating unevenly.	Blanket is folded, bunched, or creased.	Lay the blanket completely flat and smooth out any folds or creases.
Controller display is off or flickering.	Loose connection. Power issue.	Check all connections (wall outlet, controller to blanket). Try plugging into a different outlet.
Blanket feels too hot or not hot enough.	Heat setting is too high/low.	Adjust the heat level using the "+" or "-" buttons on the controller.

If the problem persists after attempting these solutions, please contact ALLJOY customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	ALLJOY
Model	HKXM-AJEHB22-L-2018-DE-05
Dimensions (L x W x H)	200 x 180 x 1 cm
Weight	2.27 kg
Material	Polyester (Imitation Lambswool & Flannel)
Heat Levels	9 (approx. 25°C - 45°C)
Automatic Shut-off Timers	9 settings (20, 40, 60, 80, 100, 120, 140, 160, 180 minutes)
Power Cable Length	8.5 feet (approx. 2.6 meters)
Washable	Machine washable (30°C, gentle cycle)

8. WARRANTY AND SUPPORT

ALLJOY products are manufactured with high-quality materials and undergo strict quality control. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official ALLJOY website.

If you encounter any issues or have questions not covered in this manual, please contact ALLJOY customer support for assistance. Please have your model number (HKXM-AJEHB22-L-2018-DE-05) and purchase information ready when contacting support.

You can typically find contact information on the product packaging, the ALLJOY brand store on Amazon, or their official website.

