oneisall PFD-001

Oneisall PF05 Automatic Cat Feeder User Manual

Programmable Cat Food Dispenser for Dry Food

Introduction

Thank you for choosing the Oneisall PF05 Automatic Cat Feeder. This device is designed to provide consistent, scheduled meals for your cat, ensuring healthy eating habits and convenience for pet owners. Please read this manual thoroughly before operation to ensure proper use and maintenance.



Image: The Oneisall PF05 Automatic Cat Feeder, showcasing its sleek black design, transparent food hopper filled with kibble, and the feeding bowl at the bottom. The digital display shows "AM 11:30".

Product Features

- **Healthy Portions:** Dispenses up to 6 meals per day, with 12 portions per meal, each portion approximately 0.17oz (6 grams).
- **Stable Base Design:** Features a low center of gravity to resist tipping, even from playful pets.
- **One-Knob Control:** Simplifies programming of feeding schedules and portion sizes.
- **Dual Power:** Operates via AC adapter with backup battery support for reliable feeding during power outages.

- **Versatile Kibble Compatibility:** Accommodates dry food up to 0.7 inches (1.8 cm) in diameter.
- **FreshLock Seal:** Includes a drying pack and an airtight lid to maintain food freshness and crispness.
- **Anti-Theft Design:** Equipped with a top cover lock and side locks to prevent pets from accessing food outside of scheduled times.

Setup Guide

1. **Unpack and Inspect:** Carefully remove all components from the packaging. Ensure all parts are present and undamaged.
2. **Assemble Components:** Attach the food bowl to the main unit. Ensure it is securely in place.
3. **Power Connection:**
   - Connect the AC adapter to the feeder and plug it into a wall outlet.
   - For backup power, install 1 Lithium Metal battery (included) into the battery compartment at the bottom of the unit. This ensures continuous operation during power interruptions.
4. **Fill Food Hopper:** Open the top lid and pour dry pet food into the transparent hopper. The feeder has a capacity of 3 liters, which can store approximately 12 cups of food.



Image: Dry pet food being poured into the transparent hopper of the Oneisall PF05 feeder, illustrating its 3-liter capacity, capable of storing up to 12 cups of food.

5. **Secure the Lid:** Close the top lid and ensure it is securely locked using the top cover lock and side locks to prevent pets from opening it.



Image: A detailed view of the Oneisall PF05 feeder highlighting the top cover lock and the two side locks, designed to prevent pets from accessing the food.

Operating Instructions

The Oneisall PF05 feeder features a user-friendly one-knob control system for programming. Refer to the icons around the knob for different functions.



Image: The Oneisall PF05 feeder's central control knob with surrounding icons for 'Feed', 'Time', 'Plan', and 'Reset', indicating its ease of use.

Setting Time and Meals:

1. **Set Current Time:** Rotate the knob to select the 'Time' icon. Press the knob to enter time setting mode. Rotate to adjust hours and minutes, press to confirm each setting.
2. **Program Feeding Plan:** Rotate the knob to select the 'Plan' icon. Press the knob to enter programming mode.
   - You can set up to 6 meals per day. For each meal, set the desired feeding time.
   - Adjust the portion size for each meal. The feeder allows for 1 to 12 portions per meal, with each portion being approximately 0.17oz (6 grams). This allows for precise control over your pet's intake.



Image: The Oneisall PF05 feeder dispensing a precise portion of food into a bowl, with a cat eating from it, emphasizing portion control for healthy eating.



Image: A graphic illustrating the Oneisall feeder's smaller serving size of 6 grams per portion compared to others at 8 grams, beneficial for managing greedy cats' intake.

3. **Manual Feed:** To dispense food immediately, rotate the knob to the 'Feed' icon and press the knob. This will dispense one portion.
4. **Reset Settings:** To clear all programmed settings, rotate the knob to the 'Reset' icon and press and hold the knob for a few seconds until the settings are cleared.

Maintenance

Regular cleaning of your Oneisall PF05 feeder is essential for hygiene and proper functioning. The feeder is designed with detachable components for easy cleaning.

1. **Disassemble:** Unplug the feeder and remove any remaining food from the hopper. Detach the food hopper and the feeding bowl from the main base unit.
2. **Cleaning Components:** The food hopper and feeding bowl can be washed with mild soap and water. Rinse thoroughly to remove all soap residue.**Important: Do not wash the main base unit, which contains electronic components.**



Image: Detachable components of the Oneisall PF05 feeder, including the food hopper and bowl, being washed under running water in a sink, with a note to not wash the base.

3. **Dry Thoroughly:** Ensure all washed components are completely dry before reassembling to prevent moisture damage to the food or feeder.
4. **Wipe Base Unit:** Use a clean, damp cloth to wipe the exterior of the main base unit. Do not submerge or rinse the base unit.
5. **Reassemble:** Once dry, reassemble the components and refill the food hopper.

Troubleshooting

If you encounter issues with your Oneisall PF05 Automatic Cat Feeder, please refer to the following common problems and solutions:

- **Feeder not dispensing food:**
  - Check if the feeder is powered on and connected to an AC outlet, or if batteries are installed and charged.
  - Ensure the food hopper is not empty.

- Verify that the feeding schedule is correctly programmed.
- Check for food blockages in the dispenser mechanism. Clear any obstructions.

- **Food getting stuck:**
  - Ensure the kibble size is within the recommended range (up to 0.7 inches in diameter).
  - Clean the dispenser mechanism regularly to prevent buildup.
- **Display not working:**
  - Check power supply.
  - Try resetting the device by unplugging it and removing batteries for a few minutes, then reconnecting.
- **Pet accessing food outside of schedule:**
  - Ensure the top cover lock and side locks are securely fastened.

Specifications

Feature	Detail
Brand	oneisall
Model Number	PFD-001
Product Dimensions	19.51 x 17.5 x 29.01 cm
Item Weight	1.39 kg
Food Capacity	3 Liters (approx. 12 cups)
Max Kibble Size	0.7 inches (1.8 cm)
Meals Per Day	Up to 6
Portions Per Meal	1 to 12 (approx. 0.17oz/6g per portion)
Power Source	AC Adapter, 1 Lithium Metal Battery (backup)
Target Species	Cat
Color	Black

Warranty and Support

For warranty information or technical support, please contact Oneisall customer service. Details can typically be found on the product packaging or the official Oneisall website.
Please retain your purchase receipt as proof of purchase for warranty claims.

© 2025 Oneisall. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question