Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

tenlamp X5

tenlamp Audio Mixer X5 User Manual

Model: X5 | Brand: tenlamp

1. Product Overview

The tenlamp Audio Mixer X5 is a versatile sound board designed for various audio applications, including PC/phone live streaming, singing, and gaming. It features multiple microphone inputs, individual channel controls, and built-in sound effects to enhance your audio experience.



Figure 1: Front and rear view of the tenlamp Audio Mixer X5, highlighting controls and ports.

2. Setup Instructions

2.1 Package Contents

- 1x tenlamp Audio Mixer X5
- 1x USB-C to USB-C cable
- 1x 3.5mm TRRS audio cable
- 1x USB A-C cable
- 1x User Manual

2.2 Connecting the Mixer

1. **Power Connection:** Connect the mixer to your computer or phone using the provided USB-C to USB-C cable or USB A-C cable. The mixer will power on automatically.
2. **Microphone Connection:**
    - For XLR microphones, use an XLR cable to connect to the XLR input port. The mixer provides built-in 48V phantom power for compatible microphones.
    - For 6.35mm dynamic microphones, 3.5mm microphones, or headset microphones, use the respective input jacks.
3. **Headphone/Speaker Connection:** Connect your headphones or speakers to the appropriate output jacks for monitoring audio.
4. **Mobile Device/PC Connection:** Use the OTG/PC port for digital signal transfer to your smartphone, tablet, or computer. Ensure your phone supports OTG if connecting directly.

3. Operating Instructions

3.1 Individual Channel Control

The X5 audio mixer features five independent channels with smooth volume knobs for precise audio control:

- **MICROPHONE:** Adjusts the volume of connected microphones.
- **MUSIC:** Controls the volume of background music.
- **INST:** Manages the volume of connected instruments.
- **MONITOR OUT:** Adjusts the volume for monitoring headphones/speakers.
- **MAIN OUT:** Controls the overall output volume.

3.2 Live Streaming Features

Enhance your live streams with built-in functions:

- **Autotune:** 12-step autotune for vocal pitch correction.
- **Voice Changer:** 5 distinct voice changer effects.
- **Reverb Modes:** 4 different reverb modes.
- **Sound Effects:** 14 warm-up sound effects to engage your audience.

3.3 Noise Reduction

Activate the Noise Reduction function to ensure clear audio, even in outdoor or noisy environments. This feature is crucial for maintaining vocal clarity during live broadcasts.

3.4 Customized Buttons

The mixer includes four customizable buttons for recording and playing back short audio clips. Each button can record up to 15 seconds of audio from computer playback, microphone, or line-in sources.

- **Recording:** Press and hold a custom button until it reflects white light to start recording. Keep holding to continue recording. Release to stop. Recording automatically ends after 15 seconds.
- **Playback:** Short press a custom button. When the white light flashes, it indicates the customized audio is playing. If the white light does not flash, it means there is no recorded audio.

3.5 RGB Lighting

The X5 features dynamic RGB lighting. Long press the RGB button for 2 seconds to turn off the RGB light. Short press to select different RGB modes or colors. No light means the function is off.

4. Maintenance

To ensure the longevity and optimal performance of your tenlamp Audio Mixer X5, please follow these guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the mixer. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the mixer in a cool, dry place away from direct sunlight and extreme temperatures.
- **Disassembly:** **CAUTION: Non-professionals should not disassemble the device.** Unauthorized disassembly may void your warranty and cause damage.

5. Troubleshooting

If you encounter issues with your tenlamp Audio Mixer X5, please refer to the following common solutions:

- **No Audio Output:**
  - Ensure all cables are securely connected.
  - Check volume levels for all relevant channels (MICROPHONE, MUSIC, INST, MONITOR OUT, MAIN OUT).
  - Verify that your headphones or speakers are functioning correctly.
- **Microphone Not Working:**
  - For XLR condenser microphones, ensure 48V phantom power is activated if required. Turn off 48V phantom power if not needed to prevent damage to dynamic microphones.
  - Check microphone mute status on the mixer and in your connected device's settings.
  - Confirm the microphone is properly plugged into the correct input jack.
- **Connectivity Issues:**
  - For mobile devices, ensure your phone supports OTG functionality.
  - Try using a different USB cable or port on your computer/device.

6. Specifications

Feature	Value
Brand	tenlamp
Model	X5
Item Weight	1.72 pounds (0.78 Kilograms)
Package Dimensions	10.67 x 7.13 x 3.03 inches
Power Source	Battery Powered
Voltage	56 Volts
Number of Channels	2
Connectivity Technology	Auxiliary, Bluetooth
Battery Capacity	3000mAh (4-6 hours of live streaming)

7. Warranty and Support

The tenlamp Audio Mixer X5 comes with a **12-month warranty**. For any support inquiries or further assistance, please refer to the contact information provided in your product packaging or visit the official tenlamp store on Amazon.

For a better user experience, always read the user manual before setting up and operating the device.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6T56Z5W

More documents and user manuals: **https://manuals.plus/**