

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Crestlive Products](#) /
- › [Crestlive Products Outdoor Dining Chairs User Manual](#)

Crestlive Products CL-DC219LGY-4

Crestlive Products Outdoor Dining Chairs User Manual

Model: CL-DC219LGY-4 | Brand: Crestlive Products

INTRODUCTION

This manual provides essential information for the safe and effective use of your Crestlive Products Outdoor Dining Chairs. These chairs are designed for outdoor dining and relaxation, featuring an adjustable high back, durable aluminum frame, and comfortable Textilene fabric. Please read this manual thoroughly before assembly and use, and retain it for future reference.



Image: Set of four Crestlive Products outdoor dining chairs in a light gray color, featuring black aluminum frames, positioned on a patio next to a swimming pool. The chairs have high backs and armrests, designed for outdoor use.

SAFETY INFORMATION

To ensure your safety and prevent damage to the product, please adhere to the following guidelines:

- Always follow the assembly instructions carefully to avoid injuries.
- Do not exceed the maximum weight capacity of **350 lbs (158.7 kg)** per chair.
- Be cautious when operating the gas spring mechanism to prevent pinching hazards.
- Ensure all bolts and fasteners are securely tightened before each use. Periodically check and re-tighten as necessary.
- Do not stand on the chairs.
- Keep children and pets away from the assembly area.
- Use the chairs only on a flat, stable surface.

PRODUCT OVERVIEW

Key Features

- **Functional Upgrade:** Ergonomic design with armrests and a gas spring mechanism for adjustable backrest angles (100° to 130°).
- **High-quality Materials:** UV-resistant, waterproof, oil-resistant, and quick-drying quilted Textilene fabric for backrests and cushions.
- **Durable Frame:** All-aluminum frame coated with a black frosted powder finish for enhanced rust resistance and durability.
- **Exquisite Appearance:** Classic design with black frosted spray coating and light gray Textilene fabric, suitable for various outdoor settings.
- **Versatile Usage:** Ideal for personal outdoor spaces such as patios, gardens, balconies, or around pools, as well as commercial settings like hotels and restaurants.

TEXTILENE FABRIC



The dining chair is long-lasting, water and oil-proof, quick-dry, and easy to maintain.



Image: Detail of the chair's Textilene fabric, highlighting its long-lasting, water and oil-proof, quick-dry, and easy-to-maintain characteristics.

ALUMINUM FRAME STAINLESS STEEL SCREWS



Ours: Rustproof & Durable



Others: Rusting & Broken

Image: Visual comparison illustrating the rustproof and durable aluminum frame of the Crestlive Products chair versus a rusted and broken alternative, emphasizing the quality of the aluminum construction.



Image: Close-up view of the chair's tall armrests, designed to provide support and enhance comfort for users when getting up or sitting down.

Components Included (per chair)

- Seat

- Backrest
- Handrails (Armrests)
- Rust-proof Gas Spring
- Assembly Hardware (screws, washers, etc. - typically included)

Specifications

Specification	Detail
Brand	Crestlive Products
Model Name	CL-DC219LGY-4
Color	Light Gray
Product Dimensions (D x W x H)	22.83"D x 22.44"W x 44.09"H
Seat Height	16.73 Inches
Seat Depth	21.26 Inches
Seat Length	22.44 Inches
Chair Backrest Width	19.29 Inches
Item Weight (for the set of 4)	24.9 pounds (approx. 6.2 lbs per chair)
Maximum Weight Recommendation	350 Pounds (158.7 kg) per chair
Frame Material	Aluminum (Powder Coated)
Fabric Type	Textilene
Adjustable Backrest Range	100° to 130°
Indoor/Outdoor Usage	Outdoor

PRODUCT SPECIFICATIONS



 Weight Capacity : 350lbs




Image: Detailed product specifications diagram, illustrating the dimensions of the chair including overall height (39.96" lowest to 44.09" highest), seat height (16.73"), seat depth (21.26"), seat width (19.29"), and armrest height (25.39").

ASSEMBLY INSTRUCTIONS

Your Crestlive Products Outdoor Dining Chairs require assembly. Please ensure you have all components and tools ready before beginning. It is recommended to assemble the chairs on a soft, clean surface to prevent scratches.

- Unpack Components:** Carefully remove all parts from the packaging. Verify that all listed components (seat, backrest, handrails, gas spring, and hardware) are present. Refer to the included assembly diagram for part identification.
- Attach Backrest to Seat:** Align the backrest with the seat frame. Secure them using the provided screws and tools. Do not fully tighten screws until all parts are loosely assembled.
- Install Armrests:** Attach the armrests to the side of the seat and backrest frame. Ensure they are correctly oriented.
- Integrate Gas Spring:** Carefully install the gas spring mechanism according to the diagram, connecting it between

the seat and backrest frame. This mechanism allows for angle adjustment.

5. **Final Tightening:** Once all components are in place and aligned, systematically tighten all screws and bolts. Do not overtighten.
6. **Stability Check:** Gently rock the chair to ensure it is stable and all connections are secure.

Note: For detailed, step-by-step visual instructions, please refer to the separate assembly manual included in your product packaging.

OPERATING INSTRUCTIONS

The Crestlive Products Outdoor Dining Chairs feature a gas spring mechanism for easy backrest adjustment, allowing you to find your preferred reclining angle.

Adjusting the Backrest Angle

1. **Locate the Adjustment Lever:** The adjustment lever is typically located on the side of the chair, near the seat or armrest.
2. **Recline:** While seated, slightly lean forward to relieve pressure on the backrest. Pull the adjustment lever. Lean back slowly to the desired angle (between 100° and 130°). Release the lever to lock the backrest in position.
3. **Return to Upright:** While seated, pull the adjustment lever. Lean forward slightly, and the gas spring will assist the backrest in returning to a more upright position. Release the lever to lock.

Caution: Ensure no body parts or objects are in the path of the moving backrest or gas spring mechanism during adjustment to prevent pinching.

PNEUMATIC ANGLE ADJUSTMENT



Find the most comfortable and suitable angle for you



Image: Diagram demonstrating the pneumatic angle adjustment feature, allowing the user to recline the backrest from an upright 100-degree position to a more relaxed 130-degree position.



Image: Detailed view of the premium pneumatic control system, which is the gas spring mechanism responsible for smooth and easy backrest angle adjustments.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your outdoor dining chairs.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow the chairs to air dry completely after cleaning or rain to prevent mildew and water spots. The Textilene fabric is quick-drying.
- **Frame Care:** The powder-coated aluminum frame is rust-resistant. If scratches occur, touch up with appropriate outdoor paint to prevent corrosion.
- **Seasonal Storage:** During prolonged periods of non-use or harsh weather conditions (e.g., heavy snow, extreme cold), it is recommended to store the chairs indoors or cover them with a protective outdoor furniture cover.
- **Fastener Check:** Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten as needed to maintain stability and safety.

TROUBLESHOOTING

If you encounter any issues with your chairs, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair feels wobbly or unstable.	Loose fasteners. Uneven surface.	Check and tighten all assembly bolts and screws. Move the chair to a flat, level surface.
Backrest does not adjust smoothly.	Gas spring mechanism obstruction or malfunction.	Ensure no debris is obstructing the gas spring. Apply light silicone lubricant to moving parts if necessary (avoiding fabric). If the issue persists, contact customer support.
Fabric appears stained or dirty.	Accumulated dirt or spills.	Clean with a damp cloth and mild soap solution. Rinse thoroughly and allow to air dry.





If the problem persists after attempting these solutions, please contact Crestlive Products customer support for further assistance.

WARRANTY AND SUPPORT

Crestlive Products stands behind the quality of its products. For information regarding warranty coverage, product support, or to purchase replacement parts, please contact Crestlive Products directly through their official website or the retailer where the product was purchased.

For the most up-to-date contact information and support resources, please visit the [Crestlive Products Store on Amazon](#) or their official company website.

Related Documents - CL-DC219LGY-4

 INSTRUCTION MANUAL <i>LOUNGE CHAIR</i>	<p>Crestlive Products Lounge Chair Instruction Manual</p> <p>Instruction manual for the Crestlive Products Lounge Chair, detailing assembly, care, and warranty information.</p>
 INSTRUCTION MANUAL <i>Dining Chair DC038</i>	<p>Crestlive Products DC038 Dining Chair Instruction Manual</p> <p>Instruction manual for the Crestlive Products DC038 Dining Chair, covering assembly, care, maintenance, and warranty information. Includes part lists, hardware details, and step-by-step assembly instructions.</p>
 INSTRUCTION MANUAL <i>PATIO UMBRELLA</i>	<p>Patio Umbrella Instruction Manual</p> <p>Comprehensive instruction manual for assembling and maintaining a patio umbrella. Includes parts list, assembly steps, operation guide, care tips, and warranty information.</p>
 INSTRUCTION MANUAL <i>Patio Umbrella PU051/PU057</i>	<p>Patio Umbrella PU051/PU057 - Assembly, Care, and Warranty Instructions</p> <p>Comprehensive instruction manual for Crestlive Products Patio Umbrella models PU051 and PU057, covering assembly steps, care and maintenance, warranty information, and customer support.</p>
 INSTRUCTION MANUAL <i>Patio Umbrella PU052/PU058/PU059/PU060</i>	<p>Crestlive Products Patio Umbrella Instruction Manual - Models PU052, PU058, PU059, PU060</p> <p>Instruction manual for Crestlive Products Patio Umbrellas, models PU052, PU058, PU059, and PU060. Includes assembly steps, parts list, hardware list, care and maintenance guidelines, warranty information, and customer support contact details.</p>
 INSTRUCTION MANUAL <i>Patio Umbrella PU86L</i>	<p>Crestlive Products PU86L Cantilever Patio Umbrella Instruction Manual</p> <p>Comprehensive instruction manual for assembling, operating, and maintaining the Crestlive Products PU86L Cantilever Patio Umbrella. Includes troubleshooting, warranty information, and care tips.</p>