

[Manuals.plus](#) /

› [Dubstep](#) /

› Dubstep Buzz X3 in-Ear Wireless Earbuds User Manual

Dubstep Buzz X3

Dubstep Buzz X3 Wireless Earbuds User Manual

Model: Buzz X3

1. INTRODUCTION

Thank you for choosing the Dubstep Buzz X3 Wireless Earbuds. These in-ear earbuds are designed to provide a superior audio experience with powerful bass, clear calls, and extended playtime. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance.

Package Contents:

- Dubstep Buzz X3 Wireless Earbuds
- Wireless Charging Case
- Type-C Charging Cable
- Ear Cushions (various sizes)
- User Manual



Image: Dubstep Buzz X3 Wireless Earbuds in their charging case.

2. SAFETY INFORMATION

Please read all safety warnings before using this product to ensure proper and safe operation.

- Do not expose the earbuds or charging case to extreme temperatures, humidity, or liquids.
- Avoid dropping, impacting, or disassembling the device.
- Use only the provided Type-C charging cable and a compatible power adapter.
- Prolonged exposure to loud sounds may cause hearing damage. Adjust volume to a moderate level.
- Keep out of reach of children and pets.

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the Type-C charging cable to the charging port on the case and the other end to a USB power source.
3. The indicator light on the case will show charging status. A full charge takes approximately 1.5 hours for both the earbuds and the charging case.

3.2 Pairing with Your Device

The Dubstep Buzz X3 earbuds feature auto-pair technology for seamless connection.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for "Dubstep Buzz X3" in the list of available Bluetooth devices and select it to connect.
5. Once connected, a voice prompt will confirm successful pairing. The earbuds will automatically reconnect to the last paired device when taken out of the case.



Image: Overview of Dubstep Buzz X3 features, including Bluetooth V5.3 and auto-pair technology.

4. OPERATING THE EARBUDS

4.1 Touch Controls

The Dubstep Buzz X3 earbuds are equipped with intuitive touch controls for easy management of music, calls, and voice assistant.

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud

Function	Action
Answer/End Call	Single tap on either earbud
Reject Call	Long press on either earbud
Activate Voice Assistant (Siri/Google Assistant)	Triple tap on either earbud
Switch Modes (Gaming/Music)	Long press on the left earbud (approx. 2 seconds)



Image: Illustration of touch control functionality on the earbud.

4.2 Dual Mode Functionality

The Buzz X3 offers specialized modes for different audio experiences:

- **Music Mode:** Optimized for rich audio quality and deep X-Bass.
- **Gaming Mode:** Provides ultra-low latency for synchronized audio and video during gaming.

To switch between modes, long press the left earbud for approximately 2 seconds until you hear a voice prompt indicating the mode change.



Image: Visual representation of the dual mode feature for gaming and music.

4.3 Environmental Noise Cancellation (ENC) for Calls

The earbuds feature Environmental Noise Cancellation (ENC) with dual condenser microphones to ensure clear calls by reducing background noise.

- Microphone 1 captures your voice.
- Microphone 2 captures and eliminates ambient noise.

dubstep

non-stop music

42

**hrs*
playtime**



6hrs* music playtime | standby time up to 300 hours*

Image: Diagram illustrating how the dual microphones and ENC technology work to reduce background noise during calls.

5. MAINTENANCE

Proper care will extend the lifespan of your Dubstep Buzz X3 earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are waterproof (as per specifications) and sweat/splash resistant. However, avoid submerging them in water or exposing them to heavy rain. Dry them thoroughly if they get wet.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from direct sunlight.

dubstep

gain total control
with easy touch and voice controls



Image: The charging case with water droplets, highlighting its water and sweat resistance.

6. TROUBLESHOOTING

If you encounter issues with your Dubstep Buzz X3 earbuds, try the following solutions:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Dubstep Buzz X3" from your device's Bluetooth list and re-pair.
No sound from one earbud	Place both earbuds back in the case, close the lid, wait a few seconds, then take them out again. Check if both are charged.
Earbuds not charging	Ensure the charging cable is securely connected. Try a different USB port or power adapter. Clean the charging contacts on the earbuds and case.

Problem	Possible Solution
Poor call quality	Ensure earbuds are properly seated in your ears. Move closer to your connected device. Check for obstructions between earbuds and device.
Touch controls not responding	Ensure your fingers are clean and dry. Try restarting the earbuds by placing them in the case and taking them out.

7. SPECIFICATIONS

Detailed technical specifications for the Dubstep Buzz X3 Wireless Earbuds:

Feature	Detail
Model Name	Buzz X3
Connectivity Technology	Wireless, Bluetooth
Bluetooth Version	5.3
Bluetooth Range	10 Metres
Audio Driver Size	13 Millimetres
Audio Driver Type	Dynamic Driver
Noise Control	Passive Noise Cancellation, Environmental Noise Cancellation (ENC)
Battery Life (Total Playtime)	Up to 42 Hours (with charging case)
Battery Life (Per Charge)	6 Hours
Standby Time	Up to 300 Hours
Charging Time	1.5 Hours (earbuds and case)
Charging Port	Type-C
Control Type	Touch Controls
Water Resistance Level	Waterproof (Sweat and Splash Resistant)
Item Weight	45 Grams
Material	Acrylonitrile Butadiene Styrene (ABS)
Compatible Devices	Cellphones, Tablets, Smart Devices, Laptops

8. WARRANTY AND SUPPORT

The Dubstep Buzz X3 Wireless Earbuds are manufactured by Nuworld Retail Private Limited. For warranty information, technical support, or service inquiries, please contact the manufacturer or your point of purchase. Keep your purchase receipt as proof of purchase for any warranty claims. Additional extended warranty plans may be available from your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question