

## Geeni GN-CW286-199

# Geeni Mini 1080P Indoor/Outdoor Security Camera User Manual

Model: GN-CW286-199

## 1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Geeni Mini 1080P Indoor/Outdoor Security Camera. Please read this manual thoroughly before using the product to ensure proper functionality and safety.



Image: Two Geeni Mini 1080P Security Cameras, one showing a live feed on a smartphone.

### What's in the Box:

- 2x Geeni Mini Smart Cameras
- 2x USB-C Power Adapters
- 2x 10ft USB-C Power Cables
- 2x Magnetic Mounting Kits
- User Manual & Quick Start Guide

## 2. KEY FEATURES

The Geeni Mini Security Camera offers a range of features designed for comprehensive home monitoring:

- **Smart Motion & Sound Alerts:** Receive instant notifications on your phone when motion or sound is detected. Customizable detection zones and sensitivity settings are available.

- **Crystal Clear 1080p HD with Night Vision:** Capture sharp footage with a 105° wide-angle lens. Infrared night vision extends up to 12 meters (20 feet) in total darkness.
- **Magnetic Mount + 10 ft Power Cord:** Easy installation on metal surfaces with a strong magnetic base. The 10 ft power cord provides flexible placement options.
- **2-Way Audio:** Communicate in real-time through the camera using your smartphone.
- **Works with Alexa & Google Assistant:** View live feeds on compatible smart displays using voice commands.
- **Weather Resistant:** Designed for both indoor and outdoor use.
- **Cloud & MicroSD Card Storage:** Flexible options for video recording and storage.



Image: Visual representation of the camera's key features.

### 3. SETUP INSTRUCTIONS

Follow these steps to set up your Geeni Mini Security Camera:

1. **Download the Geeni App:** Search for 'Geeni' in the Apple App Store or Google Play Store and download the application.
2. **Create an Account:** Open the Geeni app and follow the on-screen instructions to create a new account or log in to an existing one.
3. **Power On the Camera:** Connect the USB-C power cable to the camera and plug the power adapter into an electrical outlet. The camera will power on and indicate readiness for pairing (e.g., a flashing light).
4. **Add Device in App:** In the Geeni app, tap the '+' icon to add a new device. Select 'Video Camera' or the appropriate camera type.
5. **Connect to Wi-Fi:** Follow the app's instructions to connect the camera to your 2.4GHz Wi-Fi network. You may need to scan a QR code displayed on your phone with the camera lens.
6. **Mount the Camera:** Use the magnetic mounting kit to place the camera. The magnetic base allows for easy attachment to metal surfaces. For non-metal surfaces, use the included metal plate with adhesive.



Image: Geeni Mini Camera demonstrating magnetic mounting on a refrigerator.



## Mounts in Minutes

With the included mounting kit and flexible design, setup is quick and tool-light—no drilling required for most installs.

Image: Examples of Geeni Mini Camera installation on various surfaces.

## 4. OPERATING INSTRUCTIONS

### 4.1. Motion & Sound Detection

The camera can detect motion and sound, sending instant alerts to your smartphone. To customize these settings:

- Open the Geeni app and select your camera.
- Navigate to the settings menu (usually represented by a gear icon).
- Find 'Motion Detection Settings' or 'Alert Settings'.
- You can adjust sensitivity levels and define specific activity zones to reduce false alarms.





# Smart Motion Alerts, Right When They Happen

Get instant notifications when motion is detected, so you never miss a moment.



## Motion detection

now

Geeni 286 indoor and outdoor camera has detected movement

Image: Smartphone showing a motion detection alert from the Geeni camera.




Image: App interface for setting custom motion detection zones.

## 4.2. Night Vision & Spotlight

The camera automatically switches to infrared night vision in low-light conditions. It also features a built-in

spotlight for enhanced visibility.

- Night vision provides clear black and white footage up to 12 meters (20 feet).
- The spotlight can be activated manually through the Geeni app or automated with custom scene settings.



Image: Geeni Mini Camera using its spotlight feature at night.

## See It All, Even in the Dark

Whether it's dusk or dead of night, crisp infrared night vision ensures you catch every detail up to 12 meters.





Image: Example of night vision clarity in an outdoor setting.

### 4.3. 2-Way Audio

Use the built-in microphone and speaker to communicate with individuals near the camera.

- From the live view in the Geeni app, tap the microphone icon to speak.
- Tap the speaker icon to hear audio from the camera's location.



Image: Illustration of two-way audio in use, showing communication between a person and the camera.

### 4.4. Voice Control (Alexa & Google Assistant)

Integrate your Geeni camera with Amazon Alexa or Google Assistant for hands-free monitoring.

- Enable the Geeni skill/action in your Alexa or Google Home app.
- Link your Geeni account.
- Use commands like, "Alexa, show front door camera" or "Hey Google, what's happening at the front door?" to view live feeds on compatible smart displays.



# Voice Control

"Alexa, show me the baby room camera."



Image: Smart display showing camera feed, highlighting voice control compatibility.

## 4.5. Storage Options

Your Geeni camera supports both cloud storage and local MicroSD card storage.

- **Cloud Storage:** Access recorded footage securely through the Geeni app (subscription may be required after initial trial).
- **MicroSD Card:** Insert a MicroSD card (up to 256GB, not included) into the camera's slot for local storage. Footage can be reviewed via the app.

## 5. MAINTENANCE

To ensure optimal performance and longevity of your Geeni Mini Security Camera:

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Placement:** While the camera is weather-resistant, avoid direct exposure to extreme weather conditions if

possible to prolong its lifespan. Ensure the power connection is secure and protected.

- **Firmware Updates:** Regularly check the Geeni app for available firmware updates to ensure your camera has the latest features and security enhancements.



Image: Geeni Mini Camera installed outdoors, demonstrating its weather-resistant design.

## 6. TROUBLESHOOTING

If you encounter issues with your Geeni Mini Security Camera, refer to the following common solutions:

- **Camera Not Connecting to Wi-Fi:**
  - Ensure your Wi-Fi network is 2.4GHz. The camera does not support 5GHz networks.
  - Check that the Wi-Fi password entered is correct.
  - Move the camera closer to your Wi-Fi router to improve signal strength.
  - Restart your router and the camera.

- **Frequent False Motion Alerts:**

- Adjust the motion detection sensitivity in the Geeni app.
- Define specific activity zones to exclude areas with frequent, non-threatening movement (e.g., trees swaying, busy streets).

- **No Night Vision:**

- Ensure the camera is in a dark environment for night vision to activate automatically.
- Check app settings to confirm night vision is enabled.

- **2-Way Audio Not Working:**

- Ensure your phone's microphone and speaker permissions are granted to the Geeni app.
- Check the volume settings on both your phone and within the app.

- **Camera Offline:**

- Verify the camera is powered on and the power adapter is securely connected.
- Check your Wi-Fi network status.
- Restart the camera by unplugging and replugging it.

For further assistance, refer to the Geeni app's help section or visit the official Geeni support website.

## 7. SPECIFICATIONS

# Dimensions



Image: Detailed dimensions and component labels of the Geeni Mini Camera.

Feature	Detail
Model Number	GN-CW286-199
Video Capture Resolution	1080p
Viewing Angle	105 Degrees
Night Vision Range	20 Feet (approx. 6 meters)
Connectivity Protocol	Wi-Fi (2.4GHz), Bluetooth
Power Source	Corded Electric
Compatible Devices	Desktop, Laptop, Smartphone
Controller Type	Amazon Alexa, Google Assistant, Geeni App
Mounting Type	Wall Mount, Freestanding, Magnetic Base
Indoor/Outdoor Usage	Indoor, Outdoor (Water Resistant)



Flash Memory Supported Size Maximum	256 GB (Micro SD)
Item Dimensions (L x W x H)	5.91 x 2.76 x 5.91 inches
Item Weight	7.4 ounces

## 8. WARRANTY INFORMATION

The Geeni Mini 1080P Indoor/Outdoor Security Camera comes with a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external causes.

For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Geeni website.




## 9. SUPPORT




If you require further assistance or have questions not covered in this manual, please utilize the following resources:

- **Geeni App:** The Geeni app often includes a comprehensive help section, FAQs, and troubleshooting guides.
- **Online Support:** Visit the official Geeni support website for updated information, FAQs, and contact options.

© 2025 Geeni. All rights reserved.

### Related Documents - GN-CW286-199

	<a href="#">Geeni Smart Wi-Fi Outdoor Camera Start Guide</a> A comprehensive start guide for the Geeni Smart Wi-Fi Outdoor Camera, covering setup, connection methods (Easy Mode and QR Code Mode), mounting instructions, settings customization, live view, playback, frequently asked questions, and troubleshooting.
	<a href="#">Geeni Smart Wi-Fi Camera Start Guide: Setup, Features, and Troubleshooting</a> Get started with your Geeni Smart Wi-Fi Camera. This guide provides setup instructions, connection steps, feature explanations, and troubleshooting tips for your Geeni smart home device.
	<a href="#">Geeni Smart Wi-Fi Camera Quick Start Guide &amp; Setup Instructions</a> Comprehensive guide for setting up and using your Geeni Smart Wi-Fi Camera. Learn how to connect, configure settings, troubleshoot issues, and integrate with Amazon Alexa and Google Assistant.

<div data-bbox="188 107 240 152"><p>geeni START GUIDE</p></div> <div data-bbox="177 185 252 293"></div> <div data-bbox="167 333 261 378"><p>SMART WI-FI OUTLET EXTENDER</p></div>	<p><a href="#">Geeni Smart Wi-Fi Outlet Extender: Setup and Voice Control Guide</a></p> <p>Get started with your Geeni Smart Wi-Fi Outlet Extender. This guide covers app setup, Wi-Fi connection (Easy and AP modes), troubleshooting, technical specifications, and voice control integration with Google Assistant, Amazon Alexa, and Cortana.</p>
<div data-bbox="188 474 240 519"><p>geeni START GUIDE</p></div> <div data-bbox="167 544 258 678"></div> <div data-bbox="167 701 261 730"><p>SMART WI-FI CAMERA</p></div>	<p><a href="#">Geeni Smart Wi-Fi Camera Start Guide</a></p> <p>A comprehensive start guide for the Geeni Smart Wi-Fi Camera, covering setup, connection modes (Easy and QR), mounting, settings, troubleshooting, and voice control integration with Google Assistant and Amazon Alexa.</p>
<div data-bbox="118 822 309 1014"></div>	<p><a href="#">Geeni Smart Wi-Fi Floodlight Camera Start Guide</a></p> <p>A comprehensive start guide for the Geeni Smart Wi-Fi Floodlight Camera, covering installation, app connection, setup, and troubleshooting.</p>