

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Bomann](#) /

› Bomann KS 7254 Refrigerator with Freezer Compartment - User Manual

Bomann KS 7254

Bomann KS 7254 Refrigerator with Freezer Compartment - User Manual

Model: KS 7254 | Brand: Bomann

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Bomann KS 7254 refrigerator with a freezer compartment. Please read these instructions carefully before using the appliance and keep them for future reference.

The Bomann KS 7254 is a compact and efficient refrigerator designed for optimal food storage, featuring a 91-liter capacity, a small freezer compartment, and a reversible door hinge for flexible placement.

2. SAFETY INFORMATION

Always adhere to the following safety precautions to prevent personal injury or damage to the appliance.

- Ensure the appliance is disconnected from the power supply before cleaning or maintenance.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- This appliance is intended for household use only.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Children should be supervised to ensure they do not play with the appliance.

3. UNPACKING AND SETUP

3.1 Unpacking

Carefully remove all packaging materials. Inspect the appliance for any damage during transit. Report any damage to your retailer immediately.

3.2 Placement

Place the refrigerator on a firm, level surface. Ensure adequate ventilation around the appliance. Avoid direct sunlight and

heat sources. The appliance dimensions are approximately 47 cm (depth) x 44.5 cm (width) x 83.5 cm (height).




Image: Front view of the Bomann KS 7254 refrigerator with its dimensions (47 cm depth, 44.5 cm width, 83.5 cm height) indicated. Also shows icons for 40 dB noise level, Energy Class E, stepless temperature control, and LED interior lighting.

3.3 Door Reversal

The door hinge is reversible, allowing you to change the opening direction to suit your space. Refer to the detailed instructions in the separate door reversal guide (if provided) or consult a qualified technician for this procedure.

Genug Platz für deine Leckereien

Nutzzinhalt 91 Liter



Image: Interior view of the Bomann KS 7254 refrigerator showing its shelves and a transparent vegetable drawer. An inset icon highlights the reversible door hinge feature.

3.4 Initial Power-On

After placing the appliance, wait at least 2-4 hours before plugging it in to allow the refrigerant to settle. Connect the appliance to a properly grounded power outlet. The power cord length is approximately 120 cm.

Stillvolles Design mit cleverem System und genug Stauraum



Image: Front view of the Bomann KS 7254 refrigerator next to a circular graphic highlighting its power plug and a cable length of approximately 120 cm.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

The refrigerator features a stepless temperature control dial located inside the compartment. Turn the dial to adjust the cooling intensity. The recommended operating temperature range is 0°C to +8°C.

Stufenlose Temperaturregelung

Temperaturbereich: 0°C ~ +8°C



Image: Close-up view of the interior of the Bomann KS 7254 refrigerator, showing the temperature control dial and the LED interior lighting. Various food containers are visible on the shelves.

4.2 Interior Organization

The refrigerator is equipped with 2 glass shelves, 3 door shelves (including an egg tray), and a transparent vegetable drawer for flexible storage. The small freezer compartment includes an ice cube tray.

2 Glasablagen & transparente Gemüseschale



Image: Interior view of the Bomann KS 7254 refrigerator, highlighting the two glass shelves and the small freezer compartment. A blue line points to the freezer, indicating its function for short-term storage.

3 Türablagen inkl. Eierablage



Image: Interior view of the Bomann KS 7254 refrigerator, focusing on the three door shelves, which include an egg tray. A blue arrow indicates that the bottom shelf can accommodate large bottles.

4.3 LED Interior Lighting

The refrigerator features energy-efficient LED lighting inside the compartment for clear visibility of your stored items.

5. MAINTENANCE

5.1 Cleaning

Regularly clean the interior and exterior of the refrigerator. Unplug the appliance before cleaning. Use a soft cloth and a mild detergent. Do not use abrasive cleaners or sharp objects.

5.2 Defrosting

This appliance features manual defrosting for the freezer compartment. When ice accumulation in the freezer compartment reaches a thickness of 3-5 mm, defrost the appliance. To defrost:

1. Unplug the refrigerator.
2. Remove all food items and place them in a cool place.
3. Leave the door open to allow ice to melt naturally. Place a towel or container to collect water.
4. Once defrosted, clean and dry the interior thoroughly before plugging the appliance back in and returning food items.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Refrigerator does not operate.	No power supply.	Check if the plug is properly inserted and the power outlet is working.
Appliance is not cooling sufficiently.	Temperature setting too high; door opened too frequently; warm food placed inside; poor ventilation.	Adjust temperature control to a lower setting; avoid frequent door openings; allow hot food to cool before placing inside; ensure adequate space around the appliance.
Excessive ice formation in freezer.	Door not sealed properly; high humidity; frequent door opening.	Check door gasket for proper seal; avoid opening door unnecessarily; defrost as per instructions.
Unusual noises.	Appliance not level; objects vibrating against the unit.	Adjust leveling feet; ensure nothing is touching the back or sides of the refrigerator. Normal operating noise level is 40 dB.

If the problem persists after checking these points, please contact customer service.

7. SPECIFICATIONS

Feature	Detail
Brand	Bomann
Model Number	KS 7254 (772541)
Type	Mini Refrigerator with Freezer Compartment
Total Capacity	91 Liters
Dimensions (D x W x H)	47 x 44.5 x 83.5 cm
Weight	19 kg
Energy Efficiency Class	E
Annual Energy Consumption	85 kWh/year
Noise Level	40 dB
Temperature Range	0°C to +8°C
Defrost System	Manual

Feature	Detail
Door Hinge	Reversible
Power Supply	240 Volt
Certification	CE


For more detailed product information, including the product data sheet and energy label, please visit the EPREL database:

Produktdatenblatt					
DELEGIERTE VERORDNUNG (EU) 2019/2016 DER KOMMISSION zur Energieverbrauchskennzeichnung von Kühlgeräten					
Name oder Handelsmarke des Lieferanten: Bomann					
Anschrift des Lieferanten: Zentrale Bomann, Heinrich-Horten-Straße 17, 47906 Kempen, DE					
Modellkennung: KS 7254					
Art des Kühlgeräts:					
Geräuscharmes Gerät:	Nein	Bauart:	freistehend		
Weinlagerschrank:	Nein	Anderes Kühlgerät:	Ja		
Allgemeine Produktparameter:					
Parameter	Wert		Parameter	Wert	
Gesamtabmessungen (in Millimeter)	Höhe	835	Gesamtrauminhalt (in dm ³ oder l)	91	
	Breite	445			
	Tiefe	470			
EEL	99	Energieeffizienzklasse	E		
Luftschallemissionen (in dB(A) re 1 pW)	40	Luftschallemissionsklasse	C		
Jährlicher Energieverbrauch (in kWh/a)	85	Klimaklasse:	gemäßigte Zone, subtropische Zone		
Mindestumgebungstemperatur (in °C), für die das Kühlgerät geeignet ist	16	Höchstumgebungstemperatur (in °C), für die das Kühlgerät geeignet ist	38		
Winterschaltung	Nein				
Fachparameter:					
Fachtyp	Fachparameter und #werte				
	Rauminhalt des Fachs (in dm ³ oder l)	Empfohlene Temperatureinstellung für eine optimierte Lebensmittellagerung (in °C) Diese Einstellungen dürfen nicht im Widerspruch zu den Lagerbedingungen nach Anhang IV	Gefrierermögen (in kg/24h)	Defrosting type (auto-defrost=A, manual defrost=M)	
Tabelle 3 stehen					
Spisekammerfach	Nein	-	-	-	-
Weinlagerfach	Nein	-	-	-	-
Kellerfach	Nein	-	-	-	-
Lagerfach für frische Lebensmittel	Ja	91,0	4	-	M
Kaltlagerfach	Nein	-	-	-	-
Null-Sterne- oder Eisbereiterfach	Nein	-	-	-	-
Ein-Stern-Fach	Nein	-	-	-	-
Zwei-Sterne-Fach	Nein	-	-	-	-
Drei-Sterne-Fach	Nein	-	-	-	-
Vier-Sterne-Fach	Nein	-	-	-	-
Zwei-Sterne-Abteil	Nein	-	-	-	-
Fach mit variabler Temperatur	-	-	-	-	-


Lichtquellenparameter:	
Art der Lichtquelle	LED
Energieeffizienzklasse	-
Mindestlaufzeit der vom Hersteller angebotenen Garantie: 24 Monate	
Weitere Angaben:	
Webblink zur Website des Lieferanten, auf der die Informationen gemäß Anhang II Nummer 4 der Verordnung (EU) 2019/2019 der Kommission zu finden sind: www.bomann-germany.de	
Das Modell wurde auf dem Unionsmarkt in Verkehr gebracht, und zwar ab dem 15/03/2025.	
	
EPREL-Eintragungsnummer 2188815	https://eprel.ec.europa.eu/qr/2188815
Lieferant: C. Bomann GmbH (Hersteller)	Website:
Kundenbetreuung:	
Name: Zentrale Bomann	Website: www.bomann.de
E-Mail-Adresse: info@bomann.de	Telefonnummer: +49 2152 8998-0
Anschrift: Heinrich-Horten-Straße 17 47906 Kempen Deutschland	

Seite 2 / 2


Image: Official product data sheet for the Bomann KS 7254 refrigerator, detailing technical specifications and energy consumption. Includes a QR code and EPREL link.



ENERG



Bomann
KS 7254



85 kWh/annum



91 L



AB**C**D

2019/2016

Image: Energy label for the Bomann KS 7254 refrigerator, showing its energy efficiency class E, annual energy consumption of 85 kWh, 91L capacity, and 40 dB noise level. Includes a QR code and EPREL link.

[EPREL Database Link](#)

8. WHAT'S IN THE BOX

Your Bomann KS 7254 refrigerator package includes:

- Bomann KS 7254 Refrigerator Unit
- Transparent Vegetable Drawer
- Egg Tray
- Ice Cube Tray (for freezer compartment)
- User Manual (this document)

9. WARRANTY AND SUPPORT

This Bomann appliance comes with a 24-month manufacturer's warranty. For warranty claims, technical support, or spare parts, please contact Bomann customer service or your retailer.

You can find more information and contact details on the official Bomann website: www.bomann.de

