## T4TREAM VSC6DRSC-ABW

# T4TREAM Farmhouse 6-Drawer Dresser User Manual

**Model: VSC6DRSC-ABW**

**Brand: T4TREAM**

## 1. Introduction

This manual provides essential instructions for the assembly, operation, maintenance, and troubleshooting of your T4TREAM Farmhouse 6-Drawer Dresser, Model VSC6DRSC-ABW. Please read this manual thoroughly before assembly and use to ensure safe and proper functionality of your furniture.



*Image 1.1: The T4TREAM Farmhouse 6-Drawer Dresser, showcasing its distressed white finish and vintage design in a bedroom environment.*

The T4TREAM Farmhouse 6-Drawer Dresser is designed to offer ample storage with a rustic aesthetic. Its distressed white finish and vintage design elements, including embossed textures and beveled edges, complement various interior styles. Constructed from FSC-Certified wood, this dresser is built for durability and stability.

## 2. Safety Information

Your safety is paramount. Please adhere to the following guidelines:

- **Anti-Tipping Device:** This dresser is equipped with an anti-tipping device. It is crucial to install this device securely to a wall to prevent accidental tipping, which can cause serious injury or death. Follow the instructions provided with the anti-tipping kit.
- **Weight Distribution:** Distribute weight evenly across drawers. Avoid placing excessively heavy items in the top drawers, as this can affect stability.
- **Top Surface Weight Limit:** The top surface of the dresser can support up to 150 lbs (approximately 68 kg). Do not exceed this weight limit.
- **Children's Safety:** Do not allow children to climb on or play with the dresser drawers. Always

supervise children around furniture.

- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened before use. Periodically check and re-tighten fasteners as needed.




*Image 2.1: Diagram illustrating the dresser's dimensions (W54" x H31.2" x D15.5") and highlighting the importance of the anti-tipping device for stability. The image also shows a drawer's internal dimensions.*

## 3. Setup and Assembly

Assembly is required for this product. Please follow the detailed instructions provided in the separate assembly guide included with your purchase. It is recommended to have a second person assist with the assembly process for ease and safety.

### 3.1 Before You Begin

- **Unpack Carefully:** Remove all components from the packaging. Keep packaging materials until assembly is complete to ensure no small parts are discarded.
- **Verify Parts:** Check the parts list against the contents of your package. If any parts are missing or damaged, contact customer support immediately.
- **Tools Required:** Refer to the assembly guide for a list of necessary tools (e.g., screwdriver,

hammer).

- **Work Area:** Assemble the dresser on a soft, clean surface (e.g., a rug or cardboard) to prevent scratches.

### 3.2 Assembly Steps (General)

1. Attach the side panels to the base.
2. Install the back panel.
3. Assemble the drawer boxes according to the instructions.
4. Install drawer slides into the dresser frame and onto the drawer boxes.
5. Insert the assembled drawers into the dresser frame.
6. Attach drawer pulls/handles.
7. Securely install the anti-tipping device to the dresser and a wall stud.

## 4. Operating Instructions

The T4TREAM 6-Drawer Dresser is designed for organized storage of clothing, linens, and other personal items.

- **Drawer Usage:** Each of the six drawers operates on smooth glides. Pull drawers open gently and push them closed firmly until they are fully seated.
- **Storage Capacity:** Each drawer measures approximately 23.6 inches wide and 6.3 inches deep, providing ample space for various items. Utilize the full depth and width for efficient organization.
- **Top Surface:** The spacious tabletop can be used to display decorative items, lamps, or other personal belongings. Ensure the total weight does not exceed 150 lbs.




*Image 4.1: The dresser with several drawers partially open, illustrating the generous storage capacity suitable for folded clothing and linens.*

## 5. Maintenance

Proper care and maintenance will extend the life and preserve the appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the distressed finish. Dry immediately with a clean, soft cloth.
- **Spills:** Blot spills immediately with a clean, dry cloth to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Humidity:** Maintain a consistent humidity level in the room to prevent wood from expanding or contracting, which can lead to cracking or warping.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten as necessary to maintain structural integrity.




*Image 5.1: A detailed view of the dresser's top surface, highlighting the natural wood grain and distressed white finish, which requires gentle cleaning.*

## 6. Troubleshooting

If you encounter any issues with your dresser, refer to the following common solutions:

- **Wobbly Dresser:**
  - Ensure the dresser is placed on a level surface.
  - Check all assembly screws and bolts. Tighten any loose fasteners.
  - Verify that the anti-tipping device is securely installed.
- **Drawers Not Closing Smoothly:**
  - Check for any obstructions inside the drawer or along the drawer slides.
  - Ensure the drawer slides are properly aligned and free of debris.
  - Verify that the drawer boxes were assembled correctly and are not warped.
  - Do not overload drawers, as excessive weight can hinder smooth operation.
- **Damaged Parts:**
  - If you discover damaged parts during or after assembly, do not attempt to force them. Contact

customer support for replacement parts.

## 7. Specifications

| Feature | Detail |
|---|---|
| **Brand** | T4TREAM |
| **Model Name** | VSC6DRSC-ABW |
| **Product Dimensions (Overall)** | 54" W x 15.5" D x 31.2" H (137.16 cm W x 39.37 cm D x 79.25 cm H) |
| **Drawer Dimensions (Internal)** | Approx. 23.6" W x 12" D x 6.3" H (60 cm W x 30.5 cm D x 16 cm H) |
| **Color** | Distressed White |
| **Room Type** | Bedroom, Living Room |
| **Assembly Required** | Yes |
| **Item Weight** | 136 Pounds (61.69 kg) |
| **Material** | FSC-Certified Wood |
| **Number of Drawers** | 6 |
| **Top Surface Weight Capacity** | 150 lbs (68 kg) |

## 8. Warranty and Support

T4TREAM is committed to providing high-quality products and customer satisfaction. While specific warranty details are provided with your purchase, we assure you that our products are crafted with care and designed for durability.

- **Customer Support:** If you have any questions, require assistance with assembly, or encounter any issues with your dresser, please do not hesitate to contact our dedicated support team. Refer to the contact information provided in your product packaging or on the T4TREAM official website.
- **Replacement Parts:** In case of missing or damaged parts, our support team can assist you in obtaining replacements.

© 2025 T4TREAM. All rights reserved.