

[Manuals.plus](#) /

› [JANSNO](#) /

› JANSNO X70 Adult E-Bike User Manual

JANSNO x70

JANSNO X70 Adult E-Bike User Manual

Model: X70 | Brand: JANSNO

1. INTRODUCTION AND OVERVIEW

The JANSNO X70 Adult E-Bike is designed for versatile use, offering a powerful motor, extended range, and robust construction for various terrains. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your e-bike.



Image: The JANSNO X70 Adult E-Bike, showcasing its robust frame, fat tires, and integrated components.

Key Features:

- **Extra Long Cruising Range:** Equipped with 48V/14/20Ah dual lithium batteries, providing up to 120 miles range per full charge in assist mode. The batteries are removable for convenient recharging.
- **Strong Power:** Features a D1000 high-speed brushless motor, capable of conquering slopes up to 20 degrees.
- **High Precision Engineering Design:** Constructed with a high-carbon steel frame and 20" x 4.0 snow tires, designed for enhanced anti-skidding and wear resistance across various terrains including snow, sand, and gravel roads.
- **Multi-functional Rear Tail Rack:** An expandable rear rack allows for attachment of luggage racks or suitcases,

enhancing utility for outdoor adventures or daily commuting. (Note: Additional accessories sold separately).

- **Safety Features:** Includes front and rear mechanical disc brakes for reliable stopping power and an integrated lighting system for visibility.

2. SETUP AND ASSEMBLY

Your JANSNO X70 E-Bike comes partially assembled. Follow these steps to complete the setup and prepare for your first ride.

1. **Unpacking:** Carefully remove all components from the packaging. Inspect for any shipping damage. Retain packaging for future transport or storage.
2. **Handlebar Installation:** Attach the handlebars to the stem, ensuring all bolts are securely tightened. Adjust the angle for comfortable riding posture.
3. **Pedal Installation:** Identify the left (L) and right (R) pedals. The left pedal threads counter-clockwise, and the right pedal threads clockwise. Tighten securely with a wrench.
4. **Seat Adjustment:** Adjust the seat post height to ensure your feet can comfortably touch the ground when stopped, and your legs have a slight bend at the knee when pedaling. Secure the quick-release lever or bolt.
5. **Initial Battery Charge:** Before first use, fully charge both batteries. Connect the charger to the battery port and then to a power outlet. The indicator light on the charger will change when charging is complete (typically 6-8 hours).

LARGE CAPACITY DUALBATTERY MAX 120 MILES (ASSIST MODE)



48V/34Ah



6-8 Hours



USB Charge
port



Removable



Image: The JANSNO X70's large capacity dual battery system, showing its removable design and USB charge port.

The package includes the rear rack and enhanced tires, which are pre-installed or require minimal attachment as per the main assembly instructions.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the controls and functions of your JANSNO X70 E-Bike for a safe and enjoyable riding experience.

3.1 Powering On/Off

- To power on the bike, press and hold the power button on the LCD display.
- To power off, press and hold the power button again until the display turns off.

3.2 LCD Display Functions

The multi-functional HD LCD display provides real-time information about your ride. It features self-illuminating and adjustable brightness for clear visibility day or night.

- **Speed:** Displays current riding speed.
- **Battery Level:** Shows remaining battery charge.
- **Gear Position:** Indicates the current pedal assist level.
- **Mileage:** Tracks total distance traveled.

Safety built in

Safety is considered from the start and designed in. That includes intuitive handling and an integrated lighting system that ensures you are always visible.

Multi-functional HD LCD display

The self-illuminating, adjustable brightness HD display ensures that you can clearly monitor vehicle information even at night, including speed, battery level, gear position, and mileage.



Image: Close-up of the JANSNO X70's multi-functional HD LCD display, showing speed, battery, and mileage indicators.

3.3 Pedal Assist Modes and Throttle

- **Pedal Assist:** The bike offers multiple performance modes. Use the '+' and '-' buttons on the display to cycle through different levels of pedal assistance. Higher levels provide more motor power as you pedal.
- **Throttle:** The throttle provides power on demand without pedaling. Use it for quick acceleration or to maintain speed without effort. Always be mindful of local regulations regarding throttle use.

3.4 Braking

The JANSNO X70 is equipped with front and rear mechanical disc brakes for effective stopping. Always apply both brakes simultaneously for balanced and controlled stopping. Practice braking in a safe area before riding in traffic.

HIGH ROTATION SPEED BRUSHLESS MOTOR



D1000

30



48



7

speed
transmission




Image: Illustration of the D1000 high-speed brushless motor and the disc brake system on the JANSNO X70, highlighting the mechanical components.

4. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your JANSNO X70 E-Bike.

• Battery Care:

- Charge batteries fully after each ride, especially if storing for extended periods.
- Store batteries in a cool, dry place, away from direct sunlight and extreme temperatures.
- Avoid completely draining the battery to prolong its lifespan.

• Tire Pressure:

- Check tire pressure before each ride. Refer to the tire sidewall for recommended PSI. Proper inflation improves efficiency and prevents punctures.

- **Brake Inspection:**

- Regularly check brake pads for wear and replace if necessary.
- Ensure brake levers engage smoothly and provide firm stopping power. Adjust cable tension if needed.

- **Cleaning:**

- Clean the bike regularly with a damp cloth and mild soap. Avoid high-pressure washing directly on electrical components.

- **Chain Lubrication:**

- Keep the chain clean and lubricated to ensure smooth gear changes and prevent wear.

20-INCH UPGRADED TIRES

Durable, anti-skid and anti-puncture



4MM

Thickened Stab-proof



10CM

Extra Wide Tread



50CM

Tire Diameter



Image: The 20-inch upgraded tires of the JANSNO X70, highlighting their durable, anti-skid, and anti-puncture features with thickened stab-proof and extra wide tread.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your JANSNO X70 E-Bike.

Problem	Possible Cause	Solution
Bike does not power on.	Battery not charged or not properly seated. Loose electrical connection.	Ensure batteries are fully charged and securely inserted. Check all visible electrical connections for tightness.
Motor not assisting.	Pedal assist level set to zero. Brake levers engaged. Motor or controller issue.	Increase pedal assist level on the display. Ensure brake levers are fully released. If problem persists, contact support.
Battery not charging.	Charger not connected properly. Faulty charger or battery.	Verify charger is securely plugged into both battery and wall outlet. Check charger indicator light. Try a different outlet. If still no charge, contact support.
Unusual noises during operation.	Loose components, dry chain, or brake rub.	Inspect all bolts and fasteners for tightness. Lubricate the chain. Check for brake pad alignment and adjust if necessary.

For issues not listed here or if solutions do not resolve the problem, please contact JANSNO customer support.

6. SPECIFICATIONS

Detailed technical specifications for the JANSNO X70 E-Bike.

Specification	Detail
Model Name	X70
Bike Type	Electric Bike
Age Range	Adult
Motor	D1000 High-Speed Brushless Motor (90 Nm)
Battery	48V/34Ah (Dual Battery System)
Max Range	Up to 120 miles (assist mode)
Charging Time	Approx. 6-8 hours
Frame Material	High Carbon Steel
Wheel Size	20" x 4.0 Inches (Snow Tyre)
Brake Type	Mechanical Disc Brakes (Front & Rear)
Suspension Type	Front Suspension
E-bike Weight	95 lbs (from image)
Max Load	330 lbs (from image)
Recommended Height	5'3" - 6'4" (from image)

*Data is measured manually, there is an error of ± 1 inch



REFERENCES



5'3"-6'4"
Recommended Height



95LBS
Ebike Weight



330LBS
Max.Load



Image: Detailed dimensions and user references for the JANSNO X70 E-Bike, including recommended height, e-bike weight, and maximum load.

7. WARRANTY AND SUPPORT

JANSNO is committed to providing excellent customer service and product support.

Warranty Information:

JANSNO provides a **1-year warranty** for the X70 E-Bike, covering manufacturing defects and major components. Please retain your proof of purchase for warranty claims.

Customer Support:

If you have any questions, require technical assistance, or need to make a warranty claim, please contact JANSNO customer service. They offer 24-hour professional online customer service to assist you.

For the most up-to-date contact information, please refer to the official JANSNO website or your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question