

[Manuals.plus](#) /

› [CYBERDOT](#) /

› CYBERDOT C01 Open Ear Bluetooth Headphones User Manual

CYBERDOT C01

CYBERDOT C01 Open Ear Bluetooth Headphones

USER MANUAL

Introduction

Thank you for choosing the CYBERDOT C01 Open Ear Bluetooth Headphones. These headphones are designed to provide a comfortable and secure audio experience with enhanced situational awareness, making them ideal for sports, workouts, and daily use. Featuring air-conduction technology, clear stereo sound, and a waterproof design, the C01 ensures a high-quality listening experience while keeping you connected to your surroundings.

This manual will guide you through the setup, operation, and maintenance of your new headphones to ensure optimal performance and longevity.



Image: The CYBERDOT C01 Open Earbuds, showcasing their ergonomic design for all-day comfort.

			
	Air-Conduction	Bone-Conduction	Traditional TWS
Type	Open Ear	Open Ear	Open Ear
Sound Quality	Clear and Natural	Noise Disruption	Normal
Charging Case	Yes	No	Yes
Situational Awareness	Yes	Yes	No
Wearing Comfort	Pressure Free	Bone Pain	Ear Canal Pain

Image: A comparison chart illustrating the differences in sound quality, charging, situational awareness, and wearing comfort between Air-Conduction, Bone-Conduction, and Traditional TWS headphones.

Setup

1. What's in the Box

- Wireless Charging Case
- Open Earbuds (Left and Right)
- USB-C Charging Cable
- User Manual

2. Charging Your Headphones

Before first use, fully charge your CYBERDOT C01 headphones and charging case.

1. **Via USB-C Cable:** Connect the provided USB-C cable to the charging port on the case and to a power source.
2. **Via Wireless Charging:** Place the charging case on a compatible wireless charging pad (not included).

The LED digital display on the charging case will show the battery level of the case and the individual earbuds during charging.

LED Digital Display



Battery level display of the case



Remaining battery level of the earbuds

Image: Illustration showing the two charging methods for the CYBERDOT C01: USB-C cable charging and wireless charging.

Excellent Sound Quality

Produces a more balanced and accurate audio representation across different frequencies, which can enhance the overall listening experience.



16.3mm Dynamic Drivers

Image: Close-up of the charging case's LED digital display, indicating the battery percentage of the case and the charging status of the earbuds.

3. Pairing with Your Device

The CYBERDOT C01 headphones feature automatic pairing for convenience.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case and take out both earbuds. They will automatically enter pairing mode.
3. On your device, search for Bluetooth devices and select "CYBERDOT C01" to connect.
4. Once paired, the earbuds will automatically connect to your device whenever you take them out of the case.

Natural Clear Stereo Sound

Creating a sense of depth and space in the audio. provide an airy and breathable sound quality



Wide Compatibility



iOS



One-Step Pairing



Faster and More Stable Connections



Image: Visual representation of the one-step pairing process with a smartphone and the wide compatibility of the headphones with various devices (iOS, Android, laptops, desktops).

4. Wearing the Earbuds

The CYBERDOT C01 features a revolving design for an easier and more comfortable fit.

1. Rotate the main structure of the headphone so that it is at an angle to the plane of the ear hook.
2. Maintain this angle and gently place the ear hook over your ear.
3. Rotate the headphone body to adjust and fit comfortably against your ear, ensuring the sound outlet is positioned correctly near your ear canal without entering it.

Two Ways of Charging



Image: Step-by-step guide demonstrating how to rotate and wear the CYBERDOT C01 earbuds for an optimal and comfortable fit.

Operating Your Headphones

1. Touch Controls

The CYBERDOT C01 earbuds feature multi-functional touch buttons for easy control of music, calls, and voice assistant.

Action	Function
Touch Twice (L/R)	Play/Pause Music, Answer/End Call
Long Press (L) for 2s	Previous Track
Long Press (R) for 2s	Next Track
Touch Triple (L/R)	Activate Voice Assistant (Siri, Google Assistant)

Action	Function
Touch Once (R)	Volume Up
Touch Once (L)	Volume Down
Long Press (L/R) during call	Reject Call




Image: A visual diagram illustrating the various touch control functions for music playback, calls, and voice assistant on both the left and right earbuds.

2. Audio Features

- **Stereo Sound:** Equipped with 16.3mm dynamic drivers, the C01 delivers rich, balanced, and accurate audio reproduction.
- **Clear Calls:** Advanced drivers ensure crystal-clear call quality, minimizing background noise.
- **Air-Conduction Design:** The open-ear design allows ambient sounds to reach your ears, enhancing

situational awareness for safety during outdoor activities or in busy environments.


Open Ear Headphones Enables Real-time Awareness of Environmental Sounds, Enhancing Safety During Your Trips



Driving



Walking the Dog



Running

Image: Three scenarios (driving, walking the dog, running) demonstrating how open-ear headphones enable real-time awareness of environmental sounds, enhancing safety.

3. Battery Life

The CYBERDOT C01 provides extended listening time:

- Up to 7 hours of listening time on a single charge.
- An additional 14 hours of listening time with the fully charged wireless charging case.
- Total listening time of up to 21 hours.

Open Air-Conduction Headphones Design

No in-ear, No ear tips, safeguarding the ear canal
from any discomfort, Reduced Ear Fatigue



Image: Graphic illustrating the battery life: 7 hours from a single earbud charge and an additional 14 hours from the rechargeable charging case, totaling 21 hours. Also shows the dual LED display for case and earbud power status.

Maintenance

1. Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Ensure charging contacts on both earbuds and case are clean and dry to prevent charging issues.

2. Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Keep the device in a cool, dry place, away from extreme temperatures and direct sunlight.

3. Water Resistance

The CYBERDOT C01 headphones are waterproof. This means they are resistant to sweat and light splashes, making them suitable for workouts and outdoor activities. However, they are not designed for swimming or prolonged submersion in water. Ensure the earbuds are dry before placing them back in the charging case to prevent damage.

Troubleshooting

Common Issues and Solutions

- **Earbuds not charging:**
 - Ensure the charging case has sufficient battery.
 - Check that the earbuds are correctly seated in the charging case and the charging contacts are clean.
 - Verify the USB-C cable is securely connected to both the case and the power source, or that the case is properly positioned on a wireless charging pad.
- **Earbuds not pairing or connecting to device:**
 - Make sure Bluetooth is enabled on your device.
 - Place the earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and take them out again to re-enter pairing mode.
 - Forget the device from your phone's Bluetooth settings and attempt to pair again.
 - Ensure the earbuds are charged.
- **Poor sound quality or choppy connection:**
 - Ensure the earbuds are within the Bluetooth range of your device (typically 10 meters/33 feet).
 - Check for any obstructions or interference between the earbuds and your device.
 - Restart your device and the earbuds.
- **Earbuds do not fit comfortably:**
 - Refer to the "Wearing the Earbuds" section for proper adjustment techniques. The revolving design allows for customization.

Specifications

Feature	Detail
Model Name	C01
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.3
Headphones Jack	No Jack
Included Components	Cable, Open Earbuds, User Manual, Wireless Charging Case
Material	Plastic
Control Type	Touch Control
Water Resistance Level	Waterproof

Feature	Detail
Audio Driver Type	Dynamic Driver (16.3mm)
Earpiece Shape	Open-ear
Color	Black
Item Weight	4.6 ounces
Batteries	1 A batteries required (included)
UPC	730425867802

Warranty and Support

For warranty information, please refer to the documentation included with your purchase or contact the seller directly. If you encounter any issues not covered in this manual or require further assistance, please reach out to CYBERDOT customer support through the retailer where you purchased the product. You can also visit the official CYBERDOT store on Amazon for more information:[CYBERDOT Store](#)

© 2025 CYBERDOT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

