

[manuals.plus](#) /

› [FIREBAT](#) /

› [FIREBAT AR1 Android Tablet User Manual](#)

FIREBAT AR1

FIREBAT AR1 Android Tablet User Manual

Model: AR1 | Brand: FIREBAT

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your FIREBAT AR1 Android Tablet. Please read this manual thoroughly to ensure proper use and to maximize the performance and longevity of your device.



The FIREBAT AR1 Android Tablet, shown with its included protective case and screen protector, is designed for versatile use.

2. PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- 1 x FIREBAT AR1 Tablet
- 1 x Protective Film (Installed)
- 1 x Protective Case (Installed)
- 1 x 9V/2A 18W US Power Charger
- 1 x User Manual

More Portable And Lightweight Tablet

Suitable for Children, The Elderly, Students, Easy Travel



The complete package contents of the FIREBAT AR1 Tablet.

3. PRODUCT OVERVIEW

The FIREBAT AR1 Tablet is equipped with advanced features for a smooth user experience. Its design focuses on portability and performance, making it suitable for various applications from entertainment to productivity.



An overview of the key technical specifications and features of the FIREBAT AR1 Tablet.

Key Features:

- Display:** 10.95-inch In-Cell 1920x1200 Touchscreen
- Processor:** Unisoc Spreadtrum T606 Octa-Core CPU
- Memory:** 12GB RAM, 128GB ROM (Expandable via SD card)
- Battery:** 8000mAh Large Capacity Battery with 18W Fast Charging
- Cameras:** 5MP Front Camera, 13MP Rear Camera
- Connectivity:** Wi-Fi 5 (2.4G/5G), Bluetooth 5.0, FM
- Operating System:** Android 15
- Security:** Widevine L1 Support for high-definition streaming
- Design:** Upgraded Thinner In-Cell Technology, Narrow Bezel, Delicate Texture Metal Shell

Unisoc Spreadtrum T606


2-Core + 6-Core Processor Design

6-core office, 2-core entertainment

Balanced performance and power consumption, more power-saving

Memory speed optimization, smooth application switching

Solve the anxiety of background occupation



The powerful Unisoc Spreadtrum T606 Octa-Core Processor ensures smooth operation.

Upgraded Thinner In-Cell Technology with 10.95in 1920*1200 LCD

Embed touch sensors directly into LCD pixels and integrate them with display functions Reduce eye fatigue provide more sensitive touch response and achieve higher display clarity



Experience vibrant visuals with the 10.95-inch In-Cell 1920x1200 LCD.

Narrower Narrow Bezel Design

While expanding the display, it also ensures the small size and portability of the entire tablet
Bring vivid visual effects and an immersive viewing experience



The narrow bezel design maximizes screen space for an immersive viewing experience.

Lighter and less hand-consuming Designed for convenient travel

10.1in/25.7cm*6.6in/16.8cm*0.3in/0.75cm



1.1LB/500g

Designed to be lighter and less hand-consuming, ideal for convenient travel.

Newly Upgraded Delicate Texture Metal Shell

Enhance heat dissipation

Anti-wear and non-slip materials improve protection performance

Smooth lines and a delicate rounded arc design on the back

Makes you more comfortable to hold



The newly upgraded delicate texture metal shell enhances heat dissipation and improves protection.

8000mAh/3.8V Large Capacity Battery

Work and games, both good



6 hours

Full load battery life



10 hours

Full load battery life



18W Type-C

fast charging saves more time

8000mAh



The 8000mAh large capacity battery provides extended usage time.

5MP Front Camera 13MP Rear Camera

Make video calls easily Enjoy clearer shooting quality



Capture moments and make video calls with the 5MP front and 13MP rear cameras.

Newly Upgraded Android 15 System

-  Privacy enhancement
-  Cross-device media control
-  UI interaction optimization
-  Image and audio technology upgrade
-  Improved security and multi-scenario user experience



4. SETUP

4.1 Initial Power On

1. Press and hold the Power button located on the side of the tablet until the FIREBAT logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.

4.2 Charging the Tablet

Before first use, fully charge the tablet using the provided 9V/2A 18W US Power Charger and USB-C cable.

- Connect the USB-C cable to the tablet's USB-C port.
- Plug the power adapter into a wall outlet.
- The battery indicator on the screen will show charging status.

4.3 Inserting an SD Card (Optional)

The tablet supports SD card expansion up to 1TB for additional storage.

1. Locate the TF Card Slot on the side of the tablet.
2. Gently insert the SD card into the slot until it clicks into place.
3. The tablet will prompt you to format the SD card for use, if necessary.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

- **Touchscreen:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Screen:** Access your apps and widgets.
- **Notifications Panel:** Swipe down from the top of the screen to view notifications and quick settings.



The responsive touchscreen allows for intuitive interaction.

5.2 Connecting to Wi-Fi

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi on.
3. Select your desired network from the list and enter the password if prompted.

5.3 Bluetooth Pairing

1. Go to **Settings > Connected devices > Bluetooth**.
2. Toggle Bluetooth on.
3. Select the device you wish to pair from the list of available devices.

5.4 Using the Cameras

The tablet features a 5MP front camera and a 13MP rear camera.

- Open the **Camera** app from the home screen or app drawer.
- Tap the shutter button to take photos or switch to video mode.
- Use the front camera for video calls and selfies, and the rear camera for higher-quality photos.

5.5 Media Playback and Productivity


The tablet supports multiple video and audio formats, and is compatible with various e-book and office software applications.

Supports Multiple Video Formats and Audio Formats



Enjoy your favorite videos and music with broad format support.

Supports A Variety of E-books and Office Software



The tablet supports a variety of e-books and office software for productivity.

5.6 Using the Protective Case

The included protective case not only safeguards your tablet but also functions as a stand for hands-free viewing.

- To use as a stand, fold the front cover into a triangular shape and position the tablet securely.
- Ensure the tablet is fully encased to protect against scratches and minor impacts.



The included protective case can be folded to serve as a convenient stand.

6. MAINTENANCE

6.1 Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- Avoid using harsh chemicals or abrasive materials.

6.2 Battery Care

- Avoid exposing the tablet to extreme temperatures.
- Do not let the battery completely drain frequently.
- Use only the provided charger or a certified compatible charger.

6.3 Software Updates

- Regularly check for system updates in **Settings > System > System update**.
- Updates can improve performance, add new features, and enhance security.

7. TROUBLESHOOTING

If you encounter any issues with your FIREBAT AR1 Tablet, please refer to the following common solutions:

Problem	Possible Solution

Problem	Possible Solution
Tablet does not turn on	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a forced restart by holding the Power button for 10-15 seconds.
Wi-Fi connectivity issues	Restart your Wi-Fi router. Forget the network on your tablet and reconnect. Ensure you are within range of the Wi-Fi signal.
Slow performance	Close unused applications. Clear cache from apps in Settings > Apps. Restart the tablet. Consider freeing up storage space.
Battery drains quickly	Reduce screen brightness. Close background apps. Disable Wi-Fi/Bluetooth when not in use. Limit location services.

8. SPECIFICATIONS

Feature	Detail
Brand	FIREBAT
Model Number	AR1
Operating System	Android 15
Screen Size	10.95 Inches (In-Cell 1920x1200 Touchscreen)
Processor	T606 Octa-Core
RAM	12GB
Flash Memory (ROM)	128GB
Front Camera	5MP
Rear Camera	13MP
Battery Capacity	8000mAh
Charging	18W Type-C Fast Charging
Connectivity	Wi-Fi 5, BT5.0, FM
Product Dimensions	10 x 6.6 x 0.3 inches
Item Weight	2.49 pounds

9. WARRANTY AND SUPPORT

FIREBAT products are manufactured with high standards of quality and performance. For any warranty claims or technical support, please contact FIREBAT customer service.

Contact Information:

- Email: support@firebatpc.com
- Website: www.firebatpc.com

Please retain your proof of purchase for warranty purposes.