



[Manuals.plus](#) /

> [GoCube](#) /

> GoChess Mini AI Chess Board & Deluxe Carry Bag Instruction Manual

GoCube GoChess Mini

GoChess Mini AI Chess Board & Deluxe Carry Bag Instruction Manual

Model: GoChess Mini | Brand: GoCube

INTRODUCTION

The GoChess Mini Smart Chess Bundle offers an advanced and portable chess experience. This intelligent chess set features built-in AI coaching, light-up guidance, and connectivity for online play, making it suitable for all skill levels. The included Deluxe Carry Bag ensures safe and organized transport of your GoChess Mini and its components.



Image: The GoChess Mini AI Chess Board, chess pieces, a smartphone displaying the GoChess app, and the Deluxe Carry Bag. This image showcases the complete bundle.

Key Features:

- **Protective Deluxe Carry Bag:** Custom-fit, padded bag with compartments for secure storage and travel.
- **Smart AI Coaching System:** Real-time light-up guidance and 32 AI difficulty levels for learning and improvement.
- **Online and Offline Play:** Connects seamlessly to Chess.com and Lichess for online matches, or play against the built-in AI offline.
- **Adjustable Assistance:** Features for all skill levels, making it educational and enjoyable for everyone.
- **Modern and Portable Design:** Lightweight, sleek, and compact, ideal for home, office, or travel.

WHAT'S IN THE BOX

Your GoChess Mini bundle includes all the necessary components to begin your chess journey.

Board. Pieces. Tablet. Accessories. The Whole Experience in One Bag.



Image: A visual representation of the GoChess Mini package contents, including the GoChess Mini Board, a full set of chess pieces, a USB charging cable, a mobile stand, two storage pouches for pieces, and an indication of the free companion app.

- GoChess Mini Board
- Full Chess Set (32 pieces)
- USB Charging Cable
- Mobile Stand
- 2x Piece Pouches
- Free GoChess App (download required)
- Deluxe Carry Bag

1. **Charge the GoChess Mini Board:** Connect the provided USB cable to the charging port on the GoChess Mini board and to a compatible USB power source. The board's indicator lights will show charging status. Ensure the board is fully charged before first use for optimal battery life.
2. **Download the GoChess App:** Search for "GoChess" in your device's app store (Apple App Store or Google Play Store) and download the official application. This app is essential for accessing AI coaching, online play, and other features.

Chess.com **Lichess.org**

- ◆ Slim and Portable
- ◆ Bluetooth Low Energy
- ◆ Advanced light system
- ◆ Magnetic Sensors
- ◆ Rechargeable battery

App-Enabled Chess Board
Get the full GoChess Experience

Download on the App Store GET IT ON Google Play

Image: A graphic illustrating the GoChess app interface on a smartphone, with icons for App Store and Google Play, indicating where to download the companion application.

3. **Pair with the App:**
 - Ensure Bluetooth is enabled on your smartphone or tablet.
 - Open the GoChess app and follow the on-screen instructions to connect to your GoChess Mini board. The board uses Bluetooth Low Energy (BLE) for efficient connection.
 - Once connected, the app will display the board status.
4. **Set up the Chess Pieces:** Place the chess pieces on the board in their standard starting positions. The GoChess Mini board features magnetic sensors to detect piece movements accurately.

Playing with AI Coaching:

The GoChess Mini offers an intelligent AI coaching system to help you improve your game. The board's advanced light system provides real-time guidance.



Image: A close-up of a hand moving a white pawn on the GoChess Mini board, with the square beneath the pawn illuminated by a purple light, indicating the AI coaching system in action.

- In the GoChess app, select the "Play Against AI" mode.
- Choose from 32 levels of AI difficulty to match your skill.
- The board will light up to suggest moves, indicate threats, or highlight optimal positions. Follow the light guidance to learn and strategize.
- The app provides real-time highlights, tips, and alerts during your game.

Online Play:

Connect with millions of players worldwide through popular chess platforms.



Image: A split image showing a person interacting with the GoChess app on a smartphone on the left, displaying an online game stream, and a person playing on the physical GoChess Mini board on the right, illustrating the seamless integration of online play with the physical board.

- Open the GoChess app and navigate to the "Online Challenge" section.
- Select your preferred platform: Chess.com or Lichess.org.
- Log in to your account or create a new one.
- Initiate a game, and your physical GoChess Mini board will mirror the online game, allowing you to play against remote opponents using physical pieces.

Offline Play:

You can also play against the built-in AI without an internet connection.

- Ensure your GoChess Mini board is charged.
- Open the GoChess app and select an offline AI mode.
- The board will interact with your moves and the AI's responses through its light system.

MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the GoChess Mini board and pieces. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, store the board and pieces in the provided Deluxe Carry Bag to protect them from dust, scratches, and impacts. The bag has dedicated compartments for organized storage.




Image: An overhead view of the open Deluxe Carry Bag, showing the various compartments designed to hold the GoChess Mini board, chess pieces, and accessories securely and organized for travel or storage.

- **Battery Care:** To prolong battery life, avoid fully discharging the board frequently. Charge it regularly, even if not in constant use. Store in a cool, dry place.
- **Handle with Care:** While durable, avoid dropping the board or applying excessive force to the pieces or board surface.

TROUBLESHOOTING

If you encounter issues with your GoChess Mini, try the following steps:

- **Board Not Responding:** Ensure the board is charged. Try turning it off and on again. Check the app connection.
- **App Connectivity Issues:** Make sure Bluetooth is enabled on your device. Restart the GoChess app. If issues persist, try restarting your device.
- **Incorrect Piece Detection:** Ensure pieces are placed correctly on their squares. Clean the board surface if necessary.
- **Lights Not Working:** Check if the board is powered on and connected to the app. Ensure the light system is enabled in the app settings.
- **App Freezing/Crashing:** Ensure your app is updated to the latest version. Clear the app's cache or reinstall the app if necessary.

For further assistance, please refer to the official GoCube support resources or contact customer service.

SPECIFICATIONS

Feature	Detail
Model	GoChess Mini
Connectivity	Bluetooth Low Energy (BLE)
AI Difficulty Levels	32
Online Platform Support	Chess.com, Lichess.org
Board Technology	Advanced Light System, Magnetic Sensors
Power Source	Rechargeable Battery (via USB)
Square Size	35 mm
King Height	72.5 mm
King Weight	22 gr
ASIN	B0F6V7W9PB

WARRANTY AND SUPPORT

GoCube products are designed for quality and durability. For information regarding warranty coverage, product registration, or technical support, please visit the official GoCube website or contact their customer service department.

GoCube Official Website: [GoCube Store on Amazon](#)

Please retain your proof of purchase for any warranty claims.

