Saved from manuals.plus.
Open the live page for links to other documents and user manuals.


Ymimi Replacement Brush Roller for Shark CU512, CU510, CU520, CU500

Ymimi Replacement Brush Roller Instruction Manual

For Shark Navigator Lift-Away XL Upright Vacuum Models CU512, CU510, CU520, CU500

1. Product Overview

This document provides instructions for the installation and maintenance of the Ymimi Replacement Brush Roller. This brush roller is designed to be compatible with specific Shark Navigator Lift-Away XL Multisurface Upright Vacuum Cleaner models, ensuring optimal cleaning performance.






Image 1: The Ymimi Replacement Brush Roller. This image displays the brush roller, which is a key component for vacuum cleaning.

2. Compatibility

The Ymimi Replacement Brush Roller is compatible with the following Shark Navigator Lift-Away XL Multisurface Upright Vacuum Cleaner models:

- Shark Navigator Lift-Away XL CU512
- Shark Navigator Lift-Away XL CU510
- Shark Navigator Lift-Away XL CU520
- Shark Navigator Lift-Away XL CU500

Please verify your vacuum cleaner's model number to ensure proper fit and function.




Image 2: Visual representation of compatible Shark vacuum models CU512 and CU510, alongside the replacement brush roller. This helps users identify if their vacuum is compatible.

3. Installation Instructions

Follow these steps to replace the brush roller in your Shark Navigator Lift-Away XL vacuum cleaner:

1. **Power Off and Unplug:** Before beginning any maintenance, ensure your vacuum cleaner is turned off and unplugged from the power outlet to prevent electrical hazards.
2. **Access the Brush Roll Area:** Lay the vacuum cleaner flat on its back. Locate the brush roll cover on the bottom of the vacuum head.
3. **Remove the Brush Roll Cover:** Depending on your specific model, you may need to use a coin or screwdriver to unlock the fasteners or screws holding the brush roll cover in place. Carefully remove the cover.
4. **Remove the Old Brush Roller:** Gently lift out the worn or damaged brush roller from its housing. Note the orientation of the end caps for reinstallation.
5. **Install the New Brush Roller:** Insert the Ymimi Replacement Brush Roller into the housing, ensuring the end caps align correctly with the slots. Make sure it spins freely.
6. **Reattach the Brush Roll Cover:** Place the brush roll cover back into position and secure it with the fasteners or screws.

Ensure it is tightly closed.

7. **Test the Vacuum:** Plug in the vacuum cleaner and turn it on to ensure the new brush roller is spinning correctly and the vacuum is functioning as expected.



Image 3: A close-up view showing the brush roller installed within the vacuum cleaner's head, illustrating its position and how it fits.

4. Maintenance

Regular maintenance of your brush roller is crucial for maintaining optimal vacuum performance.

- **Regular Cleaning:** Periodically check the brush roller for tangled hair, threads, or debris. Use scissors or a brush to carefully remove any obstructions.
- **Replacement Frequency:** For optimal performance, the brush roller should be replaced approximately every 12 months, or sooner if significant wear or damage is observed.

5. Specifications

Feature	Detail

Feature	Detail
Product Dimensions	10.94 x 2 x 2 inches
Item Weight	5.8 ounces
Manufacturer	Ymimi
Compatibility	Shark Navigator Lift-Away XL CU512, CU510, CU520, CU500



Image 4: This image illustrates the length of the replacement brush roller, measuring 10.94 inches, providing a visual reference for its size.

6. Troubleshooting

If you encounter issues after installing the new brush roller, consider the following:

- **Brush Roller Not Spinning:**

- Ensure the vacuum is properly assembled and the brush roll cover is securely fastened.
- Check for any remaining debris or obstructions around the brush roller or in the housing.
- Verify that the vacuum's power is on and the brush roll function is activated (if applicable to your model).

- **Unusual Noises:**
  - Turn off and unplug the vacuum. Inspect the brush roller and its housing for any foreign objects or improper seating.
- **Reduced Cleaning Performance:**
  - Ensure the brush roller is free of tangles and debris.
  - Confirm that the brush roller is the correct replacement part for your specific vacuum model.

7. Warranty and Support

Ymimi provides after-sales service for this product. If you encounter any issues or find that the product is not suitable for your needs, please contact us. We aim to reply within 24 hours to assist you.
For further assistance, please refer to the contact information provided with your purchase or on the Ymimi official website.

© 2026 Ymimi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6V8ZMNR

More documents and user manuals: **https://manuals.plus/**