

Norelco OneBlade 360 Face+Body

Philips Norelco OneBlade 360 Face+Body Hybrid Electric Trimmer and Shaver with Travel Case

Models: QP2834/70 (Device), QP401/90 (Travel Case)

INTRODUCTION

The Philips Norelco OneBlade 360 Face+Body is a versatile hybrid electric grooming tool designed for trimming, shaving, and creating precise edges on both facial and body hair. Its unique technology features a fast-moving cutter and a dual-protection system for comfortable use. This kit also includes a dedicated travel case for convenient storage and protection.

IMPORTANT SAFETY INFORMATION

- Always keep the charging cable away from water to prevent electrical hazards.
- Exercise caution when using the shaver to avoid cuts, especially on sensitive areas.
- Replace the blade every 4 months for optimal performance and to prevent skin irritation. An eject icon will appear on the blade when replacement is recommended.

WHAT'S IN THE BOX

- Philips Norelco OneBlade 360 Face+Body Device
- OneBlade 360 Blade (pre-attached)
- Extra Original Blade
- Body Comb (3mm)
- Skin Guard for sensitive areas
- 5-in-1 Adjustable Comb (1-5mm)
- USB-A Charging Cable (wall power adapter not included)
- Philips Norelco OneBlade Travel Case

SETUP

Charging the Device

1. Connect the USB-A charging cable to the OneBlade device.
2. Plug the other end of the USB-A cable into a compatible USB wall adapter (not included) or a powered USB port.
3. Allow the device to charge for approximately 4 hours for a full charge, which provides up to 60 minutes of continuous shaving power.

Attaching and Detaching Blades/Combs

- **Attaching a Blade:** Align the blade with the handle and push until it clicks into place.
- **Detaching a Blade:** Press the release button on the back of the blade and pull it away from the handle.
- **Attaching a Comb:** Snap the desired comb (5-in-1 adjustable comb, body comb, or skin guard) onto the blade until it securely clicks.
- **Detaching a Comb:** Gently pull the comb away from the blade.

OPERATING INSTRUCTIONS

The OneBlade can be used wet or dry, with or without foam. Its innovative 360 blade flexes in all directions to maintain constant skin contact.

For Face



Body comb

SkinGuard

For Body

trim & shave sensitive areas,
even below the belt


Image: Demonstrates trimming, shaving, and edging facial hair with the OneBlade.

- **Trimming:** Attach the 5-in-1 adjustable comb (1-5mm) to achieve your desired stubble length. Move the OneBlade against the grain of your hair.
- **Shaving:** Use the blade directly on your skin, moving it against the grain. The dual-protection system helps prevent nicks and cuts. Note that it does not shave as close as a traditional blade, ensuring skin comfort.
- **Edging:** Utilize the dual-sided blade for precise lines and edges. Shave in either direction to clearly see the hair you are cutting.

For Body

Unique OneBlade Technology

with fast-moving cutter and Dual Protection System



The new innovative 360 blade

for easy trim & shave with fewer passes and greater comfort¹

Image: Shows the OneBlade being used with the body comb and skin guard for body grooming.

- **Body Trimming:** Attach the 3mm body comb to trim body hair to an even length.
- **Sensitive Areas:** For extra protection on sensitive areas, attach the skin guard. Move the OneBlade gently in any direction to trim and shave.

MAINTENANCE

Cleaning

The OneBlade is fully waterproof. After each use, simply rinse the device and blade under running tap water to remove hair and debris. Ensure the device is dry before storing or charging.

Blade Replacement



Stainless steel blade

lasts up to 4 months of use². The eject icon lets you know when it's time for a new one.

Image: Illustrates the process of replacing the OneBlade's stainless steel blade.

The stainless steel blade is designed to last up to 4 months with typical use (based on 2 full shaves per week). An eject icon will appear on the blade itself to indicate when it's time to consider changing it for optimal performance and hygiene.

Travel Case Usage



Protect your handle and blade

Keeps your product safe
and prevents damage

Image: Displays the interior of the travel case, designed to hold the OneBlade handle, an attached blade, USB-A charging cable, and one comb.



Stainless steel blade

lasts up to 4 months of use². The eject icon lets you know when it's time for a new one.

Image: Shows the travel case being stored, emphasizing its protective function.

The dedicated travel case (QP401/90) is designed to protect your OneBlade device from damage, scratches, and dents while on the go. It accommodates the handle with an attached blade, a USB-A charging cable, and one comb.

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to the charger for at least 30 minutes before attempting to power it on again.
- **Poor trimming/shaving performance:** Check if the blade is clean and free of hair. If performance is still poor, it may be time to replace the blade (refer to 'Blade Replacement' section).
- **Irritation during use:** Ensure the blade is clean and not dull. Use the skin guard for sensitive areas. Always move the OneBlade gently against the grain.
- **Charging issues:** Verify that the USB-A cable is securely connected to both the device and a working power source. Try a different USB wall adapter if available.

SPECIFICATIONS

Convenient storage

Fits handle with blade attached,
USB-A charging cable,
and one comb



Products
not included.

Image: Highlights the unique OneBlade technology, including the fast-moving cutter and the innovative 360 blade design.

Brand Name	Norelco
Model Name	OneBlade 360 Face+Body
ASIN	B0F6VDDT5J
Power Source	Battery Powered
Battery Description	Rechargeable (Lithium-Ion)
Head Type	Foil Trimming
Number of Blades	1
Blade Material	Stainless Steel
Color	Black/Lime Green
Unit Count	2 Count (Device + Travel Case)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Philips Norelco website. Keep your purchase receipt as proof of purchase for warranty claims.