

Xqscvqwfa TP.MS3553.PB782 3MS553A0

Xqscvqwfa TP.MS3553.PB782 3MS553A0 TV Motherboard User Manual

Model: TP.MS3553.PB782 3MS553A0

INTRODUCTION

This manual provides essential instructions for the installation, operation, maintenance, and troubleshooting of your Xqscvqwfa TP.MS3553.PB782 3MS553A0 TV Motherboard. This component is designed for display equipment and offers features such as easy installation, system stability, high-definition support, and protection against static and overvoltage. Please read this manual thoroughly before proceeding with any installation or operation.

SAFETY INFORMATION

- Always disconnect power from the television before attempting any installation or maintenance.
- Handle the motherboard by its edges to avoid touching sensitive components and to prevent electrostatic discharge (ESD).
- Ensure proper grounding during installation to protect against static electricity.
- Refer to the television's service manual for specific disassembly and reassembly procedures.
- If you are unsure about any step, seek assistance from a qualified technician.

SETUP AND INSTALLATION

The TP.MS3553.PB782 3MS553A0 motherboard is designed for easy installation. Follow these general steps for replacement:

1. **Preparation:** Disconnect the television from the power outlet. Lay the TV face down on a soft, clean surface

to prevent screen damage.

2. **Access the Motherboard:** Remove the back cover of the television. This usually involves unscrewing several screws.
3. **Disconnect Cables:** Carefully disconnect all cables connected to the old motherboard, including power, LVDS (display panel), and input/output cables. Note their positions or take photos for reference.
4. **Remove Old Motherboard:** Unscrew the mounting screws holding the old motherboard in place and gently lift it out.
5. **Install New Motherboard:** Place the new TP.MS3553.PB782 3MS553A0 motherboard into position, ensuring it aligns with the mounting holes. Secure it with the screws.
6. **Reconnect Cables:** Reconnect all cables to their corresponding ports on the new motherboard. Ensure all connections are firm and correctly oriented.
7. **Final Assembly:** Replace the back cover of the television and secure it with screws.
8. **Power On:** Connect the television to power and test its functionality.




Image 1: Close-up of the motherboard, highlighting the model numbers TP.MS3553.PB782 and 3MS553A0. This view shows the main chip with a heatsink and various connectors.



Image 2: A white label affixed to the motherboard, displaying a barcode and alphanumeric identifiers such as K19125368-0H00007 and IDD961823A, which are crucial for product identification and tracking.

OPERATING INSTRUCTIONS

Once the TP.MS3553.PB782 3MS553A0 motherboard is correctly installed, the television should power on and function as expected. This motherboard is a replacement component and does not typically require specific user operating instructions beyond the standard use of the television itself.

- **Initial Power On:** After installation, connect the TV to power and press the power button. The TV should display the brand logo or input selection screen.
- **Input Selection:** Use the TV remote control to select the desired input source (HDMI, AV, etc.).
- **Channel Scan:** If using an antenna or cable, perform a channel scan through the TV's menu settings to detect available channels.
- **Settings Adjustment:** Adjust picture, sound, and other settings as needed via the TV's on-screen menu.




Image 3: The full rear view of the motherboard, illustrating the arrangement of components, solder points, and various ports such as AV OUT, AV IN, and optical audio output. Important safety warnings regarding live parts and fuse replacement are also visible.

MAINTENANCE

The TP.MS3553.PB782 3MS553A0 TV Motherboard requires minimal maintenance. To ensure its longevity and optimal performance:

- **Keep Clean:** Ensure the interior of the television remains free from dust and debris. Dust accumulation can lead to overheating and component failure. Use compressed air to gently clean the motherboard if necessary, with the TV powered off and unplugged.
- **Ventilation:** Ensure the television's ventilation openings are not blocked to allow for proper airflow and heat dissipation.
- **Avoid Liquids:** Keep liquids away from the television to prevent damage to the electronic components.

TROUBLESHOOTING

If you encounter issues after installing the TP.MS3553.PB782 3MS553A0 motherboard, consider the following common troubleshooting steps:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
TV does not power on.	Loose power connection, faulty power supply, or incorrect motherboard installation.	Check all power cable connections. Ensure the power supply unit is functioning. Re-verify motherboard installation steps.
No picture, but sound is present.	LVDS cable not properly connected, or backlight issue.	Ensure the LVDS cable is securely connected to both the motherboard and the display panel. Check for backlight functionality.
No sound, but picture is present.	Audio cables not connected, or incorrect audio settings.	Verify all audio cable connections. Check TV audio settings and ensure volume is not muted.
Distorted picture or colors.	Loose LVDS cable, or panel settings mismatch.	Reseat the LVDS cable. If the issue persists, the panel settings may need adjustment (advanced users only, refer to TV service manual).

If these steps do not resolve the issue, it is recommended to consult a professional television repair technician.

SPECIFICATIONS

Key specifications for the Xqscvqwfa TP.MS3553.PB782 3MS553A0 TV Motherboard:

- **Model Number:** TP.MS3553.PB782 3MS553A0
- **Brand:** Xqscvqwfa
- **Compatible Equipment Style:** Display Equipment
- **Features:** Easy installation, system stability, high definition support, anti-static and overvoltage protection.
- **Product Dimensions:** 0.39 x 0.39 x 0.39 inches (approximate)
- **Item Weight:** 1.76 ounces (approximate)



Image 4: A white label on the motherboard providing specific technical details, including voltage requirements (36V-40.8V), current (600mA), and flash memory capacity (8MByte). This information is critical for compatibility and power supply considerations.

WARRANTY AND SUPPORT

For warranty information and technical support regarding your Xqscvqwfa TP.MS3553.PB782 3MS553A0 TV Motherboard, please refer to the retailer or manufacturer's official website. Keep your purchase receipt as proof of purchase.

For additional assistance, you may contact the seller directly through the platform where the purchase was made.

© 2024 Xqscvqwfa. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question