

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [AVIOT](#) /
- › [AVIOT TE-V1R-HOP Wireless Earbuds User Manual](#)

## AVIOT TE-V1R-HOP

# AVIOT TE-V1R-HOP Wireless Earbuds User Manual

Model: TE-V1R-HOP

## INTRODUCTION

---

This manual provides instructions for the proper use and maintenance of your AVIOT TE-V1R-HOP Wireless Earbuds. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

## WHAT'S IN THE BOX

---

Verify that all items are present in the package:

- Earbuds (Left and Right)
- Wireless Charging Case
- Charging Cable
- Ear Cushions (various sizes)
- User Manual

(((★ **Base Model** ★)))



## TE-V1R

The latest model in AVIOT's hit V Series, which has sold approximately 150,000 units, builds upon the previous model, the TE-D01v, with further upgrades to its core functionality.

The earbuds offer an impressive 19 hours of playtime on their own and up to 62 hours with the charging case, with Adaptive Hybrid Noise Canceling, which automatically adjusts the noise cancellation strength based on the surrounding environment.

**\*As of the end of September 2024**

Image: The AVIOT TE-V1R-HOP earbuds, charging case, and accessories.

## SETUP

### 1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the charging cable to the case and a power source. The indicator lights on the case will show charging status.

## (((★ Special Voice ★)))

In addition to voice guidance for notifications like power and connection status, these earbuds include a “random voice” function that plays a voice clip when you hold the right button. The app lets you switch between **nine modes**, including individual and program-inspired modes for each personality, plus a **HOOOOPE! Mode** featuring all four voices.



©文化放送

Image: Earbuds placed inside the charging case.

## 2. Pairing with a Device

1. Ensure the earbuds are in the charging case and the case lid is open.
2. Activate Bluetooth on your device (smartphone, tablet, etc.).
3. Select "AVIOT TE-V1R-HOP" from the list of available Bluetooth devices.
4. Once connected, a voice prompt will confirm successful pairing.

The earbuds support Bluetooth 5.3 for stable connectivity.

## 3. Fitting the Earbuds

Choose the ear cushions that provide the best seal and comfort for your ears. A proper fit is crucial for optimal sound quality and noise cancellation.

## (((★ Special Design ★)))

The earbuds and charging case feature a design inspired by the program's logo. The simple, user-friendly design allows you to always feel connected to HOOOOPE! and its four members.



©文化放送

Image: Earbuds correctly inserted into an ear.

## OPERATING INSTRUCTIONS

### Power On/Off

- **Power On:** Open the charging case lid, or remove the earbuds from the case.
- **Power Off:** Place the earbuds back into the charging case and close the lid.

### Touch Controls

The earbuds feature touch-sensitive controls for various functions. Refer to the detailed control scheme in the included quick start guide for specific tap and hold gestures.

### Adaptive Hybrid Noise Cancelling

The earbuds feature adaptive hybrid noise-cancelling technology with four microphones. This system automatically adjusts the noise cancellation strength based on your surrounding environment to reduce unwanted noise effectively.



Image: Overview of key features including Adaptive Hybrid Noise Cancelling.

## Special Voice Function

In addition to standard voice guidance for notifications (power, connection status), these earbuds include a "random voice" function. Hold the right earbud button to play a voice clip. The companion app allows you to switch between nine different voice modes, including individual character modes and a "HOOOOPE!" mode featuring all four voices.

-----MONDAY-----

((★ List of voice lines ★))

Turn on	Dengen ga haitta wa~
Turn off	Dengen ga kirete simatta you ne
Connect	Setsuzoku kanyou! Kore de anata mo Borubokkusu!
Disconnect	Setsuzoku ga kirete simatta wa!
Pairing	Pairing chuu yo~
Pairing success	Pairing ni seikou sita wa!
Pairing failure	Pairing sippai yo. Mou ichido challenge site minasai
Low battery	Sorosoro juuden sinasai
Noise canceling mode	Noise cancelling o on ni sita wa
Transparency mode	Ambient mic yo
Normal mode	Normal mode ni nasai

**Shuffle**  
(Press and hold the right button on the earbuds to play)

- Kirei na midoriiro ni somete ageru wa~
- Kyou no lucky color wa midoriiro yo~
- Harihari Salon Paulus
- Onesan ni soudan site gorannasai?
- "Borunee" koto, Borubokkusu neesan yo~
- Borubokkusu, chiisakute marukute kawaii desho~?
- Watashi mo wakannai yo~
- N~ nurenai you ni kousoku de ugoichae! Kaasakasakasa...
- BGM o kaechae!
- Borunee wa squat siteru wa yo?

Borun-nee

©文化放送 HOOOOPE!

Image: Explanation of the special voice function and available modes.

## Voice Line Lists

The following images detail the voice lines for each character and mode:



Image: Manatsu Murakami voice lines (Monday).



Image: Borun-nee voice lines (Monday).



Image: Hina Yomiya voice lines (Tuesday).



Image: Omusubi-chan voice lines (Tuesday).



Image: Yurie Igoma voice lines (Wednesday).



Image: Goma-chan voice lines (Wednesday).



Image: Saku Mizuno voice lines (Thursday).



Image: Fukahire voice lines (Thursday).

Image: HOOOOPE! mode voice lines.

## Special Tuning Modes

The earbuds offer two distinct tuning modes:

- **Music Mode:** Optimized for general music listening, providing the full sound performance of the TE-V1R.
- **ASMR Mode:** Specifically tuned for binaural content, enhancing the detail of subtle sounds as if the audio source is nearby.


---WEDNESDAY---


(((★ List of voice lines ★)))

Turn on	Yahho~!
Turn off	Sore jaa, bai bai~!
Connect	Setsuzoku dekita yoo~! Goma-chan da yoo~!
Disconnect	Setsuzoku kirechatta~
Pairing	Pairing chuu da yoo~
Pairing success	Pairing, ii kanji~? Yei~!
Pairing failure	Pairing sippai datte~
Low battery	Juuden site hoshii na~
Noise canceling mode	OK~, shizuka ni suru ne~
Transparency mode	Suisou no soto no oto, kiite miyo~
Normal mode	Normal mode na no?

**Shuffle**  
(Press and hold the right button on the earbuds to play)

- Kyou mo~ ii kanji~? Yei~!
- Boku ni kikitai koto wa aru kai?
- Kimi~, ii namae da ne~
- E? Goma-chan kawaii?
- Mata kite kureta no? Arigato~
- Ningenkai no koto shiritai na
- Sore jaa issho ni? Gomachaan!
- Boku ga koko ni iru koto, Yurie-oneesan ni wa naisho da yo!
- Boku no uta o kiite! Kyu kyu kyu~♪
- Kyui~!

©文化放送 



**Goma-chan**

Image: Description of special tuning modes.

## Battery Life and Charging

The earbuds provide up to 19 hours of playback on a single charge. The wireless charging case extends the total playback time to up to 62 hours. The case supports wireless charging.

## MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Do not use abrasive materials or harsh chemicals.
- **Ear Cushions:** Remove and clean ear cushions periodically. Replace them if they become worn or damaged to maintain sound quality and fit.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water Resistance:** The earbuds are IPX4 rated, meaning they are resistant to splashing water from any direction. Do not submerge them in water.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not pairing	Earbuds not in pairing mode, Bluetooth off on device, out of range.	Ensure earbuds are in case with lid open. Check device Bluetooth settings. Move closer to device.
No sound	Low battery, not connected, volume too low.	Charge earbuds. Re-pair with device. Increase volume on device and earbuds.
Noise cancellation not effective	Improper fit, environmental noise too high.	Adjust earbud fit and try different ear cushion sizes.
Earbuds not charging	Cable issue, dirty charging contacts, power source problem.	Check charging cable and power adapter. Clean charging contacts on earbuds and case.

## SPECIFICATIONS

Feature	Detail
Model Name	TE-V1R-HOP
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Noise Control	Adaptive Noise Cancellation
Water Resistance Level	IPX4 (Waterproof)
Control Method	Touch
Earpiece Shape	Bud (In Ear)
Maximum Playback Time (Earbuds only)	Up to 19 hours
Maximum Playback Time (with Charging Case)	Up to 62 hours
Charging Case	Wireless Charging Capable
Item Weight	7.2 ounces
Manufacturer	AVIOT

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official AVIOT website or contact your local distributor. Keep your proof of purchase for warranty claims.

Visit the official AVIOT store for more information: [AVIOT Store](#)