

## FLEXISPOT XRC6

# FLEXISPOT XRC6 Nursery Swivel Rocker Recliner Instruction Manual

Model: XRC6 | Brand: FLEXISPOT

## INTRODUCTION

Thank you for choosing the FLEXISPOT XRC6 Nursery Swivel Rocker Recliner. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your recliner. Please read all instructions carefully before use and retain this manual for future reference.



*Image: The FLEXISPOT XRC6 recliner, highlighting its massage function.*

## IMPORTANT SAFETY INFORMATION

To reduce the risk of injury, please observe the following safety precautions:

- Ensure all parts are securely fastened before use.
- Keep children and pets away from the recliner's moving parts.
- Do not stand on the recliner or use it as a step stool.
- Avoid placing heavy objects on the footrest when extended.
- Unplug the power cord before cleaning or if the recliner will be unused for an extended period.
- Maximum weight capacity: 300 lbs.

## SETUP GUIDE

The FLEXISPOT XRC6 recliner is designed for easy assembly. It ships in two compact boxes. Follow these steps for proper installation:

Your browser does not support the video tag.

*Video: Installation Guide for the FLEXISPOT Swivel Rocker Recliner XRC6.*

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that you have the seat, backrest, two armrests, adjustment lever, remote control, adapter, screws, flat washers, nuts, wrench, and hex key.
2. **Attach Armrests:** Align the hook-loop brackets on the armrests with the corresponding slots on the seat base. Gently push down until each armrest locks into position.
3. **Insert Adjustment Lever:** With the chair on its side, insert the angle adjustment lever into its designated slot on the side of the seat base.
4. **Secure Screws:** Locate the screw installation area. Insert the provided screws, ensuring correct orientation.
5. **Extend Footrest:** To access the remaining installation area, extend the footrest using the lever.
6. **Fasten with Washers and Nuts:** Secure the components using the washers and nuts provided. Ensure all connections are tight.
7. **Install Backrest:** Align the backrest with the seat base. Push down firmly until you hear a "click," indicating proper installation.
8. **Connect Wires:** Locate the power wires for the massage and heat functions. Connect them securely.
9. **Attach Rear Panel:** Attach the velcro on the backrest rear panel to secure it in place, covering the wires.

# Product Size

Ideal Height: 5'4"-5'9"



Image: Product dimensions and shipping information.

## OPERATING INSTRUCTIONS

### Reclining and Rocking Functions

- **Recline:** Pull the manual lever located on the side of the recliner to extend the footrest and recline the backrest. Push back with your body weight to achieve your desired recline angle.
- **Return to Upright:** To return to the upright position, gently push the footrest down with your legs and lean forward. The backrest will follow.
- **Swivel:** The recliner features a 360° swivel base, allowing you to rotate freely.
- **Rocking:** The chair provides a gentle 30° back-and-forth rocking motion for comfort.

# Manual Swivel Rocker Recliner

270° swivel, 30° rock & easy recline adjustment with a pull handle.



*Image: Manual swivel, rock, and recline adjustment with pull handle.*





*Image: Full recline position for relaxation.*

## Massage and Heat Functions

The recliner includes a remote control for activating and adjusting the massage and heat features.

- **Power On/Off:** Use the power button on the remote to turn the massage and heat functions on or off.
- **Massage Modes:** Select from multiple massage modes (e.g., pulse, press, wave, auto) using the 'Mode' button.
- **Intensity Levels:** Adjust the massage intensity (high, medium, low) with the 'Intensity' buttons.
- **Targeted Massage:** Use the 'Part' button to select specific areas for massage, such as the back or lumbar region.
- **Heat Function:** Press the 'Heat' button to activate the lumbar heating function. The indicator light will turn red when active.
- **Timer:** Set a timer for your massage session using the 'Time' button.



## Spa-Like Experience



**4** Vibration Nodes



**3** Vibration Modes



**3** Intensity Levels



*Image: Remote control for massage and heat functions.*

## CARE AND MAINTENANCE

- **Fabric Care:** The OEKO-TEX certified chenille fabric is spill-resistant. For spills and everyday messes, wipe clean with a damp cloth. Avoid harsh chemicals.
- **General Cleaning:** Regularly vacuum the recliner to remove dust and debris.
- **Moving Parts:** Periodically check all screws and connections to ensure they are tight. Lubricate moving metal parts if necessary, following manufacturer guidelines.
- **Power Cord:** Inspect the power cord for any damage. If damaged, discontinue use and contact customer support.



# Comfort In Details

every detail is precision-engineered for  
your body's natural comfort.

## Chenille



**Massage & Heating**



**24.4\"/>**



**Luxury Chenille**



**Gently Flared Armrests**



*Image: Details of the recliner's chenille fabric and comfort features.*

## TROUBLESHOOTING

If you encounter any issues with your recliner, please refer to the following common solutions:

- **Recliner Not Reclining:**

- Ensure the manual lever is fully pulled.
- Check for any obstructions preventing the footrest or backrest from moving.

- **Massage/Heat Not Working:**

- Verify that the power adapter is securely plugged into both the recliner and a working wall outlet.
- Check if the power button on the remote control is pressed.
- Ensure all internal wires are properly connected (refer to Setup Guide).



- **Unstable or Wobbly:**
  - Confirm that all assembly screws and nuts are tightened.
  - Ensure the recliner is placed on a flat, even surface.

If the issue persists, please contact FLEXISPOT customer support.

SPECIFICATIONS

Feature	Detail
Brand	FLEXISPOT
Model	XRC6
Color	Beige
Product Dimensions	35.43"D x 32.5"W x 40"H
Size	Large
Back Style	High
Weight Capacity	Up to 300 lbs
Fabric Type	OEKO-TEX Certified Chenille
Frame Material	Reinforced Steel, FSC-Certified Wood
Special Features	360° Swivel, 30° Rocking, Manual Recline, 4-point Back Massage, Lumbar Heat


WARRANTY AND SUPPORT

FLEXISPOT products are manufactured with quality and durability in mind. For specific warranty details, please refer to the warranty card included with your product or visit the official FLEXISPOT website.

For customer support, technical assistance, or to inquire about replacement parts, please contact FLEXISPOT directly or visit their official store:





[Visit the FLEXISPOT Store on Amazon](#)

Related Documents - XRC6



[Flexispot Power Swivel Rocker Recliner Assembly and User Guide](#)

Detailed assembly instructions, product specifications, usage guidelines, and troubleshooting for the Flexispot Power Swivel Rocker Recliner. Learn how to set up and operate your new recliner chair safely and efficiently.

	<p><a href="#">FlexiSpot Waffle Back Elektrische Relaxfauteuil Gebruiksaanwijzing en Montagegids</a></p> <p>Gedetailleerde instructies voor het monteren, gebruiken en oplossen van problemen met de FlexiSpot Waffle Back Elektrische Relaxfauteuil. Inclusief productspecificaties en veiligheidswaarschuwingen.</p>
	<p><a href="#">FlexiSpot XP6 Pushback Recliner Chair User Manual</a></p> <p>User manual for the FlexiSpot XP6 Pushback Recliner Chair, providing assembly instructions, usage guidelines, maintenance tips, warnings, and troubleshooting information.</p>
	<p><a href="#">FlexiSpot DT3B-EU User Manual and Warranty Information</a></p> <p>Comprehensive user manual for the FlexiSpot DT3B-EU height adjustable desk frame, including detailed assembly instructions, parts list, and warranty coverage information.</p>
	<p><a href="#">FlexiSpot XP6 Pushback Recliner Chair User Manual</a></p> <p>Comprehensive user manual for the FlexiSpot XP6 Pushback Recliner Chair, covering assembly instructions, product specifications, usage guidelines, maintenance tips, warnings, and troubleshooting.</p>
	<p><a href="#">FlexiSpot XC6 Recliner Chair User Manual: Assembly, Operation, and Safety Guide</a></p> <p>This user manual provides detailed assembly instructions, usage guidelines, maintenance tips, and safety warnings for the FlexiSpot XC6 recliner chair (Item No. XC6-BG-EU/XC6-OB-EU/XC6-LG-EU). Learn how to set up, operate, and safely use your chair.</p>