ENERGIZE LAB Eiliko

ENERGIZE LAB Eiliko Aquamarine AI Charm Robot User Manual

Model: Eiliko

1. Introduction

The ENERGIZE LAB Eiliko Aquamarine is a compact AI companion designed to offer interactive experiences and personalized expressions. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Eiliko robot.



Image: The Eiliko Aquamarine AI Charm Robot, a small white robot with blue accents and a digital face, designed to be a portable companion.

2. Safety Information

- Keep small objects away from children to prevent accidental ingestion.
- Do not expose the device to extreme temperatures or direct sunlight.
- Avoid contact with water or other liquids.
- Do not attempt to disassemble or repair the device yourself. Contact support if needed.

3. Setup

3.1 Unboxing and Initial Charge

Your Eiliko robot comes with a USB charging cable. Connect Eiliko to a power source using the provided cable to ensure it is fully charged before first use.

3.2 Attaching Eiliko

Eiliko can be easily attached to your backpack, keys, or belt loop using the integrated loop. This allows Eiliko to accompany you wherever you go.



Image: The Eiliko robot attached to a brown handbag, demonstrating its portability as a charm.

3.3 Connecting to Wi-Fi (for AI Features)

To unlock Eiliko's full AI capabilities, connect it to a 2.4G Wi-Fi network via the dedicated mobile application. This enables Eiliko to become an AI conversationalist and receive updates.

Your browser does not support the video tag.

Video: An official product video demonstrating the Eiliko AI Charm Robot's features, including its ability to match outfits and interact with users. The video highlights various expressions and interactions.

4. Operating Eiliko

4.1 Basic Interactions

- **Changing Expressions:** Press Eiliko's head once to cycle through various animated faces and expressions.
- **Petting:** Repeatedly pet Eiliko's head to influence its mood and personality, leading to different expressions.
- **Shaking:** Give Eiliko a gentle shake to see a "dizzy" animation, indicating its gyroscope functionality.
- **Voice Commands (Offline):** Eiliko responds to built-in voice commands even without Wi-Fi, displaying delightful animations.
- **Muting:** Tap Eiliko's head three times to mute its sounds for a quiet break.



Image: A hand gently petting the Eiliko robot's head, illustrating one of its interactive features.

4.2 AI Chat Mode

Once connected to Wi-Fi, Eiliko can engage in AI conversations. To activate AI chat, hold down the button on Eiliko's head until its eyes change to a rainbow color, indicating it is listening. To exit AI chat, double-tap Eiliko's head.



Image: A user interacting with Eiliko in AI chat mode, showing different facial expressions and conversational responses.

4.3 Themed Bodies and Personalities

Eiliko supports interchangeable themed bodies that alter its appearance and can influence its personality and unique responses in AI chat mode. These bodies are sold separately.



Image: A display of various themed bodies for Eiliko, including "Baby," "Hawaii," "Dracula," "Cowboy," "Dino," "Eiliko Chan," "Magician," and "Bee."

4.4 Pairing Two Eilikos

Each Eiliko robot is designed to pair only once with another Eiliko. Once paired, they will unlock exclusive animations and interactions, creating a unique bond between the two devices.



Image: Two Eiliko robots, one in a yellow baby outfit and another in a cowboy outfit, facing each other and displaying interactive expressions.

5. Maintenance

5.1 Cleaning

Wipe Eiliko with a soft, dry cloth. Do not use harsh chemicals or abrasive materials, as these may damage the device.

5.2 Software Updates

When Eiliko first enters online mode each day, it automatically checks for and installs the latest software updates to ensure optimal performance and new features.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Eiliko is unresponsive.	Low battery or device is off.	Charge Eiliko using the USB cable. Ensure the device is powered on.
Eiliko does not connect to Wi-Fi.	Incorrect Wi-Fi password, out of range, or incompatible network (only 2.4G supported).	Verify Wi-Fi credentials, move Eiliko closer to the router, and ensure you are using a 2.4G network. Restart the app and Eiliko.
AI chat responses are random or Eiliko mishears.	Poor Wi-Fi connection, background noise, or unclear speech.	Ensure a stable Wi-Fi connection. Speak clearly and reduce background noise. Try re-activating AI chat mode.

7. Specifications

- **Product Dimensions:** 2.68 x 2.2 x 3.31 inches
- **Item Weight:** 6.3 ounces
- **Item Model Number:** Eiliko
- **Manufacturer Recommended Age:** 3 years and up
- **Batteries:** 1 A battery required (included)
- **Connectivity:** 2.4G Wi-Fi (for AI features)

8. Warranty and Support

For warranty information and customer support, please refer to the official ENERGIZE LAB website or contact your retailer. Specific warranty terms may vary by region and purchase location.
Manufacturer: ENERGIZE LAB

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I make the ENERGIZE LAB Eiliko robot speak in Russian?

Based on the available manual for the ENERGIZE LAB Eiliko, there is no specific mention of a language selection setting for Russian. However, you can attempt the following steps to enable or check for...

Read full answer