

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [MANSCAPED](#) /

› [MANSCAPED® The Face Buffer PRO - Men's Electric Silicone Face Scrubber for Nourishing, Deep Cleaning & Exfoliating Your Skin, 3 Facial Cleansing Modes & 2 Sonic Vibration Speeds, Travel Lock](#)

MANSCAPED 30-00161

MANSCAPED® The Face Buffer PRO Instruction Manual

Men's Electric Silicone Face Scrubber

INTRODUCTION

Welcome to the MANSCAPED® The Face Buffer PRO user manual. This electric silicone face scrubber is designed for nourishing, deep cleaning, and exfoliating your skin. It features multiple cleansing modes and sonic vibration speeds to provide an optimal facial cleansing experience.

Please read this manual thoroughly before using your device to ensure safe and effective operation. Keep this manual for future reference.



Image: The MANSCAPED® The Face Buffer PRO, an electric silicone face scrubber, shown alongside its product packaging.

KEY FEATURES

- **3 Cleansing Modes:** Choose from pad oscillation for targeted exfoliation, sonic vibrations for deep pore cleansing, or combine both for the ultimate cleanse.
- **2 Sonic Vibration Speeds:** Switch between 6,000 or 9,000 RPMs to match your skin's needs, from a gentle refresh to a more powerful cleanse.
- **Dual Bristle Pads:** Two independent silicone pads work together to scrub away dirt, oil, and dead skin to reveal better-looking skin.
- **Fast & Effective:** Get a deep clean in just 60 seconds, making it easy to fit into your daily skincare routine.
- **Long-Lasting Battery:** Enjoy up to 75 minutes of runtime on a single charge, plus a five-minute quick charge option when you're in a hurry.
- **Travel Lock:** Waterproof, portable, and equipped with a travel lock for mess-free grooming wherever you go. Press and hold the power button for 3 seconds to engage / disengage.

Electric Face Scrubber



Three cleansing modes.

Pad oscillation, sonic vibrations, or combine both for the ultimate cleanse.



Dual Bristle Pads

Two individual bristle pads that oscillate or use sonic vibrations to cleanse and exfoliate.



Travel Lock

Press and hold the lock button for 3 seconds to engage / disengage.



Two Vibration Speeds

Switch between 6,000 or 9,000 RPMs to match your skin's needs, from a gentle refresh to a more powerful cleanse.



Image: An overhead view of The Face Buffer PRO highlighting its key features: three cleansing modes, travel lock, dual bristle pads, and two vibration speeds.

SETUP

Unboxing and Initial Charge

1. Carefully remove The Face Buffer PRO and all accessories from the packaging.
2. Before first use, fully charge the device. Connect the charging cable to the device and a suitable USB power source. The indicator light will show charging status.
3. A full charge provides up to 75 minutes of runtime. A 5-minute quick charge option is available for immediate use.

Travel Lock

The device is equipped with a travel lock to prevent accidental activation. To engage or disengage the travel lock, press and hold the power button for 3 seconds.



Take a minute.

Get a deep clean in 60 seconds. And with up to 60 minutes of runtime, that's over a month's worth of cleansing on a single charge.



Image: The MANSAPED® The Face Buffer PRO being charged, illustrating its long-lasting battery and quick charge capability.

OPERATING INSTRUCTIONS

Daily Cleansing Routine

1. Apply one pump of Skin Ultra™ Daily Face Wash onto damp hands or directly onto The Face Buffer PRO's silicone pads.
2. Press the power button to turn on the device.
3. Select your desired cleansing mode and vibration speed using the mode selection buttons.
4. Gently massage the device in circular motions onto your face and neck for 60 seconds.
5. Rinse your face and neck thoroughly with water after cleansing.



Set the vibe.

Switch between a vibration speed of 6,000 RPMs or 9,000 RPMs for your choice of a gentler or more powerful clean.



Image: A man using The Face Buffer PRO on his face, demonstrating the sonic clean feature for deep pore cleansing.



Soft on skin.

Soft silicone bristles gently exfoliate while giving you a deep cleanse.

Image: The Face Buffer PRO on a textured surface, illustrating the two sonic vibration speeds (6,000 or 9,000 RPMs) for customized cleansing.



Independent buffer pads.

Equipped with two independent bristle pads that oscillate or use sonic vibrations to cleanse and exfoliate.

Image: A close-up of the soft silicone bristles of The Face Buffer PRO, designed for gentle exfoliation and deep cleansing.



Image: The Face Buffer PRO showcasing its two independent bristle pads that oscillate or use sonic vibrations for cleansing and exfoliation.



Image: Hands applying face wash directly onto the silicone bristles of The Face Buffer PRO, preparing for use.



Image: A man smiling while using The Face Buffer PRO to cleanse his face, demonstrating the product in action.

MAINTENANCE

Cleaning the Device

- After each use, rinse The Face Buffer PRO thoroughly under running water to remove any soap residue and debris.
- The device is waterproof, allowing for easy cleaning.
- Allow the device to air dry completely before storing.

Storage

Store The Face Buffer PRO in a clean, dry place away from direct sunlight and extreme temperatures. Ensure the travel lock is engaged when traveling to prevent accidental activation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is low or depleted. Travel lock is engaged.	Charge the device fully. Disengage the travel lock by pressing and holding the power button for 3 seconds.
Weak vibration or oscillation.	Low battery.	Recharge the device.

Problem	Possible Cause	Solution
Device stops unexpectedly.	Battery depleted.	Recharge the device.

If you encounter issues not listed here, please refer to the [Warranty and Support](#) section for assistance.

SPECIFICATIONS

Model Name: The Face Buffer PRO

Item Model Number: 30-00161

Brand: MANSCAPED

Material: Silicone

Color: Black

Power Source: Battery Powered (1 Lithium Ion battery included)

Battery Runtime: Up to 75 minutes on a single charge

Vibration Speeds: 6,000 RPMs, 9,000 RPMs

Cleansing Modes: Pad oscillation, Sonic vibrations, Combined

Waterproof: Yes

Package Dimensions: 7.8 x 6.3 x 5.63 inches

Weight: 1.26 Pounds

Manufacturer: MANSCAPED

WARRANTY AND SUPPORT

For warranty information and customer support, please visit the official [MANSCAPED website](#) or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is not a dietary supplement.

For additional information and product registration, please visit: www.manscaped.com

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video showcasing the features and benefits of The Face Buffer PRO by MANSCAPED. This video demonstrates the device's cleansing modes, silicone bristles, and overall effectiveness in a concise format.