Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Acouto 917-327

Acouto 917-327 Automatic Transmission Fluid Dipstick Tool User Manual

Brand: Acouto | **Model:** 917-327

1. Introduction

This manual provides instructions for the proper use and maintenance of your Acouto 917-327 Automatic Transmission Fluid Dipstick Tool. This professional-quality tool is designed for accurately checking automatic transmission fluid levels and quality, helping to minimize the need for costly workshop visits. Its lightweight and portable design ensures easy handling and storage.

2. Safety Information


- Always ensure the vehicle is on a level surface and the engine is at the correct operating temperature as specified by the vehicle manufacturer before checking fluid levels.
- Wear appropriate personal protective equipment, such as gloves and eye protection.
- Avoid contact with hot engine components and fluids.
- Do not leave the dipstick tool inside the dipstick tube after checking the fluid level.

3. Product Overview

The Acouto 917-327 Automatic Transmission Fluid Dipstick Tool is constructed from durable steel, ensuring stability and reliability for both commercial and occasional use. It features a red handle for easy identification.



This image shows the complete Acouto 917-327 Automatic Transmission Fluid Dipstick Tool, featuring its flexible metal cable and red handle.



This image illustrates the dimensions of the dipstick tool, showing a total length of 134 cm (52.8 inches) and a thickness of 2.4 mm (0.09 inches).

4. Setup

No assembly is required for this tool. Ensure the dipstick is clean before first use.

5. Operating Instructions

Follow these steps to accurately check your automatic transmission fluid level:

1. Ensure the vehicle is parked on a level surface and the engine is at the correct operating temperature (refer to your vehicle's service manual for specific instructions).
2. Locate the automatic transmission dipstick tube. This tool is designed to be used in conjunction with the original dealer tool specifications.
3. Carefully insert the Acouto 917-327 dipstick tool into the dipstick tube until it bottoms out. Note that for some vehicles, this tool may be longer than the dipstick tube itself; simply insert it until it reaches its maximum depth.
4. Remove the tool and check the fluid level indicated on the dipstick. The fluid level should be within the specified range for your vehicle.

5. Observe the fluid's color and condition. Healthy transmission fluid is typically red or clear and free of debris.
6. **Important:** Do not leave the dipstick tool inside the dipstick tube when you have finished checking the fluid level. Remove it completely after each use.



This image shows the Acouto 917-327 Automatic Transmission Fluid Dipstick Tool inserted into a vehicle's transmission fluid tube within an engine bay, demonstrating its application.

6. Maintenance

- After each use, wipe the dipstick tool clean with a lint-free cloth to remove any fluid residue.
- Store the tool in a clean, dry place to prevent corrosion and damage.
- Regular inspection for any signs of wear or damage is recommended.

7. Troubleshooting

- **Tool Appears Too Long:** For some vehicles, the Acouto 917-327 tool may be longer than the vehicle's dipstick tube. This is normal. Simply insert the tool until it bottoms out, then remove it to check the fluid level. Do not force the tool

beyond its natural stopping point.

- **Inaccurate Readings:** Ensure the vehicle is on a level surface and the engine is at the correct operating temperature. Verify that the tool is fully inserted and removed correctly. Consult your vehicle's service manual for specific fluid check procedures.

8. Specifications

Material	Steel
Color	Red
Manufacturer Part Number	917-327
Length	134 cm (52.8 inches)
Thickness	2.4 mm (0.09 inches)
Weight	Approx. 50g (2.29 ounces)
Package Dimensions	14.17 x 11.81 x 1.57 inches
Item Model Number	Acoutoog0n7rbxy4
ASIN	B0F71C95WM
Date First Available	April 30, 2025

9. Warranty and Support

For warranty information or technical support regarding your Acouto 917-327 Automatic Transmission Fluid Dipstick Tool, please refer to the product packaging or contact Acouto customer service directly. Always retain your proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F71C95WM

More documents and user manuals: **https://manuals.plus/**