

Motorola Edge 60 Fusion

Motorola Edge 60 Fusion 5G Smartphone User Manual

Model: Edge 60 Fusion

1. INTRODUCTION

The Motorola Edge 60 Fusion is a 5G smartphone designed for advanced mobile communication and multimedia. It features a powerful 2.5 GHz Octa-core processor, 12GB of RAM, and 256GB of internal storage, expandable via microSDXC. Running on Android 15, the device is equipped with a long-lasting 5200mAh non-removable battery. This manual provides essential information for setting up, operating, and maintaining your device.

2. WHAT'S IN THE BOX

- Motorola Edge 60 Fusion Smartphone
- USB Cable

3. PHYSICAL OVERVIEW

The Motorola Edge 60 Fusion features a sleek design with a 6.67-inch LTPO P-OLED display. The device is available in Pantone Amazonite color. Key physical components include:

- **Display:** 6.67 inches, LTPO P-OLED, 1220 x 2712 pixels.
- **Front Camera:** Located at the top center of the display.
- **Rear Camera System:** Features a 50 MP wide lens and a 32 MP ultrawide lens, accompanied by an LED flash.
- **Buttons:** Power button and volume rocker are typically located on the side.
- **Ports:** USB-C port for charging and data transfer.
- **SIM Tray:** Supports Dual-SIM functionality (physical SIM and eSIM).



Figure 1: Front and back view of the Motorola Edge 60 Fusion. The front shows the curved display with a punch-hole camera, while the back highlights the camera module and Motorola logo.



Figure 2: Front view of the Motorola Edge 60 Fusion, showcasing the edge-to-edge display and minimal bezels.



Figure 3: Back view of the Motorola Edge 60 Fusion, featuring the distinct camera island and the Motorola 'M' logo.

4. SETUP

4.1. SIM Card Installation

The Motorola Edge 60 Fusion supports Dual-SIM functionality, allowing for the use of two SIM cards (one physical SIM and one eSIM). Please ensure your network provider supports the device's frequencies (2G, 3G, 4G, 5G) before purchase.

1. Locate the SIM tray on the side of your device.
2. Insert the SIM ejector tool (not included) into the small hole on the SIM tray to open it.
3. Place your nano-SIM card(s) into the tray with the gold contacts facing down.
4. Carefully reinsert the SIM tray into the device.
5. For eSIM activation, follow the on-screen instructions during initial setup or refer to your network provider's guide.

4.2. Initial Power-On and Setup

1. Press and hold the Power button until the Motorola logo appears.
2. Follow the on-screen prompts to select your language, connect to Wi-Fi, and set up your Google account.
3. During setup, you will be guided through options for security, including fingerprint setup.

5. OPERATING YOUR DEVICE

5.1. Display and Navigation

The device features a 6.67-inch LTPO P-OLED display with a resolution of 1220 x 2712 pixels, offering vibrant colors and smooth visuals. The display supports a high refresh rate for fluid scrolling and responsiveness.

- **Touch Gestures:** Navigate the interface using intuitive touch gestures.
- **Refresh Rate:** The display's refresh rate can be adjusted in settings for smoother viewing or to conserve battery.

5.2. Performance

Powered by the Mediatek Dimensity 7300 (4 nm) Octa-core processor (4x2.5 GHz Cortex-A78 & 4x2.0 GHz Cortex-A55) and 12GB of RAM, the Motorola Edge 60 Fusion delivers smooth performance for multitasking, gaming, and demanding applications.

5.3. Camera Features

The Motorola Edge 60 Fusion is equipped with a versatile camera system:

- **Rear Camera:** 50 MP, f/1.8, (wide), 1/1.56", 1.0µm, dual pixel PDAF, OIS.
- **Ultrawide Camera:** 32 MP, f/2.2, (wide), 1/3.14", 0.7µm.
- **Front Camera:** (Specific megapixels not detailed in provided data, but typically high for Edge series).
- **Features:** LED flash, various shooting modes for different scenarios.

5.4. Battery and Charging

The device is powered by a 5200mAh non-removable battery. It supports fast charging capabilities, allowing for quick power-ups.

6. SPECIFICATIONS

Feature	Detail
Model Name	Motorola Edge 60 Fusion

Operating System	Android 15
Processor	Mediatek Dimensity 7300 (4 nm) Octa-core (4x2.5 GHz Cortex-A78 & 4x2.0 GHz Cortex-A55)
RAM	12 GB
Internal Storage	256 GB (expandable via microSDXC)
Display Size	6.67 Inches
Display Type	LTPO P-OLED
Resolution	1220 x 2712 pixels
Rear Camera	50 MP (wide, OIS), 32 MP (ultrawide)
Battery Capacity	5200 mAh
Connectivity	5G, GSM, UMTS, LTE
SIM Support	Dual-SIM (Physical SIM + eSIM)
Dimensions	6.34 x 2.87 x 0.33 inches
Color	Pantone Amazonite

7. TROUBLESHOOTING

7.1. Common Issues

- **Device Unresponsive:** Press and hold the Power button for about 10-15 seconds to force a restart.
- **Network Connectivity Issues:** Check SIM card insertion, toggle Airplane Mode on/off, or restart the device. Verify network compatibility with your carrier.
- **Battery Draining Quickly:** Adjust screen brightness, close unused apps, or check for rogue apps in Battery Usage settings.
- **App Malfunctions:** Clear the app's cache and data in Settings > Apps, or uninstall and reinstall the app.

7.2. Factory Reset

If your device experiences persistent issues, a factory reset may resolve them.**Warning:** This will erase all data from your device. Back up important data before proceeding.

1. Go to Settings > System > Reset options.
2. Select 'Erase all data (factory reset)'.
3. Confirm your choice and enter your PIN/password if prompted.
4. The device will restart and begin the reset process.

8. MAINTENANCE

- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security. Go to Settings > System > System update.
- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the device. Avoid harsh chemicals.
- **Storage Management:** Periodically clear unnecessary files and apps to free up storage space and maintain

performance.

9. WARRANTY AND SUPPORT

Your Motorola Edge 60 Fusion is covered by a manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please visit the official Motorola support website or contact their customer service. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question