



Manuals.plus /

- › eeTao /
- › eeTao USB Type C Charger Instruction Manual for enya NOVA GO Sonic BK Electric Guitar

## eeTao USB Type C Charger

# eeTao USB Type C Charger Instruction Manual

FOR ENYA NOVA GO SONIC BK ELECTRIC GUITAR AND COMPATIBLE MODELS

## 1. Introduction

Thank you for choosing the eeTao USB Type C Charger. This manual provides essential information for the safe and efficient use of your charger. This charger is designed to provide power to compatible devices, specifically the enya NOVA GO Sonic BK, NOVA GO/BK SP1, NOVA Go SP1, NOVA GO BK SP1, and NOVA GO BK Electric Guitars, which utilize a 2000mAh 7.4V 24W battery with a USB Type C input.

Please read this manual thoroughly before operating the charger and retain it for future reference.

# eeTao<sup>®</sup> AC Adapter Power Supply Compatible with:



Image 1.1: eeTao AC Adapter Power Supply compatible with various enya NOVA GO electric guitar models. The image displays two guitars in cases, a guitar strap, and the charger with its cable, indicating the charger's intended use with these instruments.

## 2. Safety Information

To ensure safe operation and prevent damage, observe the following safety precautions:

- **Input Voltage:** This charger supports a worldwide input voltage range of 100-240VAC, 50/60Hz. Ensure your power outlet matches these specifications.
- **Protection Features:** The charger is equipped with OVP (Over Voltage output Protection), OCP (Over Current output Protection), and SCP (Short Circuit output Protection) to safeguard your devices.
- **Environmental Conditions:** Do not expose the charger to water, moisture, or extreme temperatures. Use it in a dry, well-ventilated area.
- **Cable Integrity:** Do not use the charger if the cable or plug is damaged. Avoid bending or crimping the cable excessively.
- **Battery Health:** Rechargeable batteries have a limited lifespan, typically 1 to 3 years. If your device's battery is damaged or has reached the end of its life, it may not accept a charge, which is not an indication of a charger malfunction.
- **Unplug When Not in Use:** Disconnect the charger from the power outlet when not in use for extended periods.

# Security Protection

Multiple professional protection, so that fast charge more safe



Image 2.1: Diagram illustrating the security protection features of the eeTao charger, including temperature protection, short circuit protection, overcharge protection, anti-interference protection, and lightning protection, ensuring safe charging.

## 3. Package Contents

Verify that all items are present in your package:

- 1 x eeTao USB Type C Charger Unit
- 1 x Integrated USB Type C Cable

## 4. Setup

Follow these steps to set up your eeTao USB Type C Charger:

1. **Inspect the Charger:** Before use, visually inspect the charger unit and its integrated cable for any signs of damage. Do not use if damaged.
2. **Connect to Power Outlet:** Plug the charger's AC prongs into a standard wall power outlet (100-240VAC, 50/60Hz).



Image 4.1: The eeTao USB Type C Charger unit, showing the AC prongs for wall outlet connection and the integrated cable.

1. **Connect to Device:** Insert the USB Type C connector of the charger's cable into the charging port of your enya NOVA GO electric guitar or compatible device. Ensure the connection is firm.

# Premium Cable




Image 4.2: The eeTao USB Type C Charger with its integrated cable, featuring the USB Type C connector ready for device connection.

## 5. Operating Instructions

Once properly connected, the charger will begin supplying power to your device. There are no specific operational controls on the charger itself.

- **Charging Indication:** Refer to your device's user manual for information on how it indicates charging status (e.g., LED lights, screen display).
- **Charging Time:** Charging time will vary depending on the device's battery capacity and its current charge level.
- **Disconnecting:** Once your device is fully charged, or if you need to stop charging, first disconnect

the USB Type C cable from your device, then unplug the charger from the wall outlet.

## 6. Maintenance

---

Proper maintenance ensures the longevity and safe operation of your charger:

- **Cleaning:** Disconnect the charger from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and moisture when not in use. Avoid wrapping the cable too tightly around the charger.
- **Cable Care:** Do not pull on the cable to disconnect the charger. Always grasp the plug itself. Avoid placing heavy objects on the cable or exposing it to sharp edges.

## 7. Troubleshooting

---

If you encounter issues with your charger, consider the following:

- **Device Not Charging:**
  - Ensure the charger is securely plugged into a working wall outlet.
  - Verify the USB Type C cable is firmly connected to both the charger and your device.
  - Test the wall outlet with another device to confirm it has power.
  - Check your device's charging port for any obstructions or damage.
  - As noted in the safety section, if your device's internal battery is damaged or at the end of its lifespan, it may not accept a charge, which is not a fault of the charger.
- **Charger Feels Warm:** It is normal for the charger to become slightly warm during operation. If it becomes excessively hot, disconnect it immediately and contact support.
- **No Power Output:** If the charger shows no signs of life, ensure it is connected to a live power source. If the issue persists, the charger may be faulty.

## 8. Specifications

---

Feature	Specification
Brand	eeTao
Model Number	USB Type C Charger
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	5 Volts (DC)
Output Current	1 Amps
Connector Type	USB Type C
Item Weight	4 Ounces
Item Dimensions (L x W x H)	3 x 3 x 1 inches



Image 8.1: The label on the eeTao AC/DC Adapter, displaying input and output specifications, model information, and safety certifications.

## 9. Warranty and Support

eeTao stands behind the quality of its products:

- **Refund Policy:** Enjoy a 30-day refund period from the date of purchase.
- **Exchange Policy:** A 24-month satisfaction exchange warranty is provided for this product.

For warranty claims, technical assistance, or any questions regarding your eeTao USB Type C Charger, please refer to the retailer's support channels or visit the official eeTao store page for contact information.

Thank you for your purchase.