



Manuals.plus /

› Silonn /

› Silonn Ice Maker Countertop User Manual

Silonn Ice Cube Maker

Silonn Ice Maker Countertop User Manual

Model: Ice Cube Maker | Brand: Silonn

1. INTRODUCTION

Thank you for choosing the Silonn Ice Maker Countertop. This appliance is designed to produce crystal-clear, slow-melting ice cubes efficiently for your home, office, bar, or party needs. With its dual water fill options, high-speed production, and self-cleaning function, it offers convenience and a continuous supply of ice. Please read this manual thoroughly before operation to ensure safe and proper use, and to maximize the lifespan of your ice maker.

2. SAFETY INSTRUCTIONS

To prevent injury or damage, always follow basic safety precautions when using electrical appliances. This includes, but is not limited to:

- Ensure the power outlet voltage matches the appliance's requirements.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug from the outlet when not in use, before cleaning, or if a malfunction occurs.
- Keep the appliance away from heat sources and direct sunlight.
- Do not operate with a damaged cord or plug.
- Only use potable water in the ice maker.
- Keep children and pets away from the appliance during operation.
- Allow the unit to sit upright for at least 24 hours after transport or unpacking before plugging it in. This allows the compressor oil to settle, preventing potential damage.

3. PRODUCT OVERVIEW

The Silonn Ice Maker Countertop is a compact and efficient appliance designed for convenient ice production. Key components include the ice basket, ice scoop, water reservoir, and control panel.



The Silonn Ice Maker Countertop in its sleek stainless steel finish, ready to produce ice.

WHY CHOOSE CUBED ICE?



Crystal
Clear



Larger
& Thicker



Melts
Slower



The ice maker produces crystal-clear, larger, and thicker ice cubes that melt slower, ideal for various beverages.

COMPACT DIMENSIONS



Compact dimensions (13.78"D x 9.53"W x 14.57"H) allow the ice maker to fit in tight spaces.

Key Features:

- **Crystal-Clear, Slow-Melting Cubes:** Produces premium ice cubes with zero cloudiness or odors, designed for minimal drink dilution.
- **Dual Water Fill Options:** Offers direct 3.0L reservoir filling or the option to attach a water bottle (not included) to the top inlet.
- **High-Speed Ice Production:** Capable of producing 24 cubes in 13 minutes, with a daily output of up to 44 lbs.

- **Effortless Self-Cleaning:** Features a 1-touch 20-minute cleaning cycle to remove mineral buildup and ensure hygienic ice.
- **Compact Design:** Space-saving dimensions make it suitable for various environments.
- **Automatic Overflow Prevention:** Ensures continuous operation without spills.

4. SETUP

4.1 Unpacking and Placement

Carefully remove the ice maker from its packaging. Place the unit on a flat, stable surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the appliance. Allow the ice maker to stand upright for at least 24 hours before plugging it in to allow the refrigerant and compressor oil to settle.

4.2 Initial Cleaning

Before first use, it is recommended to clean the interior of the ice maker. Use a soft cloth with mild detergent and warm water to wipe down the ice basket and water reservoir. Rinse thoroughly and dry. The self-cleaning function can also be used for initial cleaning.

4.3 Water Filling Options

2 WAYS TO ADD WATER



1 Water
Bottle

2 Manual
Water Fill



Water bottle is not included.

The ice maker supports two convenient ways to add water: directly pouring into the reservoir or attaching a water bottle.

- **Manual Fill:** Open the top lid and pour potable water directly into the 3.0L water reservoir up to the MAX fill line.
- **Water Bottle Attachment:** Place a compatible water bottle (not included) onto the top inlet for automatic water supply.

Do not overfill the reservoir. Use filtered or distilled water for best ice quality and to minimize mineral buildup.

5. OPERATING INSTRUCTIONS



The Silonn Ice Maker provides a continuous ice supply, producing up to 44 lbs per day, suitable for gatherings.

1. Ensure the unit is plugged into a grounded electrical outlet.
2. Add water to the reservoir using one of the methods described in Section 4.3.
3. Press the "ON/OFF" button on the control panel to start the ice making cycle.
4. The ice maker will automatically begin producing ice. The first batch may take slightly longer.
5. When the ice basket is full, the "ICE FULL" indicator will illuminate, and the machine will pause. Remove ice to resume production.

6. If the water level is low, the "ADD WATER" indicator will illuminate. Add more water to continue.

5.2 Controlling Ice Thickness

CONTROL ICE THICKNESS



Ice Thickness	Production Time	Recommended Use
Thin	11 Mins	Blend Smoothies
Medium	15 Mins	Preserve Food
Thick	20 Mins	Chill Drinks



Customize ice cube thickness with two available settings, influencing production time and cube density.

The Silonn Ice Maker offers two settings to customize ice cube thickness:

- **Thin Ice:** Approximately 11 minutes per batch, suitable for smoothies and ice cream.
- **Thick Ice:** Approximately 20 minutes per batch, ideal for chilling drinks and cocktails.

Refer to the control panel for specific buttons to adjust the ice thickness setting.

6. MAINTENANCE

6.1 Self-Cleaning Function



The self-cleaning function circulates water to remove mineral buildup, ensuring hygienic ice.

The ice maker features an effortless self-cleaning cycle:

1. Ensure the water reservoir is filled with clean water.
2. Activate the 1-touch 20-minute cleaning cycle (refer to your control panel for the specific button).
3. The machine will automatically clean its internal components.
4. After the cycle, drain any remaining water and wipe the interior dry.

Regular use of the self-cleaning function helps remove mineral buildup, prevents odors, and extends the lifespan of your ice machine.

6.2 General Cleaning and Storage

- Always unplug the unit before cleaning.
- Clean the exterior with a soft, damp cloth. Avoid abrasive cleaners.
- Periodically clean the ice basket and water reservoir with a mild detergent and warm water.
- If storing the ice maker for an extended period, drain all water, clean thoroughly, and ensure it is completely dry before storing in a cool, dry place.

7. TROUBLESHOOTING

If you encounter issues with your Silonn Ice Maker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
"ADD WATER" indicator on	Water reservoir is empty or low.	Add potable water to the reservoir up to the MAX fill line.
"ICE FULL" indicator on	Ice basket is full.	Remove ice from the basket. The machine will resume production.
Ice not forming or poor quality ice	Insufficient water, high ambient temperature, or dirty unit.	Ensure adequate water. Operate in a cooler environment. Perform a self-cleaning cycle.
Unusual noise during operation	Normal compressor operation or unit not level.	Ensure the unit is on a flat, stable surface. If noise persists or is excessive, contact customer support.

For more detailed troubleshooting or issues not listed here, please refer to the full user manual available for download or contact Silonn customer support.

8. SPECIFICATIONS

Technical specifications for the Silonn Ice Maker Countertop:

Specification	Detail
Product Dimensions	13.78"D x 9.53"W x 14.57"H
Item Model Number	Ice Cube Maker
Capacity	3 Liters (Water Reservoir)
Voltage	120 Volts
Manufacturer	Silonn

9. WHAT'S IN THE BOX

Upon unpacking your Silonn Ice Maker, you should find the following items:

- Silonn Ice Maker Unit
- Portable Ice Basket
- Ice Scoop

10. WARRANTY AND SUPPORT

Silonn products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Silonn website. If you experience any issues or require technical assistance, please contact Silonn customer support. Protection plans are also available for extended coverage.