

[Manuals.plus](#) /

› [Curtis Stone](#) /

› Curtis Stone Dry Grain Dispenser Instruction Manual

## Curtis Stone Dry Grain Dispenser

# Curtis Stone Dry Grain Dispenser Instruction Manual

Model: Dry Grain Dispenser

## INTRODUCTION

---

This manual provides instructions for the safe and efficient use of your Curtis Stone Dry Grain Dispenser. This dispenser is designed for storing and dispensing various dry food items such as grains, nuts, beans, and more. Please read these instructions carefully before first use and retain them for future reference.

## PRODUCT OVERVIEW

---

The Curtis Stone Dry Grain Dispenser features six individual compartments for organized storage of different dry ingredients. Its transparent design allows for easy monitoring of contents, and the 360-degree rotation provides convenient access to all compartments.



Image: The Curtis Stone Dry Grain Dispenser, illustrating its compact, cylindrical design with clear compartments for various dry goods.

## SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts are present.
2. **Cleaning:** Before first use, hand wash all removable parts with warm, soapy water. Rinse thoroughly and dry completely. Refer to the "Maintenance" section for detailed cleaning instructions.
3. **Assembly:** Place the main dispenser unit on a stable, flat surface. Ensure the dispensing drawer is correctly inserted at the bottom.
4. **Filling Compartments:**
  - Remove the top lid of the dispenser.
  - Carefully pour your desired dry ingredients into each of the six separate compartments. Avoid overfilling.
  - Replace the lid securely.

## SUITABLE FOR STORAGE IN THE CURTIS STONE DRY GRAIN DISPENSER

Centralized, categorized storage for up to 6 varieties of dry goods.

### GRAINS



✓ RICE



✓ POPCORN



✓ QUINOA



✓ STEEL CUT OATS



✓ BARLEY

### SMALL DRIED BEANS



✓ BLACK EYED PEAS



✓ BLACK BEANS



✓ SPLIT PEAS



✓ LENTILS,  
ANY COLOR



✓ WHOLE BEAN  
COFFEE



✓ GROUND  
COFFEE



✓ NAVY BEANS



✓ RED ADZUKI  
BEANS

### ...AND MORE!



✓ COUSCOUS



✓ GRANULATED  
SUGAR



Image: A visual guide indicating various dry goods suitable for storage in the dispenser, such as grains, small dried beans, and other items like couscous and granulated sugar.

## OPERATING INSTRUCTIONS

- Selecting a Compartment:** Rotate the dispenser to align the desired ingredient compartment with the dispensing button. The 360-degree rotation feature allows easy access to all compartments.
- Dispensing Ingredients:**
  - Ensure the dispensing drawer is empty and properly inserted.
  - Press the large push button located below the selected compartment.
  - Hold the button until the desired amount of ingredient is dispensed into the drawer.
  - Release the button to stop dispensing.
- Removing Dispensed Ingredients:** Carefully pull out the dispensing drawer to retrieve the ingredients.
- Refilling:** Monitor the transparent compartments. When an ingredient level is low, remove the top lid and refill the specific compartment as needed.



Image: A detailed view of the dispensing mechanism, highlighting the push button and the clear collection drawer with measurement markings.

## MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your dispenser.

1. **Emptying:** Before cleaning, ensure all compartments are empty.
2. **Disassembly:** Remove the top lid and the dispensing drawer.
3. **Washing: Hand Wash Only.** Wash all removable parts with warm, soapy water. Use a soft sponge or cloth. Do not use abrasive cleaners or scrubbers.

4. **Rinsing:** Rinse all parts thoroughly under running water to remove any soap residue.
5. **Drying:** Allow all parts to air dry completely before reassembling or refilling. Ensure no moisture remains, especially in the dispensing mechanism, to prevent clumping of dry goods.
6. **Exterior Cleaning:** Wipe the exterior of the main unit with a damp cloth.

**Important:** Do not immerse the main unit in water. The item is not microwaveable.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Ingredients do not dispense when button is pressed.	<ul style="list-style-type: none"> <li>• Ingredient is clumping or stuck.</li> <li>• Button not pressed firmly enough.</li> <li>• Dispensing mechanism is blocked.</li> <li>• Ingredient type is not suitable (e.g., too fine, too sticky).</li> </ul>	<ul style="list-style-type: none"> <li>• Ensure ingredients are dry and free-flowing. Gently shake the dispenser to loosen contents.</li> <li>• Press the button firmly and hold it down completely.</li> <li>• Empty the compartment and inspect the dispensing mechanism for any blockages. Clean if necessary.</li> <li>• Refer to the "Product Overview" or "Setup" section for suitable ingredient types.</li> </ul>
Dispenser does not rotate smoothly.	<ul style="list-style-type: none"> <li>• Debris under the base.</li> <li>• Uneven surface.</li> </ul>	<ul style="list-style-type: none"> <li>• Lift the dispenser and clean any debris from under the base.</li> <li>• Place the dispenser on a flat, stable surface.</li> </ul>

## SPECIFICATIONS

Feature	Detail
Brand	Curtis Stone
Model	Dry Grain Dispenser
Color	White
Material	Plastic
Recommended Uses	Dry foods, dry ingredients (e.g., rice, sugar, nuts, beans, lentils, quinoa)
Special Features	Large, Easy-to-Push Buttons, 360-Degree Rotation, 6-compartment design
Closure Type	Push Button
Item Weight	4 Pounds
Unit Count	6.0 Count (referring to compartments)
Product Care Instructions	Hand Wash Only
Microwave Safe	No
Container Shape	Rectangular (individual compartments within the cylindrical unit)
UPC	606582504129

Feature	Detail
ASIN	B0F76WWQJQ

## WARRANTY AND SUPPORT

---

This Curtis Stone Dry Grain Dispenser (Renewed) comes with a **1-Year Refurbished Warranty**. For warranty claims or technical support, please contact the retailer or manufacturer directly. Keep your proof of purchase for warranty validation.

