

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sona](#) /

› [Sona 16-inch Remote DC Wall Fan SFW 9518DC User Manual](#)

## Sona SFW 9518DC

# Sona 16-inch Remote DC Wall Fan SFW 9518DC User Manual

Model: SFW 9518DC

## INTRODUCTION

---

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your Sona 16-inch Remote DC Wall Fan, model SFW 9518DC. Please read this manual thoroughly before using the appliance and retain it for future reference.

## SAFETY INSTRUCTIONS

---

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the power supply voltage matches the fan's requirements (100-240V~ 50/60Hz).
- Do not insert fingers or any objects into the fan grille when it is operating.
- Unplug the fan from the power outlet before cleaning or performing any maintenance.
- Do not use the fan in wet or damp environments.
- Keep the fan away from curtains, drapes, or any objects that may be drawn into the fan.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

## PRODUCT OVERVIEW

---

The Sona SFW 9518DC is a 16-inch remote-controlled DC wall fan designed for efficient air circulation. It features a brushless DC motor, 10 speed selections, 3 wind modes, and a 7-hour timer.

# Breeze

## Made For Everyone



30W Brushless  
DC Motor




Memory  
Function



Break Resistant  
ABS Fan Blade



2 Ways  
Installation



16" Remote DC Wall Fan SFW 9518DC



Figure 1: Overview of the Sona 16-inch Remote DC Wall Fan SFW 9518DC. This image displays the complete fan unit, highlighting its sleek design and wall-mounted configuration.

### Key Features:

- Brushless DC Motor for energy efficiency and quiet operation.
- 10 Speed Selection for precise airflow control.

- 3 Wind Modes: Normal, Natural, and Sleep.
- 7-Hour Timer for automatic shut-off.
- Memory Function to recall last settings.
- Wide Angle Left-Right Oscillation.
- Adjustable Neck for Up-Down Tilting Adjustment.
- 5 Bladed Break Resistant ABS Fan Blade.
- Infra-Red Remote Control for convenient operation.
- Two-way Installation Bracket.


## SETUP AND INSTALLATION

---

The SFW 9518DC fan offers flexible installation options. Ensure you have all parts (fan components, remote) before beginning.

# 2-Ways

## Installation



**Given 2 Options On The Style Of Installation.  
Choose Which Is Best For You!**

*Figure 2: Illustration of the two-way installation bracket. This image shows two distinct bracket designs, offering flexibility for mounting the fan to a wall.*

### **Installation Steps:**

1. **Choose Location:** Select a suitable wall location, ensuring it is sturdy enough to support the fan's weight and has access to a power outlet.
2. **Mount Bracket:** Securely attach the chosen installation bracket to the wall using appropriate screws

and anchors (not included). Refer to Figure 2 for bracket options.

3. **Assemble Fan:** Follow the assembly instructions provided with the fan parts to connect the motor unit, fan blades, and grilles. Ensure the 5-bladed ABS fan blade is securely attached.
4. **Attach Fan to Bracket:** Carefully mount the assembled fan unit onto the installed wall bracket. Ensure it is firmly locked in place.
5. **Connect Power:** Plug the fan's power cord into a suitable electrical outlet (100-240V~ 50/60Hz).

## OPERATING INSTRUCTIONS

---

Your Sona wall fan can be operated using the included infra-red remote control.

### Remote Control Functions:

- **Power On/Off:** Press the power button to turn the fan on or off.
- **Speed Selection:** Adjust fan speed from 1 to 10.
- **Mode Selection:** Cycle through Normal, Natural, and Sleep wind modes.
- **Timer:** Set the fan to operate for up to 7 hours before automatically shutting off.
- **Oscillation:** Activate or deactivate wide-angle left-right oscillation.

# Wind Levels To Choose From

**Speed 1-2:  
Ventilation**


**Speed 3-4:  
Gentle Breezes**

**Speed 5-7:  
Windy Coast Side**

**Speed 8-10:  
Extremely Powerful**



**Enjoy Breezes Along With  
3 Wind Mode Options!**



*Figure 3: Visual representation of the 10 wind speed levels. This graphic categorizes speeds into Ventilation (1-2), Gentle Breezes (3-4), Windy Coast Side (5-7), and Extremely Powerful (8-10), illustrating the fan's versatility.*

## **Wind Modes Explained:**

- **Normal Mode:** Provides a constant airflow at the selected speed.
- **Natural Mode:** Simulates natural breezes by varying the fan speed intermittently.

- **Sleep Mode:** Operates at a lower, quieter speed, often gradually decreasing over time for comfortable sleep.




# Memo- rised

## The Last Settings



Memory  
Function



**Turn Off Your Fan From Which Ever Wind Level  
And Turn It Back On To The Same Wind Level!**

Figure 4: Depiction of the fan's memory function. This image highlights the fan's ability to recall the last used wind level and settings upon restart.

The fan's **Memory Function** (Figure 4) ensures that when you turn the fan off and then back on, it will resume operation at the last selected wind level and mode.

# More Traits To Enjoy!



Horizontal Oscillation



Vertical Neck Adjustment



Enjoy Its 7 Hours Timer, A Fan For Deep Sleep!



Figure 5: Features including horizontal oscillation, vertical neck adjustment, and 7-hour timer. This graphic illustrates how the fan can distribute air widely and be angled for optimal comfort, along with its timed operation capability.

Utilize the **Wide Angle Left-Right Oscillation** for broader air distribution and adjust the fan head with the **Adjustable Neck for Up-Down Tilting Adjustment** to direct airflow precisely (Figure 5).

## MAINTENANCE

---

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Sona wall fan.

### **Cleaning Instructions:**

1. **Disconnect Power:** Always unplug the fan from the power outlet before cleaning.
2. **Clean Exterior:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
3. **Clean Grilles and Blades:** The front grille can be removed for easier access to the fan blades. Carefully wipe the blades and grilles to remove dust accumulation. Ensure the 5-bladed break-resistant ABS fan blade is handled with care during cleaning.
4. **Reassemble:** Ensure all parts are dry before reassembling the fan and plugging it back in.

# Durable

## Break Resistant



*Figure 6: Close-up of the durable, break-resistant ABS fan blade. This image emphasizes the robust construction of the fan blades, designed for longevity and safety.*

## **TROUBLESHOOTING**

If you encounter issues with your Sona wall fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; remote control battery depleted.	Check if the fan is plugged in and the outlet is functional. Replace remote control batteries.
Weak airflow.	Fan speed set too low; grilles or blades are dirty.	Increase fan speed. Clean the fan grilles and blades as per maintenance instructions.
Fan makes unusual noise.	Loose parts; obstruction in blades.	Ensure all parts are securely assembled. Disconnect power and check for any obstructions around the blades.
Remote control not working.	Depleted batteries; obstruction between remote and fan sensor.	Replace remote control batteries. Ensure a clear line of sight to the fan's IR receiver.

## SPECIFICATIONS

Detailed technical specifications for the Sona SFW 9518DC wall fan:

Feature	Detail
Model	SFW 9518DC
Voltage	100-240V~
Frequency	50/60Hz
Wattage	30 watts
Motor Type	Brushless DC Motor
Speed Selection	10 Speeds
Wind Modes	Normal, Natural, Sleep
Timer	Up to 7 Hours
Oscillation	Wide Angle Left-Right
Tilting Adjustment	Adjustable Neck for Up-Down
Fan Blade Material	5 Bladed Break Resistant ABS
Control Type	Infra-Red Remote Control
Mounting Type	Wall Mount (Two-way bracket)
Product Dimensions	28D x 45W x 55H centimetres

Feature	Detail
Material	Plastic
Color	Grey

## WARRANTY

---

The Sona SFW 9518DC wall fan comes with a **3 Years Warranty on the Main Motor** from the date of purchase. Please retain your proof of purchase for warranty claims. This warranty covers manufacturing defects in the main motor under normal use conditions. It does not cover damage resulting from misuse, accidents, unauthorized repairs, or normal wear and tear.

## CUSTOMER SUPPORT

---

For further assistance, technical support, or warranty inquiries, please contact Sona customer service. Refer to the product packaging or the official Sona website for contact details.

*Please have your model number (SFW 9518DC) and proof of purchase ready when contacting support.*

© 2025 Sona. All rights reserved.

This manual is subject to change without prior notice.