

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [realme](#) /

› [Realme Air 7 True Wireless Earbuds User Manual](#)

realme Air 7

Realme Air 7 True Wireless Earbuds User Manual

Model: Air 7 (RMA7PADRE)

INTRODUCTION

Thank you for choosing the Realme Air 7 True Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

WHAT'S IN THE BOX

The Realme Air 7 package includes the following items:

- Realme Air 7 True Wireless Earbuds
- Wireless Charging Case
- USB Charging Cable
- Eartips (various sizes)
- User Manual



Image: Realme Air 7 True Wireless Earbuds inside their charging case, showcasing the Ivory Gold color.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. The charging case can be charged via a USB-C cable.

1. Connect the USB charging cable to the charging port on the case and to a power source.
2. The indicator light on the case will show charging status.
3. Place the earbuds into the charging case. They will begin charging automatically.

A 10-minute charge can provide approximately 7 hours of music playback. A full charge provides up to

40 hours of total playback with the charging case.



Image: The Realme Air 7 charging case, displaying the realme logo on its lid.

2. Bluetooth Pairing

To connect your Realme Air 7 earbuds to a device:

1. Ensure the earbuds are in the charging case and the case lid is open.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Realme Air 7" in the list of available Bluetooth devices.
4. Select "Realme Air 7" to pair. A voice prompt will confirm successful connection.

The earbuds use Bluetooth 5.3 for a stable connection up to 10 meters.

OPERATING INSTRUCTIONS

The Realme Air 7 earbuds feature touch controls for easy management of audio and calls.

Touch Controls

Refer to the following common touch gestures:

- **Single Tap:** Play/Pause music, Answer/End call.
- **Double Tap:** Skip to next track.
- **Triple Tap:** Go to previous track.
- **Long Press (Left Earbud):** Activate/Deactivate Active Noise Cancellation (ANC) or Transparency Mode.

- **Long Press (Right Earbud):** Activate/Deactivate Game Mode.



Image: Close-up view of the Realme Air 7 earbuds, highlighting their design and touch-sensitive areas.

Active Noise Cancellation (ANC)

The Realme Air 7 features 52dB Active Noise Cancellation, reducing up to 98.5% of ambient noise. Long press the left earbud to cycle through ANC modes (ANC On, Transparency Mode, ANC Off).

Game Mode

Activate Game Mode by long pressing the right earbud to achieve an ultra-low latency of 55ms, enhancing audio-video synchronization for gaming.

MAINTENANCE

Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the eartips and speaker mesh using a small, soft brush or cotton swab.

Water Resistance

The earbuds are rated IP55 for water and dust resistance. This means they are protected against limited dust ingress and low-pressure water jets from any direction. They are not designed for swimming or showering. Avoid exposing them to excessive moisture or submerging them in water.

Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged.

TROUBLESHOOTING

If you encounter issues with your Realme Air 7 earbuds, try the following solutions:

- **Earbuds not pairing:**
 - Ensure both earbuds are charged.
 - Place earbuds back in the case, close the lid, then open it again to re-enter pairing mode.
 - Turn off and on Bluetooth on your device.
 - Forget "Realme Air 7" from your device's Bluetooth list and re-pair.
- **No sound from one earbud:**
 - Check if both earbuds are charged.
 - Clean the charging contacts on both the earbuds and the case.
 - Try resetting the earbuds (refer to the full user manual for specific reset instructions if needed).
- **Charging issues:**
 - Ensure the charging cable is securely connected.
 - Try a different USB-C cable and power adapter.
 - Clean the charging port on the case.
- **Poor sound quality:**
 - Ensure earbuds are properly seated in your ears and eartips are the correct size.
 - Clean the speaker mesh.
 - Move closer to your connected device to avoid interference.

For further assistance, please visit the official [realme support website](#).

SPECIFICATIONS

Feature	Detail
Model Name	Air 7
Item Model Number	RMA7PADRE
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	10 Meters
Audio Driver Size	12.4 Millimeters (Dynamic Driver)
Noise Control	Active Noise Cancellation (52dB)
Battery Life (Total)	Up to 40 Hours (with charging case)
Quick Charge	10 minutes charge for 7 hours playback

Water Resistance Level	IP55
Item Weight	130 Grams (total) / 4.6 ounces
Product Dimensions	0.39 x 0.39 x 0.39 inches (earbud, approximate)
Included Components	Cable, Eartip, User Manual, Wireless Charging Case

WARRANTY AND SUPPORT

Realme products are covered by a limited warranty. Please refer to the warranty card included in your package or visit the official realme website for detailed warranty terms and conditions.

For technical support, product registration, or frequently asked questions, please visit the official realme support page:

[realme Official Support](#)

You can also find additional resources and contact information on the realme store page on Amazon:

[realme Store on Amazon](#)