AEDNX adfqad1692

AEDNX 10x10/10x12 Gazebo User Manual

Model: adfqad1692

1. Product Overview

The AEDNX 10x10/10x12 Gazebo is designed to provide a comfortable and versatile outdoor space for various activities. Featuring a double-layer ventilated roof, it offers protection from strong light, rain, and snow, while ensuring stable support. The gazebo includes four-sided rolling shutters with detachable curtains and mesh for customizable protection and ventilation.



Figure 1.1: The AEDNX 10x10 Gazebo installed in an outdoor patio area, showcasing its double roof and privacy curtains.



Figure 1.2: A front view of the gazebo, highlighting its spacious interior and the ability to tie back the curtains for an open feel.

2. Safety Information

- Always assemble the gazebo on a flat, stable surface.
- Ensure all connections are securely fastened before use.
- Do not use the gazebo in extreme weather conditions such as strong winds, heavy rain, or snow accumulation. While designed for stability, severe weather can cause damage or injury.
- Keep open flames or heat sources away from the gazebo fabric.
- Regularly inspect the frame and fabric for any signs of wear or damage.
- Adult assembly is required. Keep children away during the assembly process.

3. Parts List

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Part No.	Description	Quantity
A	Main Frame Poles	X pcs
B	Roof Support Beams	X pcs
C	Double Roof Canopy Fabric	1 set
D	Privacy Curtains	4 pcs
E	Mosquito Netting	4 pcs
F	Hardware Kit (screws, bolts, anchors)	1 set
G	Assembly Tools (wrench, hex key)	1 set

Note: "X pcs" indicates the exact quantity will vary based on the specific 10x10 or 10x12 model. Refer to the packing list included with your product for precise counts.

4. Setup and Assembly

Assembly typically requires two or more adults. Follow these steps carefully for proper installation.

4.1 Frame Assembly

1. Unpack all components and lay them out on a clean, flat surface.
2. Identify the main frame poles (Part A) and connect them according to the diagram in your separate assembly guide. Ensure all connections are secure.
3. Attach the roof support beams (Part B) to the top of the main frame, creating the basic structure for the roof.



Figure 4.1: Illustration of the durable reinforced structure, highlighting key connection points and components like thickened poles and arched crossbars for stability during assembly.

4.2 Canopy and Curtain Installation

4. Carefully unfold the double roof canopy fabric (Part C) and drape it over the assembled roof frame. Align the corners and secure it to the frame as per the specific instructions in your assembly manual.
5. Attach the privacy curtains (Part D) and mosquito netting (Part E) to the dual-track system on the gazebo frame. Ensure they can slide freely.



Figure 4.2: Detail of the dual-track system, allowing independent operation of the curtains and netting.



Figure 4.3: Features of the durable curtains and netting, showing the UV-resistant fabric, fine mesh to prevent bugs, convenient tie ropes, and dual-sided zippers for easy access.

4.3 Securing the Gazebo

6. Once the frame and canopy are assembled, use the provided hardware kit (Part F) to anchor the gazebo securely to the ground. This is crucial for stability, especially in windy conditions.

5. Operating Instructions

The AEDNX Gazebo offers flexible configurations to suit your needs and weather conditions.

5.1 Dual-Roof Ventilation

The double-layer ventilated roof is designed to increase air circulation and enhance stability. It allows hot air to escape,

keeping the interior cooler, and provides resistance against light rain and sun.



Figure 5.1: The ventilated dual-roof design, showing how it promotes airflow and offers protection from drizzle, fading, and sun.

5.2 Curtain and Netting Modes

The gazebo features a dual-track system for independent operation of the curtains and netting, allowing for three primary modes:

- **Good Ventilation (All Open):** Tie back both the curtains and netting to enjoy an unobstructed outdoor view and maximum airflow.
- **Anti-Mosquito (Open Netting):** Close the mosquito netting while tying back the curtains to block disturbing bugs while maintaining ventilation.
- **Sun Shade / Privacy (Open Curtains):**Close the privacy curtains to protect from direct sunlight or for enhanced privacy. The netting can be tied back or closed as desired.



Figure 5.2: Visual representation of the three adjustable modes for the gazebo's curtains and netting.

6. Maintenance

- **Cleaning Fabric:** Clean the canopy, curtains, and netting with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Rinse thoroughly and allow to air dry completely before folding or storing.
- **Frame Care:** Wipe down the metal frame with a damp cloth to remove dirt and debris. Inspect the powder coating for any chips or scratches and touch up if necessary to prevent rust.
- **Hardware Check:** Periodically check all bolts, screws, and anchors to ensure they remain tight. Re-tighten as needed.
- **Winter Storage:** In areas with heavy snow or prolonged freezing temperatures, it is recommended to disassemble and store the gazebo indoors to prolong its lifespan.

7. Troubleshooting

Problem	Possible Cause	Solution
Gazebo feels unstable.	Loose connections; insufficient anchoring.	Ensure all frame connections are tight. Verify ground anchors are properly installed and secure. Consider additional weights if needed.
Water pooling on the roof.	Improper canopy tension; heavy rainfall.	Adjust canopy tension to ensure proper slope for water runoff. Clear any debris from the roof.
Curtains/netting not sliding smoothly.	Debris in tracks; bent tracks.	Clean tracks of any dirt or leaves. Gently straighten any minor bends in the tracks.
Fabric tearing or fraying.	Exposure to sharp objects; prolonged sun exposure; strong winds.	Avoid contact with sharp objects. Consider using a protective cover when not in use for extended periods. Repair small tears with fabric repair kits or replace damaged sections if severe.

8. Specifications

Brand: AEDNX

Model Number: adfqad1692

Product Dimensions: 141.73"L x 116.14"W x 116.14"H (for 10x12 model)

Item Weight: 96.8 Pounds

Frame Material: Metal+Wood (Powder coated aluminum frame)

Roof Material: Galvanized Steel (as per feature bullets, though specifications say Canvas for Material)

Canopy Material: Canvas

Water Resistance Level: Waterproof

Assembly Required: Yes

Color: Gray

Country of Origin: China



Figure 8.1: Detailed dimensions for the 10x10FT Patio Gazebo model.

9. Warranty and Support

For warranty information, product support, or to order replacement parts, please contact AEDNX customer service. Refer to your purchase documentation for specific warranty terms and contact details.

Customer Service: Please visit the AEDNX Store on Amazon or refer to the contact information provided in your product packaging.

Online Resources: For additional tips and FAQs, you may visit the official AEDNX brand store: AEDNX Store

© 2024 AEDNX. All rights reserved.