

NutriBullet NBF550DG

NutriBullet SmartSense Blender Combo NBF550DG Instruction Manual

Model: NBF550DG

1. IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions before operating this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the blender from the power outlet before cleaning or when not in use.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the blending pitcher while blending to reduce the risk of severe personal injury.
- Ensure the lid is securely locked in place before operating the blender.
- Do not blend hot liquids in sealed cups as pressure buildup can cause the cup to burst. Use the vented pitcher lid for hot ingredients.
- Avoid contact with moving parts.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. WHAT'S INCLUDED

Your NutriBullet SmartSense Blender Combo NBF550DG package includes the following components:


- 1500-Watt Motor Base
- 1.8 Liter Blending Pitcher with Integrated Stainless Steel Blades
- Vented Pitcher Lid with Pour Spout
- 900ml Personal Blending Cup
- 700ml Personal Blending Cup with Handle
- 2 Travel Lids for Personal Cups

- Tamper

Qu'y a-t-il dans la boîte:



Base moteur
de 1500 watts



Tasse de 900ml
et tasse avec
anse de 700 ml



Bol de 1.8L



2 couvercles
de voyage



Couvercle de bol
avec bec verseur



Poussoir



Lames d'extraction
en acier inoxydable

This image illustrates all the components included with your NutriBullet SmartSense Blender Combo, ensuring you have everything needed to get started.

3. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the pitcher, personal cups, lids, and tamper with warm, soapy water before first use. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Placement:** Place the motor base on a clean, dry, and level surface. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Plug the power cord into a standard electrical outlet.

**Base
moteur de
1500 watts.**



nutribullet.



The powerful 1500-watt motor base provides robust performance for all blending needs, from crushing ice to pulverizing tough ingredients.

4. OPERATING INSTRUCTIONS

The NutriBullet SmartSense Blender Combo offers versatile blending options with its intuitive digital interface, 5 variable speeds, Pulse function, and Smart Auto Cycle.

4.1. Using the Pitcher

1. **Add Ingredients:** Place your desired ingredients into the 1.8L blending pitcher. Do not exceed the MAX fill line.
2. **Secure Lid:** Place the vented pitcher lid onto the pitcher and twist clockwise until it locks securely. Ensure the pour spout is closed.
3. **Place on Base:** Carefully place the pitcher onto the motor base, aligning the pitcher handle with the handle icon on the base. Twist clockwise to lock it into place.
4. **Select Function:**
 - **Smart Auto Cycle:** Press the 'AUTO' button. The blender will intelligently detect the ingredients and adjust blending speed and time automatically.

- **Variable Speeds:** Use the '+' and '-' buttons to select one of the 5 available speeds (1-5).
- **Pulse Function:** Press and hold the 'PULSE' button for short bursts of power. Release to stop.

5. **Start Blending:** Press the power button or selected function button to begin.
6. **Stop Blending:** Press the power button again or wait for the automatic cycle to complete.
7. **Remove:** Twist the pitcher counter-clockwise to unlock and lift it from the base.

Mixez en
grande
quantité.
5 vitesses.
Cycle
automatique
intelligent.

nutribullet.




The NutriBullet SmartSense Blender Combo, featuring a large 1.8L pitcher and a personal blending cup, is designed for versatile blending. It offers 5 variable speeds and an intelligent automatic cycle for efficient food preparation.

**Le cycle
automatique
détecte la
quantité et
s'ajuste aux
ingrédients.**



nutribullet.



The SmartSense blender features an automatic cycle that intelligently detects the quantity and consistency of ingredients, adjusting blending speed and time for optimal results.

**5 vitesses
et touche
Pulse pour
plus de
polyvalence
et de contrôle.**



nutribullet.



The control panel offers 5 variable speeds and a dedicated Pulse function, providing precise control and versatility for different blending tasks.

Interface
intuitive
avec affichage
digital.



nutribullet.



The blender features an intuitive digital interface, making it easy to select settings and monitor blending progress.

4.2. Using Personal Cups

1. **Add Ingredients:** Fill the personal cup with your ingredients. Do not exceed the MAX fill line.
2. **Attach Blade:** Screw the extraction blade assembly onto the personal cup until securely tightened.
3. **Place on Base:** Invert the cup and place it onto the motor base, aligning the tabs. Twist clockwise to activate the blending cycle.
4. **Blend:** The blender will start automatically. Blend until desired consistency is reached.
5. **Stop Blending:** Twist the cup counter-clockwise to disengage and stop blending.
6. **Remove:** Lift the cup from the base. Unscrew the blade assembly and replace with a travel lid if desired.

2 tasses
à emporter
pour des
préparations
individuelles.



nutribullet.



Included are two personal blending cups (900ml and 700ml) with travel lids, perfect for individual servings and on-the-go convenience.

4.3. Versatile Preparations

The NutriBullet SmartSense Blender is designed for a wide range of culinary tasks:

- **Smoothies & Shakes:** Blend fruits, vegetables, and liquids for nutritious drinks.
- **Soups & Sauces:** Create creamy soups (use vented lid for hot liquids) and smooth sauces.
- **Nut Butters:** Process nuts into smooth or chunky nut butters using speeds 3-4.
- **Flours:** Grind grains into fine flours using lower speeds (1-2).
- **Plant-Based Milks:** Prepare homemade plant-based milks with speed 5 for a residue-free result.

Farines.

Mixez à vitesse
1-2 pour les farines
alternatives.



nutribullet.

Beurres.

Mixez à vitesse 3-4
pour le beurre
de noix et
de graines.



Boissons végétales.

Mixez à vitesse
5 pour une boisson
de noix sans résidus.



This blender is capable of preparing various textures, from fine flours (using speeds 1-2) to creamy nut and seed butters (speeds 3-4), and smooth plant-based milks (speed 5).

Préparez
des smoothies,
des dips des
vinaigrettes
et bien plus
encore.

nutribullet.



The NutriBullet SmartSense Blender is versatile, allowing you to prepare a wide range of recipes including smoothies, dips, sauces, and vinaigrettes.

5. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and optimal performance of your NutriBullet SmartSense Blender.

- **Unplug Before Cleaning:** Always ensure the blender is unplugged from the power outlet before cleaning.
- **Motor Base:** Wipe the motor base with a clean, damp cloth. Do not immerse the motor base in water or any other liquid.
- **Pitcher, Cups, and Lids:** The 1.8L pitcher, personal cups, and lids are dishwasher safe (top rack recommended). For manual cleaning, wash with warm, soapy water, rinse thoroughly, and air dry.
- **Blades:** The integrated blades in the pitcher can be cleaned by rinsing under running water. For personal cups, unscrew the blade assembly and rinse under running water. Use a brush to remove any stubborn residue. Handle blades with care as they are sharp.
- **Storage:** Store the blender in a clean, dry place when not in use.

**Bol, tasses
et couvercles
lavables
au lave-
vaisselle.**



nutribullet.



For easy cleaning, the pitcher, personal cups, and lids are all dishwasher safe (top rack recommended).

6. TROUBLESHOOTING

If you encounter any issues with your NutriBullet SmartSense Blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet issue; pitcher/cup not properly secured.	Ensure the power cord is securely plugged in. Check the power outlet. Make sure the pitcher or cup is twisted and locked onto the motor base.
Motor stops during operation.	Overheating; too many ingredients; ingredients too thick.	Unplug the unit and let it cool down for 15-20 minutes. Reduce the amount of ingredients or add more liquid.
Ingredients are not blending smoothly.	Insufficient liquid; ingredients too large; incorrect speed setting.	Add more liquid. Cut ingredients into smaller pieces. Increase speed or use the Pulse function for stubborn ingredients.

Problem	Possible Cause	Solution
Leakage from pitcher/cup.	Lid not properly secured; overfilling; damaged seal.	Ensure the lid is securely twisted and locked. Do not exceed the MAX fill line. Inspect the seal for damage and replace if necessary.

If the problem persists after trying these solutions, please contact customer support.


7. SPECIFICATIONS

Detailed technical specifications for the NutriBullet SmartSense Blender Combo NBF550DG:

Feature	Specification
Model Number	NBF550DG
Power	1500 Watts
Voltage	240 Volts
Pitcher Capacity	1.8 Liters
Personal Cup Capacities	900ml, 700ml
Number of Speeds	5 Variable Speeds + Pulse
Special Features	Smart Auto Cycle, Digital Display
Dimensions (L x W x H)	16.8 x 16.8 x 42.5 cm
Weight	4.4 Kilograms
Color	Dark Grey (Noir)

Spécifications techniques:

Poids: 5,3kg
Longueur du câble:
100cm



nutribullet.

Refer to this diagram for the physical dimensions and weight of the NutriBullet SmartSense Blender.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official NutriBullet website. Keep your proof of purchase for warranty claims.

Online Resources:

- Official NutriBullet Website: www.nutribullet.com
- Product Registration: Register your product online to receive updates and support.