

[Manuals.plus](#) /

› [Part Synergy](#) /

› Part Synergy Sirocco II 7-Inch 3-Speed Cabin Fan User Manual

Part Synergy 1527 - 7010CABBX

Part Synergy Sirocco II 7-Inch 3-Speed Cabin Fan User Manual

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Part Synergy Sirocco II 7-inch 3-speed cabin fan. Please read this manual thoroughly before using the product to ensure proper function and safety.



Image: The Part Synergy Sirocco II 7-inch cabin fan, featuring a black finish, a protective grill, and a sturdy mounting base. The fan is designed for cabin use and offers 360-degree rotation.

SAFETY INFORMATION

- Ensure the power source matches the fan's voltage requirements (12V or 24V).
- Disconnect power before installation or maintenance.
- Do not insert fingers or objects into the fan blades while operating.
- Mount the fan securely to prevent vibration or detachment during use.
- Keep the fan away from water or excessive moisture.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Sirocco II 7-inch Cabin Fan
- Mounting Hardware (screws, washers)
- User Manual (this document)

SETUP AND INSTALLATION

Follow these steps for proper installation of your cabin fan:

1. **Choose a Mounting Location:** Select a flat, secure surface in your cabin for mounting. Ensure adequate clearance for the fan's 360-degree rotation.
2. **Mark Drilling Points:** Use the fan's base as a template to mark the positions for drilling mounting holes.
3. **Drill Pilot Holes:** Drill pilot holes at the marked positions.
4. **Secure the Fan:** Attach the fan base to the surface using the provided mounting hardware. Ensure it is firmly secured.
5. **Wiring Connection:**
 - Connect the **red wire** from the fan to the positive (+) terminal of your 12V or 24V power supply.
 - Connect the **black wire** from the fan to the negative (-) terminal or ground of your power supply.
 - Ensure all connections are secure and insulated.



Image: Rear view of the Sirocco II fan, illustrating the mounting bracket and the red and black wires for electrical connection. This view helps in understanding the installation process.

Your browser does not support the video tag.

Video: This video demonstrates the general wiring and initial setup of a similar cabin fan. It shows how to connect the power wires and the fan's movement. Note: The fan in the video may have a toggle switch and 2-speed control, while this model features push-button control and 3 speeds.

OPERATING INSTRUCTIONS

The Sirocco II fan features a push-button control for speed adjustment and a gimbal design for directional airflow.

1. **Power On/Off:** Press the power button once to turn the fan on. Press it again to turn the fan off.

2. **Adjust Fan Speed:** While the fan is on, repeatedly press the speed control button to cycle through the 3 available speeds (Low, Medium, High).
3. **Adjust Airflow Direction:** The fan's gimbal design allows for 360-degree rotation. Manually adjust the fan head to direct airflow as desired.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your fan.

- **Cleaning:** Periodically wipe the fan blades and grill with a soft, damp cloth. Ensure the fan is turned off and disconnected from power before cleaning. Do not use abrasive cleaners or solvents.
- **Inspection:** Regularly check mounting hardware for tightness and wiring for any signs of wear or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; loose wiring; faulty switch.	Check power connection; ensure wires are securely connected; test power source.
Fan operates at low speed only.	Incorrect speed setting; power supply issue.	Press speed button to cycle through speeds; verify stable power supply.
Excessive noise or vibration.	Loose mounting; obstruction in fan blades.	Tighten mounting screws; clear any obstructions from blades.

SPECIFICATIONS

Feature	Detail
Model Number	1527 - 7010CABBX
Diameter	7 inches
Height	12 inches
Number of Speeds	3
Voltage Rating	12 to 24 Volt DC
Head Type	360 Degree Rotation (Gimbal Design)
Control Type	Push Button
Color	Black
Mounting Type	Windshield Mount (Universal Fit)
Material	ABS Plastic
Item Weight	2.7 Pounds

Feature	Detail
Product Dimensions (L x W x H)	13 x 10.5 x 5.5 inches

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact Part Synergy directly through their official website or the retailer where the product was purchased.