

Manuals.plus /
› BoxWave /
› BoxWave ClearTouch Anti-Glare Privacy Screen Protector User Manual

BoxWave ClearTouch Anti-Glare Privacy (2-Pack)

BoxWave ClearTouch Anti-Glare Privacy Screen Protector User Manual

Model: ClearTouch Anti-Glare Privacy (2-Pack)

1. INTRODUCTION


This manual provides comprehensive instructions for the installation, use, and maintenance of your BoxWave ClearTouch Anti-Glare Privacy Screen Protector. This product is designed to protect your device's screen while ensuring your privacy and reducing glare.

2. PRODUCT OVERVIEW

The BoxWave ClearTouch Anti-Glare Privacy Screen Protector is a flexible film designed to fit your specific device. It offers privacy from side views and features an anti-glare matte surface.

2.1. Package Contents

- ClearTouch Anti-Glare Privacy Screen Protector (2-Pack)
- Microfiber Cleaning Cloth
- Applicator Card (if included in specific packaging)



Please note this is a general product photo for display purposes.
The actual product is tailored specifically to fit your device

Image: Contents of the BoxWave ClearTouch Anti-Glare Privacy Screen Protector 2-Pack, including the screen protectors, a microfiber cleaning cloth, and an applicator card.

3. KEY FEATURES

- **Privacy Protection:** The screen protector obstructs views from angles beyond 25 degrees, ensuring that only the user directly in front of the screen can see its content.

Anti-Spy Privacy Protection

Visible to you directly in front of the screen. Prevents others from viewing from the sides.




Image: A visual representation demonstrating how the privacy screen protector limits visibility from side angles (30 and 45 degrees) while maintaining clear visibility when viewed directly (90 degrees).

- **Anti-Glare Surface:** Features a matte finish that disperses light, effectively reducing glare and reflections from ambient light sources, improving screen readability.
- **Precision Design:** Custom-cut to fit your specific device, ensuring full accessibility to all ports and buttons without interference.
- **Easy Installation:** Utilizes a glueless adhesive that automatically clings to the screen after proper cleaning and alignment, minimizing bubbles.
- **Durable Protection:** Made from strong and flexible material that guards the screen against scratches and cracks, offering robust protection without the brittleness of glass.




Image: An illustration depicting the screen protector's scratch-resistant properties, showing it withstands contact from sharp objects like a knife and keys.

4. INSTALLATION GUIDE

Follow these steps carefully for optimal installation of your screen protector:

1. **Prepare Your Workspace:** Ensure you are in a clean, dust-free environment. Wash your hands thoroughly to avoid transferring oils or dirt to the screen.
2. **Clean the Device Screen:** Use the included microfiber cloth to meticulously clean your device's screen. Ensure all dust, smudges, and fingerprints are removed. For stubborn marks, a screen cleaning solution (not included) can be used sparingly.
3. **Remove Dust:** Use a dust-removal sticker (if provided) or tape to lift any remaining dust particles from the screen. Inspect the screen carefully under light to ensure it is perfectly clean.
4. **Align the Screen Protector:** Carefully peel back a small portion of the protective film from the adhesive side (usually marked "1" or "Back"). Align the screen protector with the edges and cutouts of your device's screen. Take your time to ensure precise alignment.
5. **Apply the Protector:** Once aligned, slowly peel off the rest of the protective film while gently laying the screen

protector onto the device's screen. Use the applicator card (or a credit card wrapped in the microfiber cloth) to smooth out any air bubbles, pushing them towards the edges.

6. **Remove Top Film:** Once the screen protector is fully adhered and free of bubbles, carefully peel off the top protective film (usually marked "2" or "Front").
7. **Final Inspection:** Perform a final check for any remaining bubbles or misalignments. Small bubbles may disappear over 24-48 hours.

5. MAINTENANCE AND CARE

To ensure the longevity and effectiveness of your BoxWave ClearTouch Anti-Glare Privacy Screen Protector, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the screen protector with a clean, dry microfiber cloth to remove dust and smudges. For deeper cleaning, lightly dampen the microfiber cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.

Anti-Smudge Surface

Protects Against Fingerprints



Other Brands



Image: A visual comparison illustrating the anti-smudge properties of the BoxWave screen protector compared to a standard surface, showing significantly fewer fingerprints.

- **Avoid Sharp Objects:** While the protector is scratch-resistant, excessive force or contact with extremely sharp objects can still cause damage.

- **Reusability:** The ClearTouch screen protector is designed to be reusable. If you need to remove and reapply it, ensure the adhesive side remains clean and free of dust.

6. TROUBLESHOOTING

Common issues and their solutions:

- **Bubbles After Installation:**
 - *Small Bubbles:* Many small bubbles will naturally dissipate within 24-48 hours.
 - *Large Bubbles:* Gently lift the nearest edge of the screen protector and reapply, using the applicator card to push the air out as you lay it back down. Ensure no dust is trapped underneath.
- **Dust Underneath Protector:**
 - Carefully lift the corner closest to the dust particle. Use a dust-removal sticker or a piece of tape to gently dab and lift the dust from both the screen and the adhesive side of the protector. Reapply.
- **Protector Not Sticking:**
 - Ensure the screen was thoroughly cleaned and free of oils or residues before application. The adhesive side of the protector must also be clean.

7. SPECIFICATIONS

Attribute	Detail
Brand	BoxWave
Model Name	ClearTouch Anti-Glare Privacy
Compatible Device	TownSteel e-Genius 4000
Material	Polyethylene Terephthalate
Screen Surface Description	Matte
Item Weight	0.7 ounces

8. WARRANTY AND SUPPORT

BoxWave stands behind the quality of its products. For any questions, concerns, or support needs regarding your ClearTouch Anti-Glare Privacy Screen Protector, please contact BoxWave customer service. While specific warranty details are not provided in this manual, standard return policies typically allow for returns or replacements within 30 days of purchase if the product is defective or not as described. Please refer to your purchase documentation or the retailer's policy for exact terms. For further assistance, visit the official BoxWave website or contact their support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F7J5LTVY>

More documents and user manuals: <https://manuals.plus/>