

## Vossfamul AC14000-G

# Vossfamul 14,000 BTU Portable Air Conditioner User Manual

Model: AC14000-G

[Instructions](#)   [Maintenance](#)   [Safety Information](#)   [Troubleshooting](#)   [Setup](#)   [Specifications](#)   [Operating](#)   [Warranty](#)   [Support](#)

## 1. SAFETY INFORMATION

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the unit is placed on a flat, stable surface to prevent tipping.
- Always plug the unit into a grounded electrical outlet. Do not use extension cords or adapter plugs.
- Do not operate the air conditioner with a damaged power cord or plug.
- Keep the air intake and exhaust vents clear of obstructions. Maintain at least 20 inches (50 cm) of clearance around the unit.
- Do not insert fingers or objects into the air inlet or outlet.
- Unplug the unit before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

## 2. SETUP INSTRUCTIONS

Follow these steps to properly set up your portable air conditioner.

### 2.1 Unpacking

- Carefully remove the air conditioner and all accessories from the packaging.
- Check for any damage that may have occurred during shipping. Contact customer support if any damage is found.
- Retain the original packaging for future storage or transportation.

### 2.2 Unit Placement

Place the air conditioner on a firm, level surface in the desired room. Ensure there is at least 20 inches (50 cm) of space around the unit for proper airflow.



Image: The Vossfamul portable air conditioner positioned in a living space, demonstrating appropriate clearance from furniture.

### 2.3 Window Kit Installation

The patented Slide-Seal Window Kit is designed for easy installation in most sliding and double-hung windows without tools.

1. Adjust the window slider kit to fit the opening of your window. Extend the adjustable panel as needed.
2. Secure the window kit in place within the window frame. Close the window against the kit to create a seal.
3. Ensure the kit is sealed tightly to prevent air leakage.

### 2.4 Exhaust Hose Connection

Connect the exhaust hose to the unit and the window kit.

1. Attach one end of the exhaust hose to the air outlet on the back of the air conditioner. The leak-proof 360° hose connector ensures a secure fit.
2. Attach the other end of the exhaust hose to the adapter on the window slider kit.

3. Extend the hose as straight as possible to minimize bends, which can reduce efficiency. The hose is extendable up to 1.5 meters.



Image: Rear view of the portable air conditioner, illustrating the connection point for the exhaust hose.

## 2.5 Power Connection

Plug the power cord into a standard, grounded 115V AC electrical outlet. Do not use power strips or extension cords.

## 3. OPERATING INSTRUCTIONS

Your Vossfamul portable air conditioner features a user-friendly control panel and a remote control for convenient operation.



Image: Detailed view of the top-mounted control panel with LED display and function buttons.

### 3.1 Control Panel and Remote Control

The unit is equipped with an easy-to-read LED digital display on the front and a control panel on top. A remote control is included for convenient adjustments from a distance.

### 3.2 Power On/Off

- Press the **POWER** button on the control panel or remote control to turn the unit on or off.

### 3.3 Operating Modes

Press the **MODE** button to cycle through the available operating modes:

- **Cooling Mode:** Provides powerful cooling for rooms up to 700 sq.ft. Adjust the temperature using the temperature adjustment buttons.
- **Dehumidifier Mode:** Removes excess moisture from the air. The unit's self-evaporation system minimizes the need for manual drainage.
- **Fan Mode:** Circulates air without cooling. Fan speed can be adjusted.

### 3.4 Temperature Adjustment

- In Cooling Mode, use the **UP** and **DOWN** arrow buttons on the control panel or remote to set the desired temperature between 61°F and 88°F (16°C and 31°C). The unit offers precision control with  $\pm 1^\circ\text{F}$  accuracy.

### 3.5 Fan Speed Adjustment

- Press the **SPEED** button to select between different fan speeds (e.g., Low, Medium, High).

### 3.6 Timer Function

- Press the **TIMER** button to set a delayed start or stop time for the unit. Use the temperature adjustment buttons to set the desired hours.

### 3.7 Sleep Mode

- Activate **SLEEP MODE** for ultra-quiet operation (as low as 40dB) and automatic temperature adjustments for comfortable sleep.

### 3.8 Swing Function

- Press the **SWING** button to activate or deactivate the automatic louver swing, which helps distribute air evenly.

## 4. MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner.

### 4.1 Filter Cleaning

The unit includes washable allergen filters. Clean the air filter every two weeks or more frequently depending on usage and air quality.

1. Unplug the air conditioner from the power outlet.
2. Locate the air filter panel (usually on the back or side of the unit).
3. Remove the air filter.
4. Wash the filter with warm, soapy water. Rinse thoroughly and allow it to air dry completely before reinstalling.
5. Reinsert the dry filter into the unit and close the panel.

### 4.2 Drainage

This unit features a self-evaporation system that typically eliminates the need for daily drainage. However, in areas of high humidity, the internal water tank may fill up. If the unit stops operating and displays a 'Full Water' indicator, manual drainage is required.

1. Unplug the air conditioner.
2. Place a shallow pan or tray under the drainage port (located at the bottom rear of the unit).
3. Remove the drain plug to allow water to flow out.
4. Once all water has drained, replace the drain plug securely.

### 4.3 Unit Cleaning

- Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the unit is completely dry before plugging it back in.

### 4.4 Storage

- Before storing, drain any remaining water from the unit and clean the air filter.

- Wrap the power cord and store it neatly.
- Cover the unit with a plastic bag or cloth to protect it from dust.
- Store the unit in a cool, dry place.

## 5. TROUBLESHOOTING

Refer to this section for solutions to common issues. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Unit does not turn on	No power; Power cord unplugged; Circuit breaker tripped; Water tank full	Ensure unit is plugged into a live outlet; Check circuit breaker; Drain water tank if 'Full Water' indicator is on.
Unit is running but not cooling	Air filter clogged; Exhaust hose not properly installed or blocked; Room temperature too low; Doors/windows open	Clean air filter; Check exhaust hose for kinks or blockages and ensure proper sealing; Adjust desired temperature; Close all doors and windows.
Unit is noisy	Unit not on a level surface; Air filter clogged; Foreign object in fan	Place unit on a flat, stable surface; Clean air filter; Turn off and unplug unit, then check for obstructions.
Remote control not working	Batteries dead or incorrectly inserted; Obstruction between remote and unit	Replace batteries; Ensure clear line of sight to the unit's receiver.

## 6. PRODUCT SPECIFICATIONS

Detailed technical specifications for the Vossfamul AC14000-G Portable Air Conditioner.

Feature	Detail
Brand	Vossfamul
Model Name	AC14000-G
Cooling Power	14,000 BTU
Floor Area Coverage	Up to 700 Square Feet
Operating Modes	Cooling, Dehumidifier, Fan
Noise Level	40 Decibels (in Sleep Mode)
Voltage	115 Volts (AC)
Wattage	1155 Watts
Item Weight	81 pounds
Product Dimensions (D x W x H)	18.9 x 15.3 x 30.7 inches

Feature	Detail
Refrigerant	R32 (Eco-friendly)
Special Features	Air Purification Filter, Dehumidifier, Fast Cooling, Remote Controlled, Sleep Mode, Roll-Wheel Mobility
Included Components	Air Conditioner, Remote Control, Exhaust Hose, Window Kit

## 7. WARRANTY INFORMATION

---

This Vossfamul portable air conditioner comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or contact Vossfamul customer support directly. Keep your proof of purchase for warranty claims.

## 8. CUSTOMER SUPPORT

---

If you have any questions, require technical assistance, or need to report an issue with your Vossfamul portable air conditioner, please contact our customer support team. Refer to the contact information provided in your product packaging or on the official Vossfamul website.

When contacting support, please have your model number (AC14000-G) and purchase date available.