

Ntaanoo F50

Ntaanoo F50 10000mAh Power Bank User Manual

Model: F50

1. INTRODUCTION

Thank you for choosing the Ntaanoo F50 10000mAh Power Bank. This portable charger is designed to provide reliable and fast charging for your mobile devices on the go. Please read this manual carefully before using the product to ensure safe and optimal performance. Keep this manual for future reference.

2. IMPORTANT SAFETY INFORMATION

To prevent damage, electric shock, injury, or fire, please observe the following safety precautions:

- Do not expose the power bank to extreme temperatures (above 60°C/140°F or below 0°C/32°F).
- Do not disassemble, modify, or attempt to repair the device yourself.
- Avoid dropping, hitting, or subjecting the power bank to strong impacts.
- Keep away from water, moisture, and flammable materials.
- Use only certified cables and chargers compatible with the device.
- Do not short-circuit the output terminals.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations. Do not dispose of it in household waste.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Ntaanoo F50 10000mAh Power Bank

- USB-C Charging Cable
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Ntaanoo F50 Power Bank:



This image displays the Ntaanoo F50 10000mAh Power Bank from an angled perspective. The device is black with a smooth finish, featuring a digital display on one end showing '100%' charge. Below the display, there are multiple ports, including USB-A and USB-C, indicating its fast charging capabilities. A power button is visible on the side.

Components:

- **Digital LED Display:** Shows the remaining battery percentage.
- **USB-A Output Ports:** For charging your devices.
- **USB-C Input/Output Port:** For charging the power bank or compatible devices.
- **Power Button:** Press once to check battery level or activate charging.

5. SETUP

Your Ntaanoo F50 Power Bank comes with a partial charge. For optimal performance, it is recommended to fully charge it before first use.

1. **Unpack:** Remove the power bank and all accessories from the packaging.

2. **Initial Charge:** Connect the provided USB-C cable to the power bank's USB-C port and the other end to a USB wall charger (not included). The LED display will show the charging progress.
3. **Full Charge:** Charge until the LED display shows 100%.

6. OPERATING INSTRUCTIONS

6.1. Charging the Power Bank

To recharge your Ntaanoo F50 Power Bank:

1. Connect the USB-C charging cable to the power bank's USB-C input port.
2. Connect the other end of the cable to a compatible USB wall charger or a computer's USB port.
3. The digital LED display will show the current battery percentage and flash during charging.
4. The display will show "100%" when fully charged. Disconnect the cable.

6.2. Charging Your Devices

To charge your smartphone, tablet, or other USB-powered devices:

1. Connect your device's charging cable to one of the power bank's USB-A output ports or the USB-C output port (if your device supports USB-C charging).
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. If not, press the power button once to activate charging.
4. The digital LED display will show the remaining battery percentage of the power bank.
5. Disconnect your device once it is fully charged or when you no longer need to charge.

7. MAINTENANCE

Proper care will extend the life of your power bank:

- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- If not used for extended periods, charge the power bank at least once every three months to maintain battery health.
- Avoid overcharging or completely draining the battery frequently.

8. TROUBLESHOOTING

If you encounter issues with your Ntaanoo F50 Power Bank, refer to the following table:

Problem	Possible Solution
Power bank not charging	Ensure the charging cable and wall adapter are working correctly. Try a different cable or adapter. Check if the USB-C port is clean and free of debris.
Device not charging from power bank	Press the power button to activate output. Ensure the power bank has sufficient charge. Try a different charging cable for your device. Check if your device's charging port is clean.
LED display not working	Press the power button. If it still doesn't light up, the power bank might be fully discharged or require service.
Slow charging	Ensure you are using a fast-charging compatible cable and adapter. Some devices may limit charging speed.

9. SPECIFICATIONS

Detailed technical specifications for the Ntaanoo F50 Power Bank:

Feature	Value
Model Number	F50
Battery Capacity	10000 Milliamp Hours
Voltage	3.85 Volts
Connector Type	USB Type C
Special Features	LED Indicator Lights
Product Dimensions	1 x 1 x 1 inches
Item Weight	0.035 ounces
Manufacturer	Shenzhen lingJi Creative Technology Co. , Ltd.
Date First Available	May 6, 2025

10. WARRANTY AND SUPPORT

10.1. Warranty Information

Ntaanoo products are manufactured to the highest quality standards. This product is covered by a limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

10.2. Customer Support

For technical support, warranty claims, or any questions regarding your Ntaanoo F50 Power Bank, please contact our customer service team. You can find contact information on the official Ntaanoo website or through your purchase platform.

Visit the [Ntaanoo Store on Amazon](#) for more information.