

[Manuals.plus](#) /

› [LLAMA VIVA](#) /

› LLAMA VIVA L-BFEGT74 Dual Fuel Grill Combo User Manual

LLAMA VIVA L-BFEGT74

LLAMA VIVA L-BFEGT74 Dual Fuel Grill Combo User Manual

Model: L-BFEGT74

1. IMPORTANT SAFETY INFORMATION

Please read this entire manual before assembly and use of your LLAMA VIVA L-BFEGT74 Dual Fuel Grill Combo. Failure to follow these instructions could result in property damage, bodily injury, or death.

- For outdoor use only. Do not operate indoors.
- Keep children and pets away from the grill at all times.
- Never leave the grill unattended while in use.
- Ensure proper ventilation when using the charcoal section.
- Always connect and disconnect propane cylinders outdoors and away from ignition sources.
- Check for gas leaks before each use.
- Wear protective gloves, such as the included silicone non-slip grill gloves, when handling hot components.

2. SETUP AND ASSEMBLY

While the LLAMA VIVA L-BFEGT74 grill is designed for straightforward setup, some assembly and preparation are required before first use. Ensure all components are present and undamaged before proceeding.

2.1 Unpacking and Component Check

Carefully remove all parts from the packaging. Refer to the packing list (if provided separately) to ensure all components are accounted for. Inspect for any shipping damage. If any parts are missing or damaged, do not attempt to assemble or operate the grill. Contact customer support immediately.

2.2 Assembly Instructions

Follow the step-by-step instructions provided in the separate assembly guide (if included) to construct the grill. Pay close attention to the attachment of the side shelves, wheels, and any other structural components. Ensure all fasteners are securely tightened.

HIGH QUALITY PRODUCT DETAILING

More Details providing more convenience



Image: The LLAMA VIVA L-BFEGT74 Dual Fuel Grill Combo, showcasing its overall design with side shelves and storage.

2.3 Propane Tank Connection

1. Ensure the gas control knob on the grill is in the 'OFF' position.
2. Connect the regulator hose from the grill to the propane cylinder valve. Hand-tighten firmly. Do not use tools.
3. Perform a leak test: Apply a soapy water solution to the connection points. If bubbles appear, there is a leak. Tighten the connection or replace the cylinder/regulator if necessary. Do not use the grill if a leak is detected.

2.4 Initial Burn-Off

Before cooking food for the first time, operate the gas grill on high for 15 minutes to burn off any manufacturing residues. For the charcoal side, allow a full load of charcoal to burn down completely once before first use.

3. OPERATING INSTRUCTIONS

The LLAMA VIVA L-BFEGT74 offers dual-fuel flexibility, allowing you to choose between propane gas for convenience and charcoal for traditional smoky flavor.

3.1 Gas Grill Operation

1. Open the lid of the gas grill section.
2. Ensure the propane cylinder valve is fully open.
3. Push and turn the control knob to the 'HIGH' position. The automatic ignition will spark and light the burner. If the burner does not light within 5 seconds, turn the knob to 'OFF', wait 5 minutes, and repeat the process.
4. Adjust the heat by turning the control knob between 'LOW' and 'HIGH'.
5. After use, turn the control knob to 'OFF' and close the propane cylinder valve.



Image: Close-up view of the grill's cooking surface, highlighting the propane gas burner and the charcoal grate sections.



Not Only Can You Enjoy the Convenience of Gas Barbecue,
But Also Savour the Delicious Taste of Charcoal BBQ !

ENJOY THE GREAT OUTDOORS



Adjustable Knob

Image: The adjustable control knob for the gas burner, allowing precise temperature control.

3.2 Charcoal Grill Operation

1. Open the lid of the charcoal grill section.
2. Place charcoal briquettes or lump charcoal onto the charcoal grate. Do not overfill.
3. Use a charcoal chimney starter or appropriate fire starters to ignite the charcoal. Never use gasoline or kerosene.
4. Allow charcoal to ash over (typically 15-20 minutes) before placing food on the cooking grate.
5. Adjust cooking temperature by manipulating the air vents (if present) and the amount of charcoal.
6. After cooking, allow charcoal to cool completely before disposal.

3.3 Cooking Surface and Capacity

The grill features a total cooking surface area of 327 square inches, including a cast iron pan (griddle) and a cooking grid. This allows for cooking multiple items simultaneously. The porcelain-enameled cast iron grates provide even heat distribution and superior heat retention for consistent cooking results and nice searing marks.

PORCELAIN-ENAMELED CAST IRON GRATES

OTHERS

Normal Thin Grates

- ✗ Poor Heat Distribution
- ✗ Peeling Off Easily
- ✗ Food Burns Easily



OURS

Heavy-duty & Thicker Cast Iron Grates

- ✓ Evenly Heat & Superior Heat Retention
- ✓ Rust Resistant
- ✓ Nice Searing Marks




Image: Detailed image comparing the grill's heavy-duty porcelain-enameled cast iron grates with standard thin grates, emphasizing heat retention and rust resistance.

3.4 Product Video Demonstration

Your browser does not support the video tag.

Video: Official video demonstrating the features and operation of the LLAMA VIVA Dual Fuel Grill Combo, including both propane and charcoal cooking methods.

4. MAINTENANCE AND CLEANING

Regular maintenance and cleaning will extend the life of your grill and ensure optimal performance.

4.1 After Each Use

- **Cooking Grates:** While still warm, brush the cooking grates with a stiff wire brush to remove food residue.
- **Grease Trap:** The grill features a solid grease trap. Allow it to cool, then remove and empty it. Clean with warm, soapy water.

- **Ash Tray:** For the charcoal section, the sliding ash tray should be emptied once charcoal has completely cooled. Clean with warm, soapy water.

PUSH-OUT CHARCOAL & GREASE TRAY

Easy to Clean More Safer & Reassuring



Extra Large Ash Tray



Solid Grease Trap



Image: Illustration of the pull-out ash tray for charcoal and the solid grease trap for easy cleaning.

4.2 Periodic Maintenance

- **Exterior Surfaces:** Wipe down exterior surfaces with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Burners:** Periodically inspect gas burners for blockages (e.g., spider webs, food debris). Clean with a soft brush if necessary.
- **Rust Prevention:** The grill is designed to be rust-resistant. However, storing it under a grill cover in a dry area when not in use will further protect it from the elements.

5. TROUBLESHOOTING

If you encounter issues with your grill, refer to the following common troubleshooting steps.

Problem	Possible Cause	Solution
Gas burner won't light.	No gas flow, clogged burner, faulty igniter.	Check propane tank for gas. Ensure propane tank valve is fully open. Check for leaks at connections. Clean burner ports if clogged. Verify igniter spark.
Uneven heating on gas side.	Clogged burner ports, low gas pressure.	Clean burner ports. Ensure regulator is functioning correctly.
Charcoal not igniting or burning poorly.	Insufficient airflow, damp charcoal, improper lighting method.	Ensure air vents are open. Use dry charcoal. Utilize a charcoal chimney starter for best results.
Flare-ups.	Excess fat dripping onto heat source, too high temperature.	Trim excess fat from meat. Move food to a cooler part of the grill. Close lid briefly to starve oxygen (for charcoal).

6. SPECIFICATIONS

Detailed specifications for the LLAMA VIVA L-BFEGT74 Dual Fuel Grill Combo.




Image: Diagram showing the dimensions of the LLAMA VIVA L-BFEGT74 Dual Fuel Grill Combo, including height, width, and depth.

Feature	Detail
Brand	LLAMA VIVA
Model Name	L-BFEGT74
Product Dimensions (D x W x H)	35"D x 30"W x 17"H (88.9cm D x 76.2cm W x 43.2cm H)
Special Features	Heavy Duty, Rust Resistant
Color	Charcoal and Gas Combo Grill
Fuel Type	Charcoal, Gas (Propane)
Heating Power (Gas Burner)	12,000 British Thermal Units (BTU)

Feature	Detail
Main Burner Count	1
Number of Racks	2
Grill Configuration	Dual Fuel (Propane & Charcoal)
Primary Cooking Method	Grilling, Griddle
Cooking Surface Area	327 Square Inches
Material Type	Cast Iron (Grates), Stainless Steel (Handle)
Frame Material	Cast Iron
Indoor/Outdoor Usage	Outdoor
Included Components	User Manual, Long Silicone Non-Slip Grill Gloves
UPC	716597243071

7. WARRANTY INFORMATION

According to the product specifications, there is no explicit warranty description provided for the LLAMA VIVA L-BFEGT74 Dual Fuel Grill Combo. Please retain your proof of purchase for any potential claims or inquiries regarding product defects or issues.

8. CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your LLAMA VIVA L-BFEGT74 Dual Fuel Grill Combo, please contact the manufacturer, Llamaviva, through their official channels or the retailer from whom you purchased the product.

Manufacturer: Llamaviva
Website: [Visit the LLAMA VIVA Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question