

ZOLAMENTE 4K Video Camera

ZOLAMENTE 4K Video Camera User Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the ZOLAMENTE 4K Video Camera. It covers product features, setup, operation, maintenance, and troubleshooting to ensure optimal use of your device. Please read this manual thoroughly before using the camera.

2. PACKAGE CONTENTS

The following items are included in your ZOLAMENTE 4K Video Camera package:

- ZOLAMENTE 4K Video Camera
- Rechargeable Lithium-ion Batteries (x2)
- 32GB SD Card
- USB Charging Cable
- Lens Cover
- Remote Control
- Storage Bag
- User Manual

パッケージ内容



SDカード



バッテリー-x2



充電ケーブル



レンズカバー



リモコン



収納バッグ



日本語説明書

Figure 2.1: ZOLAMENTE 4K Video Camera and included accessories.

3. CAMERA PARTS

Familiarize yourself with the main components of your ZOLAMENTE 4K Video Camera:



Figure 3.1: Front and side view of the ZOLAMENTE 4K Video Camera.

- **Lens:** Captures video and still images.
- **IR Lights:** For infrared night vision.
- **3.0-inch IPS Display:** Rotates 270 degrees for flexible viewing and selfies.
- **Power Button:** Turns the camera on or off.
- **Record/Shutter Button:** Starts/stops video recording or takes a photo.
- **Zoom Control:** Adjusts digital zoom (18x).
- **Mode Button:** Switches between video and photo modes.
- **Battery Compartment:** Houses the rechargeable battery.
- **SD Card Slot:** For inserting the memory card.
- **USB Port:** For charging and data transfer.
- **3.5mm Microphone Jack:** For connecting an external microphone (not included).

4. SETUP

4.1. Battery Installation and Charging

1. Open the battery compartment cover.
2. Insert a fully charged 1500mAh lithium-ion battery, ensuring correct polarity.
3. Close the battery compartment cover.

4. To charge, connect the camera to a power source using the provided USB cable. The camera supports recording while charging.

4.2. SD Card Insertion

1. Locate the SD card slot.
2. Insert the 32GB SD card with the metal contacts facing the correct direction until it clicks into place.
3. To remove, gently press the SD card until it pops out.

4.3. Powering On/Off

- Press and hold the Power button to turn the camera on or off.
- The display screen will illuminate when the camera is powered on.

5. OPERATING INSTRUCTIONS

5.1. Basic Video Recording (4K/30FPS)

1. Ensure the camera is in video mode (indicated on the display). If not, press the Mode button to switch.
2. Press the Record button to start recording. A red indicator will typically appear on the screen.
3. Press the Record button again to stop recording.

5.2. Taking Still Photos (44MP)

1. Press the Mode button to switch to photo mode.
2. Frame your shot using the display.
3. Press the Shutter button to capture the photo.

多機能の 4Kビデオカメラ



4K

4K高画質
ビデオ



4400万
画素



IRナイト
ビジョン



3.0イン
チ画面



18倍デジタ
ルズーム



ウェブ
カメラ



充電中のビ
デオ録画



リモコン



Figure 5.1: Photo resolution comparison and feature icons.

5.3. Using Digital Zoom (18x)

Use the zoom controls (usually marked 'W' for wide and 'T' for telephoto) to adjust the 18x digital zoom. This allows you to magnify subjects from a distance.



Figure 5.2: Digital zoom demonstration.

5.4. Activating IR Night Vision

The camera is equipped with two infrared lamps for night vision. In low-light or dark conditions, activate IR Night Vision to record clear video and photos within a 7-meter range.



Figure 5.3: IR Night Vision comparison.

5.5. Webcam Functionality

Connect the camera to your computer via the USB cable to use it as a webcam for live streaming or video calls. The camera's 270-degree rotating screen allows for easy self-monitoring.

ウェブカメラ機能



Figure 5.4: Camera used as a webcam.

5.6. Pause Recording Feature

During video recording, you can pause and resume recording without creating a new file. This feature allows for seamless video segments.

5.7. Special Recording Modes

- **Time-lapse:** Capture events over a period and play them back quickly.
- **Slow Motion:** Record fast-moving subjects and play them back in slow motion.
- **Motion Detection:** The camera starts recording automatically when motion is detected.
- **Continuous Shooting:** Capture a rapid sequence of still images.

スローモーション撮影



充電中しながら使用可能



タイムラプス録画



タイムラプス撮影

Figure 5.5: Slow motion, time-lapse, and recording while charging features.

5.8. Remote Control Operation

Use the included remote control to operate the camera from a distance, useful for self-recording or group shots.

5.9. External Microphone Connection

For enhanced audio quality, an external microphone (not included) can be connected via the 3.5mm microphone jack.

6. MAINTENANCE

6.1. Cleaning the Camera

- Use a soft, dry cloth to clean the camera body.
- For the lens, use a specialized lens cleaning cloth and solution to avoid scratches.
- Do not use harsh chemicals or abrasive materials.

6.2. Battery Care

- Store batteries in a cool, dry place when not in use.
- Avoid fully discharging batteries frequently to prolong their lifespan.
- If storing for extended periods, charge batteries to about 50% capacity.

6.3. Storage

- Store the camera in the provided storage bag to protect it from dust and scratches.
- Keep the camera away from extreme temperatures, humidity, and direct sunlight.

7. TROUBLESHOOTING

If you encounter issues with your ZOLAMENTE 4K Video Camera, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Camera does not power on.	Battery is depleted or incorrectly inserted.	Charge the battery or ensure it is inserted correctly.
Poor image/video quality.	Lens is dirty; insufficient lighting; incorrect settings.	Clean the lens; ensure adequate lighting or activate IR Night Vision; check resolution settings.
Recording stops unexpectedly.	SD card is full or faulty; low battery.	Delete unnecessary files or replace SD card; charge the battery.
Camera not recognized as webcam.	Incorrect USB connection mode; driver issue.	Ensure camera is in webcam mode; try a different USB port or cable; check computer's device manager.

8. SPECIFICATIONS




Feature	Detail
Video Resolution	4K (3840x2160) at 30FPS
Photo Resolution	Up to 44 Megapixels
Display Screen	3.0-inch IPS, 270-degree rotation
Digital Zoom	18x
Night Vision	IR Infrared (effective range up to 7 meters)
Battery Type	Rechargeable Lithium-ion (1500mAh)
Battery Life	Approx. 70-120 minutes per charge (recording), 60-90 minutes per battery (continuous use)
External Storage	SD Card (32GB included)
External Microphone Port	3.5mm Jack (microphone not included)


Feature	Detail
Connectivity	USB (for charging, data transfer, webcam)
Special Functions	Pause Function, Time-lapse, Slow Motion, Motion Detection, Continuous Shooting, Remote Control
External Lens Support	37mm (lenses not included)

9. WARRANTY AND SUPPORT

The ZOLAMENTE 4K Video Camera comes with a 1-year product warranty. For technical support or warranty claims, please refer to the contact information provided with your purchase documentation or visit the official ZOLAMENTE support website.

Related Documents - 4K Video Camera

<div>Instruction Manual</div> <div></div>	<div>Delmodes DV081 4K Digital Video Camera Instruction Manual</div> <div>Comprehensive instruction manual for the Delmodes DV081 4K digital video camera. Learn about battery installation and charging, memory card usage, basic camera operations, shooting modes, connecting to computers and TVs, and important safety precautions.</div>
<div>Instruction Manual</div> <div></div>	<div>Video Camera Camcorder 4K 48MP 30FPS with IR Night Vision, 18X Digital Zoom Camera Recorder 3.0" LCD Touch Screen Vlogging Camera for YouTube with Remote Controller. 2 Batteries, 32GB SD Card</div> <div>User manual for the 4K Video Camera Camcorder featuring 48MP, 30FPS, IR Night Vision, 18X Digital Zoom, 3.0" LCD Touch Screen, Vlogging capabilities, remote controller, and support for 2 batteries and 32GB SD card. Provides detailed instructions on setup, operation, shooting modes, settings, connectivity, and troubleshooting.</div>
<div></div>	<div>ORDRO M5 Camera User Manual and Technical Specifications</div> <div>Comprehensive user manual for the ORDRO M5 camera, covering setup, features, modes, troubleshooting, and technical specifications. Learn how to charge, use memory cards, connect to a computer, and utilize the companion app.</div>

<p>Great view</p> <p>Thank you for purchasing the portable digital video camera. This camera features video recording at 4K (3840x2160) resolution at 30FPS/25FPS. It features Sony 1/2.3-inch image sensor at 20MP video recording format. The video file image size is small while still has high image quality. You can connect your camera via USB to your computer/Phone, transfer, to view the camera live screen and use your phone to record or shooting.</p> <p>Safety Instructions</p> <ul style="list-style-type: none">Do not force, tug or pull on the camera.Do not expose the camera to high/low temperatures, excessive dust/fumphy or strong vibration, otherwise the product may be damaged.Do not use harsh chemicals to clean the product.Do not disassemble this camera or attempt to repair or modify it in any manner. If there is any damage to the camera, stop using the camera and return the product to the store where you have purchased it from, the product will be sent back to the company and for. <p>Cautions</p> <ul style="list-style-type: none">Keep children away from the product, accessories and its packaging materials. It may cause suffocation.Do not put the product in a fire, otherwise it may cause explosion.Remove the battery if the camera is not going to be used for long period, and please fully charge the battery before using it again.	<p>ORDRO HDR-AC3 4K Camcorder User Manual</p> <p>User manual for the ORDRO HDR-AC3 4K Camcorder, detailing its features, operation, and technical specifications. Learn how to use the camera, connect it to devices, and utilize its various modes and settings.</p>
<p>DENVER[®]</p> <p>Instruction Manual 4K Action camera ACK-8062W</p>  <p>www.denveraction.com</p> <p>Before operating this product, please read this instruction manual carefully and completely.</p>	<p>Denver ACK-8062W Action Camera: User Manual, Features, and Specifications</p> <p>Detailed user guide for the Denver ACK-8062W action camera. Covers product features, operation instructions for video and photo modes, Wi-Fi connectivity, specifications, and compliance information.</p>
<p>reolink</p> <p>Operational Instruction Apply to RLC833A and RLC1224A</p> <div></div>	<p>Reolink RLC-833A & RLC-1224A Operational Instructions</p> <p>Comprehensive operational instructions for Reolink RLC-833A and RLC-1224A PoE security cameras, covering setup, installation, troubleshooting, and specifications.</p>