

[Manuals+](#)

[Q & A](#) | [Deep Search](#) | [Upload](#)

[Manuals.plus](#) /

> [JYJMDMG](#) /

> JYJMDMG LYZRC L700 Pro RC Drone Replacement Arm (B1 Gray) Instruction Manual

JYJMDMG JYJMDMG019

JYJMDMG LYZRC L700 Pro RC Drone Replacement Arm (B1 Gray) Instruction Manual

1. PRODUCT OVERVIEW

This document provides instructions for the installation, maintenance, and troubleshooting of the JYJMDMG LYZRC L700 Pro RC Drone Replacement Arm, specifically the B1 Gray variant. This component is designed as a direct replacement part for the LYZRC L700 Pro quadcopter, ensuring proper fit and function.



Image: The JYJMDMG LYZRC L700 Pro RC Drone Replacement Arm (B1 Gray) with integrated motor and propeller blades.

2. SAFETY INFORMATION

- **Read Instructions:** Always read and understand all instructions before attempting installation or maintenance.
- **Small Parts:** This product contains small parts. Keep out of reach of children to prevent choking hazards.
- **Electrical Components:** Handle with care. Avoid contact with water or other liquids. Ensure the drone is powered off and the battery is disconnected before installation.

- **Proper Tools:** Use appropriate tools for installation to avoid damage to the part or the drone.
- **Static Electricity:** Discharge any static electricity from your body before handling electronic components.

3. PACKAGE CONTENTS

Verify that all items are present upon opening the package:

- 1 x JYJMDMG LYZRC L700 Pro RC Drone Replacement Arm (B1 Gray) with integrated motor and propeller blades.

4. SETUP AND INSTALLATION

Follow these general steps for replacing a drone arm. Specific drone disassembly and reassembly procedures may vary; refer to your drone's primary manual for detailed instructions.

1. **Power Off:** Ensure the LYZRC L700 Pro drone is completely powered off and the battery is removed.
2. **Access Damaged Arm:** Carefully identify and access the damaged B1 arm on your drone. This may involve removing screws or covers.
3. **Disconnect Wiring:** Gently disconnect any wiring connecting the damaged arm's motor to the drone's main board. Note the orientation and connection points for reassembly.
4. **Remove Damaged Arm:** Unscrew or unclip the damaged arm from the drone's frame.
5. **Install New Arm:** Position the new B1 Gray replacement arm in the correct location. Ensure it aligns properly with the drone's frame.
6. **Connect Wiring:** Reconnect the motor's wiring to the drone's main board, ensuring correct polarity and secure connections.
7. **Secure Arm:** Fasten the new arm to the drone's frame using the original screws or clips. Do not overtighten.
8. **Reassemble Drone:** Reattach any covers or components that were removed to access the arm.
9. **Test Functionality:** Reinsert the battery and power on the drone. Perform a low-power test to ensure the motor on the new arm spins correctly and the propeller is securely attached.

5. OPERATING INSTRUCTIONS

This product is a replacement part and does not have independent operating instructions. Its function is integrated into the overall operation of the LYZRC L700 Pro drone. Once installed correctly, the arm and its motor will operate as part of the drone's flight system. Ensure the propeller is securely attached and free from obstructions before each flight.

6. MAINTENANCE

- **Regular Inspection:** Periodically inspect the arm for any signs of damage, cracks, or loose connections.
- **Propeller Check:** Ensure the propeller blades are free from damage and securely fastened to the motor shaft. Replace damaged propellers immediately.
- **Cleaning:** Use a soft, dry cloth to gently clean the arm and motor to remove dust or debris. Avoid using harsh chemicals or excessive moisture.

- **Storage:** Store the drone and its components in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues after installing the replacement arm, consider the following:

- **Motor Not Spinning:**
 - Check all wiring connections to ensure they are secure and correctly oriented.
 - Verify that no debris is obstructing the motor or propeller.
 - Ensure the drone's battery is fully charged and properly connected.
- **Unusual Noise/Vibration:**
 - Inspect the propeller for damage or imbalance. Replace if necessary.
 - Ensure the arm is securely fastened to the drone frame and all screws are tightened.
- **Drone Instability:**
 - Confirm that the correct arm (B1 Gray) was installed in the designated position.
 - Ensure all other drone components are functioning correctly.

If problems persist, consult the LYZRC L700 Pro drone's main user manual or contact JYJMDMG customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	JYJMDMG019
ASIN	B0F7LM3J22
Item Weight	1.76 ounces
Package Dimensions	0.39 x 0.39 x 0.39 inches
Number of Pieces	1
Assembly Required	No (for the arm itself, but installation into drone is required)

9. WARRANTY AND SUPPORT

Specific warranty information for this replacement part is not provided in the product details. Please refer to the original purchase documentation or contact the seller, JunYiWangLuo, or the manufacturer, JYJMDMG, directly for warranty details and customer support inquiries.

For further assistance, you may visit the JYJMDMG official website (if available) or contact their customer service department.

