Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gizoon CC61

Gizoon 100 Gallon Resin Outdoor Storage Deck Box Instruction Manual

Model: CC61

1. Introduction

This manual provides instructions for the assembly, operation, and maintenance of your Gizoon 100 Gallon Resin Outdoor Storage Deck Box. This storage solution is designed for outdoor use, offering a large capacity for various items while providing durability and weather resistance.
Key features include a 100-gallon storage capacity, durable resin construction, waterproof and UV-resistant properties, a lockable lid for security, and a hydraulic piston for smooth opening and closing. The unit can also serve as an outdoor bench.

2. Safety Information

- Read all instructions carefully before assembly and use.
- Ensure all components are securely fastened before placing items inside or using the unit as a bench.
- Do not exceed the maximum weight capacity of 500 pounds when using the deck box as a bench.
- Keep children away from the deck box during assembly to prevent injury.
- The hydraulic piston is designed for safe operation, preventing finger pinching during lid closure. However, always exercise caution.
- Do not store hazardous materials or flammable liquids inside the deck box.

3. Package Contents

Please verify that all parts are present and undamaged before beginning assembly. Refer to the included parts list in your physical manual for detailed component identification. If any parts are missing or damaged, contact Gizoon customer support.

4. Assembly Instructions

Assembly typically requires two individuals. Refer to the detailed diagrams and step-by-step instructions provided in your physical assembly guide for precise component placement and fastening. A general overview of the assembly process is as follows:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Base:** Connect the side panels to the base panel according to the instructions.
3. **Attach Front and Back Panels:** Securely attach the front and back panels to the assembled base and side panels.
4. **Install Lid Hinges and Hydraulic Piston:** Attach the lid hinges and the hydraulic piston mechanism to the main body and the lid. Ensure the piston operates smoothly.
5. **Attach Lid:** Carefully place and secure the lid onto the hinges.
6. **Final Checks:** Verify that all connections are tight and the lid opens and closes without obstruction.

Note: Some users have found assembly challenging. If you encounter difficulties, consider watching an assembly video if available from the manufacturer or seeking assistance.



Image: The Gizoon 100 Gallon Deck Box fully assembled and closed, situated on a wooden patio with outdoor furniture in the background.



Image: The Gizoon 100 Gallon Deck Box fully assembled with its lid open, revealing various garden tools and patio accessories stored inside.

5. Operation

Opening and Closing the Lid

The deck box features a hydraulic piston mechanism for smooth and controlled lid operation. To open, gently lift the lid. The piston will assist in holding it open. To close, gently pull the lid down; the piston will ensure a soft, controlled descent, preventing sudden drops and finger pinching.

Lockable Feature

The deck box is equipped with a lockable latch for added security. A padlock (not included) can be inserted through the designated hole on the latch to secure the contents.

GIF: A close-up view demonstrating the lockable latch mechanism on the deck box lid.

Storage Capacity

The 100-gallon capacity provides ample space for storing patio cushions, gardening tools, pool supplies, outdoor toys, and other items, helping to keep your outdoor area organized.

Bench Functionality

The sturdy lid allows the deck box to be used as an outdoor bench, supporting up to 500 pounds. Ensure the lid is fully closed and securely latched before sitting on it.



Image: A man and a woman sitting comfortably on the closed Gizoon deck box, demonstrating its use as an outdoor bench.

6. Maintenance and Care

- **Cleaning:** The resin surface is easy to clean. Wipe down with a damp cloth and mild soap as needed. Avoid abrasive cleaners or harsh chemicals that could damage the material.

- **Weather Resistance:** The deck box is designed to be waterproof and UV-resistant. While it protects contents from light rain and sun exposure, it is not intended for submersion or extreme weather conditions.
- **Inspection:** Periodically check all fasteners and hinges to ensure they remain tight and in good working order.



Image: Visual representation highlighting the waterproof, anti-UV, and anti-bent features of the Gizoon deck box.

7. Troubleshooting

- **Lid not closing properly:** Check for any obstructions inside the box or along the lid's edges. Ensure the hydraulic piston is correctly installed and not damaged.
- **Difficulty during assembly:** Review the assembly instructions carefully. Ensure all parts are oriented correctly. If issues persist, contact customer support.
- **Water inside the box:** While waterproof, ensure the lid is fully closed and latched. Check for any cracks or damage to the resin material.

8. Specifications

Feature	Detail
Brand	Gizoon
Model Number	CC61
Material	Resin
Color	Brown & Gray
Capacity	100 Gallons
Product Dimensions (L x W x H)	50.4" x 24.8" x 25.2"
Item Weight	54.1 pounds
Special Features	Lockable, Stackable, Bench Functionality, Storage Box
Water Resistance Level	Water Resistant
Opening Mechanism	Controlled Spring Hinge (Hydraulic Piston)



Image: The Gizoon 100 Gallon Deck Box with its key dimensions (length, width, height) clearly indicated.

9. Warranty and Support

For warranty information, product support, or to report missing/damaged parts, please contact Gizoon Direct customer service. Refer to your purchase documentation for specific warranty terms and contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7LMH2RC

More documents and user manuals: **https://manuals.plus/**