Samsung Galaxy S25 Edge

Samsung Galaxy S25 Edge Smartphone User Manual

Model: Galaxy S25 Edge

1. Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Samsung Galaxy S25 Edge smartphone. Please read this guide thoroughly to ensure optimal performance and longevity of your device.



Image: The Samsung Galaxy S25 Edge, showcasing its slim profile and modern design.

2. What's in the Box

Verify that all items are present in your product packaging:

- Samsung Galaxy S25 Edge Smartphone
- Data Cable (Type C-to-C)
- SIM Ejection PIN
- Quick Start Guide

3. Physical Overview

The Samsung Galaxy S25 Edge features a precision-built titanium body and Corning Gorilla Glass Ceramic 2 for enhanced durability. Its ultra-sleek design measures just 5.8 mm in thickness.




Image: Side view of the Galaxy S25 Edge, highlighting its slim profile of 5.8 mm.

Available Colors

The device is available in the following finishes:

- Titanium Silver
- Titanium Jetblack



Image: The Samsung Galaxy S25 Edge in Titanium Jetblack and Titanium Silver.

4. Setup

4.1. Inserting the SIM Card

1. Locate the SIM card tray on the side of your device.

2. Insert the provided SIM ejection pin into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down. This device supports Dual SIM functionality.
4. Carefully reinsert the tray into the phone.

4.2. Initial Power On and Configuration

1. Press and hold the Power button until the Samsung logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. You may also be prompted to transfer data from a previous device.

4.3. Charging the Device

Connect the USB Type-C cable to the phone's charging port and the other end to a compatible power adapter. The device supports fast charging. Ensure you use a certified charger for optimal performance and safety.

5. Operating Your Device

5.1. User Interface and Navigation

Your Samsung Galaxy S25 Edge runs on **Android 15.0** with **One UI 7**, designed for intuitive touchscreen interaction. Navigate through menus, open apps, and interact with content using gestures and taps.




Image: The One UI 7 interface on the Galaxy S25 Edge, featuring customizable layouts and widgets.

5.2. Security Features

The device includes a **Fingerprint Recognition** sensor for secure unlocking and authentication. Additionally, **Knox Vault** provides defense-grade security to safeguard your personal data.



Image: The Knox Vault logo, symbolizing advanced data encryption and security.

5.3. Camera Operation

The Galaxy S25 Edge features a powerful**200 MP rear camera** with a ProVisual Engine, enhanced by AI for superior image quality. The front camera is **12 MP**.



Image: Close-up of the Galaxy S25 Edge's rear camera system, highlighting the 200 MP sensor.

Available shooting modes include: Bixby Vision, Dual Recording, Food, Hyperlapse, Night, Panorama, Photo, Portrait, Portrait Video, Pro, Pro Video, Single Take, Slow Motion, and Video. The camera also supports 10x digital zoom.




Image: A portrait captured with the Galaxy S25 Edge, demonstrating the object-aware engine for natural skin tones.

5.4. AI Features

The Galaxy S25 Edge integrates advanced AI capabilities, including:

- **Now Brief:** Provides personalized daily briefings and reminders.
- **Google AI Pro:** Offers enhanced features in the Gemini app and 2 TB of cloud storage (trial period may apply).
- **Gemini Live:** Enables real-time information retrieval through camera or image uploads, assisting with tasks like decoding care tags.




Image: A user interacting with Gemini Live on the Galaxy S25 Edge to get information about clothing care.

5.5. Performance

Powered by the **Snapdragon 8 Elite processor for Galaxy**, the device delivers fast processing and AI performance. It is optimized for smooth gaming with real-time ray tracing and Vulkan optimization.




Image: The Snapdragon 8 Elite processor, customized for Galaxy devices, highlighting its advanced architecture.



Image: The Galaxy S25 Edge displaying a graphically intensive game, showcasing its smooth gaming performance.

5.6. Battery Management

The device is equipped with a **3900 mAh Lithium-Ion battery**, providing an average life of 12 hours and talk time of 31.1 hours. Optimize battery life by managing background apps and using power-saving modes.




Image: The Galaxy S25 Edge playing a video, demonstrating its extended battery life for media consumption.

5.7. Connectivity

The Galaxy S25 Edge supports **5G cellular technology** for high-speed mobile data. It also features **Bluetooth, NFC, USB Type-C, Wi-Fi (GSM)**, and **Built-In GPS** with support for BeiDou, GLONASS, GPS, and Galileo satellite navigation systems.

6. Maintenance and Care

6.1. Water Resistance

The Samsung Galaxy S25 Edge is **Water Resistant (IP68)**. While it can withstand splashes and brief immersion, avoid exposing it to high-pressure water, saltwater, or other liquids. Ensure all ports are dry before charging.

6.2. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid abrasive materials or harsh chemicals that could damage the finish or screen coating.

6.3. Battery Longevity

To prolong battery life, avoid extreme temperatures, do not overcharge for extended periods, and consider enabling adaptive battery settings.

7. Troubleshooting

If you encounter issues with your device, try the following steps:

- **Restart the Device:** A simple restart can resolve many minor software glitches.
- **Check for Software Updates:** Ensure your device is running the latest software version by checking in Settings > Software update.
- **Clear App Cache:** If a specific app is causing issues, try clearing its cache in Settings > Apps > [App Name] > Storage > Clear cache.
- **Network Issues:** For connectivity problems, try toggling Airplane Mode on and off, or reset network settings in Settings > General management > Reset > Reset network settings.
- **Factory Reset:** As a last resort, if problems persist, you may need to perform a factory data reset.**Warning: This**

will erase all data on your device. Back up important data before proceeding. Go to Settings > General management > Reset > Factory data reset.

8. Specifications

Feature	Specification
Brand	Samsung
Model Name	Galaxy S25 Edge
Model Year	2025
Operating System	Android 15.0
RAM Memory	12 GB
Storage Capacity	256 GB
CPU Model	Snapdragon 8 Elite
CPU Speed	4.47 GHz
Colour	Titanium Silver
SIM Card Slot Count	Dual SIM
SIM Card Size	Nano
Connector Type	USB Type C
Biometric Security	Fingerprint Recognition
Water Resistance Level	Water Resistant (IP68)
Front Camera Resolution	12 MP
Rear Camera Resolution	12 MP, 200 MP
Number of Rear Cameras	2
Digital Zoom	10 x
Battery Capacity	3900 Milliamp Hours (Lithium-Ion)
Average Battery Life	12 Hours
Phone Talk Time	31.1 Hours
Item Weight	163 Grams
Item Dimensions (LxWxH)	6 x 76 x 158 Millimeters
Screen Size	6.7 Inches
Display Resolution	3120 x 1440 Pixels
Refresh Rate	120 Hz

Display Type	AMOLED
Cellular Technology	5G
Wireless Network Technology	GSM, Wi-Fi
Network Connectivity	Bluetooth, NFC, USB, Wi-Fi
Supported Satellite Navigation	BeiDou, GLONASS, GPS, Galileo

9. Warranty Information

Your Samsung Galaxy S25 Edge comes with a**1 Year Manufacturer Warranty for the device** and **6 Months for In-Box Accessories** from the date of purchase. Please retain your proof of purchase for warranty claims.

10. Support and Contact

For technical support, service, or further inquiries, please contact Samsung India Electronics Pvt. Ltd. at the details below:

Address: 6th Floor, DLF Centre, Sansad Marg, New Delhi – 110001, India

Email: support.india@samsung.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question