

Huuger 8757FC

Huuger 47.2 Inch TV Stand Dresser with Power Outlets and LED Lights User Manual

Model: 8757FC

1. INTRODUCTION

Thank you for choosing the Huuger 47.2 Inch TV Stand Dresser. This versatile furniture piece combines a TV stand, a dresser with four fabric drawers, and an entertainment center, featuring integrated power outlets and LED lighting. Designed for TVs up to 55 inches, it offers ample storage and modern convenience. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.

2. SAFETY INFORMATION

- Exercise caution around sharp edges during assembly.
- Keep small parts out of reach of children to prevent choking hazards.
- Ensure the unit is placed on a stable, level surface. Use the adjustable feet to balance if necessary.
- Utilize the provided anti-tip device to secure the TV stand to the wall, preventing accidental tipping.
- Do not overload shelves or drawers beyond their recommended weight capacity.
- Avoid exposing the unit to excessive moisture or direct sunlight.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact Huuger customer support.

- Metal Frame Components
- Engineered Wood Panels (Top, Middle Shelf, Bottom)

- 4 Fabric Drawers with PU Finish
- Built-in Power Strip (2 AC outlets, 2 USB ports, 1 Type-C port)
- LED Light Strip with Smart Controller
- Adjustable Feet
- Anti-tip Device
- Assembly Hardware (screws, bolts, etc.)
- Assembly Tools (e.g., Allen wrench)
- Detailed Instruction Manual

4. SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the detailed instructions provided in the separate assembly guide included with your package. All components are numbered, and necessary tools are supplied for a straightforward setup process.

1. **Unpack and Organize:** Lay out all components on a clean, soft surface to prevent scratches. Verify all parts against the package contents list.
2. **Assemble the Frame:** Connect the metal frame components according to the diagrams in the assembly guide. Ensure all screws are tightened securely.
3. **Attach Wood Panels:** Secure the top, middle, and bottom engineered wood panels to the frame. The middle shelf is detachable for flexible storage.
4. **Install Power Strip:** Integrate the built-in power strip into its designated slot on the top shelf.
5. **Insert Fabric Drawers:** Assemble the fabric drawers and slide them into their respective compartments.
6. **Attach Adjustable Feet:** Screw in the adjustable feet at the bottom of the frame. Adjust them to ensure stability on uneven floors.
7. **Install LED Lights:** Adhere the LED light strip to the underside of the top shelf or desired location. Connect it to one of the USB ports on the power strip.
8. **Secure Anti-Tip Device:** Attach the anti-tip device to the back of the TV stand and to a wall stud, following the instructions for your wall type.



Figure 1: Fully assembled Huuger TV Stand Dresser in a living room setting.

5. OPERATING INSTRUCTIONS

5.1. LED Lights Operation

The integrated LED lights enhance your viewing experience and room ambiance. They are controlled via a smart controller or a dedicated app.

- **Smart Controller:** Use the included smart controller to switch between 12 scene modes, adjust speed levels, and select from 3 brightness modes.
- **Mobile App:** Download the dedicated app (refer to the assembly guide for app details) to access over 60,000 colors, timing mode, mic mode (lights react to sound), and music mode.




Figure 2: LED lights in operation, creating ambient lighting for entertainment.

5.2. Power Outlets Usage

The built-in power strip provides convenient charging and power access for your devices.

- **AC Outlets:** Two 125V/12A AC outlets are available for powering your TV, Wi-Fi router, or other electronics.
- **USB Ports:** Two 5V/3A USB ports are included for charging smartphones, tablets, or other USB-powered devices.
- **Type-C Port:** One 5V/3A Type-C port offers fast charging for compatible devices.
- **On/Off Switch:** A master on/off switch controls power to all integrated outlets and USB ports.




Figure 3: Detail of the integrated power outlets for convenient device charging.

6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Fabric Drawers:** The PU finish on the fabric drawers makes them stain and waterproof. Wipe clean with a damp cloth. Do not machine wash.
- **Hardware:** Periodically check and tighten all screws and bolts to ensure the unit remains stable.
- **Adjustable Feet:** Re-adjust feet as needed to maintain stability, especially if the unit is moved.

7. TROUBLESHOOTING

7.1. LED Lights Not Working

- Ensure the LED strip is properly connected to a functioning USB port on the power strip.

- Check if the main power switch on the power strip is turned ON.
- Verify that the smart controller or app is correctly paired and functioning.

7.2. Power Outlets Not Supplying Power

- Confirm the TV stand's power cord is securely plugged into a wall outlet.
- Ensure the main power switch on the built-in power strip is in the ON position.
- Check the wall outlet with another device to confirm it is receiving power.

7.3. Unit is Unstable

- Adjust the leveling feet at the bottom of the stand to compensate for uneven flooring.
- Ensure all assembly hardware is tightened.
- Verify the anti-tip device is correctly installed and secured to the wall.

8. SPECIFICATIONS

Feature	Detail
Brand	Huuger
Model Number	8757FC
Color	Rustic Brown
Size	47.2 Inches (Width)
Material Type	Engineered Wood, Fabric
Number of Drawers	4
Max TV Size Supported	Up to 55 inches
Power Outlets	2 AC (125V/12A), 2 USB (5V/3A), 1 Type-C (5V/3A)
LED Lights	RGB, 12 scene modes, 3 brightness, 60,000 colors, timing, mic, music modes (app controlled)
Assembly Required	Yes



Figure 4: Product dimensions for planning your space.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact Huuger directly through their official website or the retailer where the product was purchased. Please have your model number (8757FC) and purchase date ready when contacting support.