Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

INNOD B0F7QP98GD

INNOD Rattan Shoe Storage Cabinet (47" Natural Oak) - Instruction Manual

Model: B0F7QP98GD

Introduction **Safety Information** **Parts List** **Setup & Assembly** **Operating Instructions** **Maintenance** **Troubleshooting** **Specifications** **Warranty & Support**

1. Introduction

Thank you for choosing the INNOD Rattan Shoe Storage Cabinet. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new shoe cabinet. Please read these instructions thoroughly before use and retain them for future reference.



Figure 1: INNOD Rattan Shoe Storage Cabinet (47" Natural Oak)

2. Safety Information

WARNING: This product comes with safety warnings. Always secure the cabinet to the wall using the provided anti-tip device to prevent tipping and protect children. Be cautious of fingers when using the flip-up doors to avoid pinching.

- Ensure all parts are correctly assembled before use.
- Do not overload the drawers or shelves.
- Keep small parts away from children during assembly.
- Place the cabinet on a flat, stable surface.



Figure 2: Anti-tip device installation steps. Secure the cabinet to the wall to prevent accidental tipping, especially in households with children.

3. Parts List

Before assembly, verify that all components are present and undamaged. Refer to the included assembly instructions for a detailed list of hardware.

- Main Cabinet Frame (Engineered Wood)
- Top Drawer (with semi-circular handle)
- 2 Flip-Down Shoe Drawers (with rattan panels and semi-circular handles)
- Adjustable Dividers for flip-down drawers
- Bottom Open Shelf
- Wooden Support Legs
- Anti-Tip Device (wall anchor kit)
- Assembly Hardware (screws, dowels, etc.)



Figure 3: Product dimensions and component breakdown. The cabinet measures 32"D x 10"W x 47"H.

4. Setup & Assembly

Assembly is required for this shoe storage cabinet. Clear instructions and numbered parts are included to make the process straightforward. It is recommended to have a second person for assistance during assembly.

1. Unpack all components and verify against the parts list.
2. Assemble the main cabinet frame according to the provided diagrams.
3. Attach the wooden support legs to the base of the cabinet.
4. Install the top drawer and the two flip-down shoe drawers. Ensure the flip mechanisms operate smoothly.
5. Insert the adjustable dividers into the flip-down drawers as desired.
6. Secure the bottom open shelf.
7. **Important:** Install the anti-tip device by attaching it to the back of the cabinet and securing it to a wall stud.

Your browser does not support the video tag.

Video 1: Overview of the Rattan Shoe Organizer, demonstrating its features and compact design. This video provides a visual guide to the product's functionality.

5. Operating Instructions

5.1 Top Storage Area

The top surface of the cabinet features a raised fence to prevent items from falling. This area is suitable for displaying decorative items, plants, or holding frequently used items like keys, wallets, or umbrellas.

5.2 Top Pull-Out Drawer

The top pull-out drawer provides hidden storage for small essentials. Gently pull the semi-circular handle to open and push to close.



Figure 4: The top drawer offers convenient storage for small items, while the top surface can hold decorative objects or frequently accessed belongings.

5.3 Flip-Down Shoe Drawers

The cabinet features two flip-down drawers for shoe storage. Gently pull the semi-circular handle to open each drawer. The internal panels can be adjusted or removed to accommodate different shoe heights and sizes.

- **Adjusting Dividers:** The internal dividers have two grooves, allowing you to adjust the partition height.
- **Removing Panels:** For taller shoes like boots or high heels, the internal panel can be completely removed to create a larger storage space.

- **Capacity:** Each flip-down drawer can typically hold multiple pairs of shoes, depending on their size and style.



Figure 5: Illustration of how to adjust or remove internal panels within the flip-down drawers to fit various shoe types.

5.4 Bottom Open Shelf

The bottom open shelf is ideal for quick access shoes, slippers, or even a robot vacuum cleaner.

6. Maintenance

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Rattan Care:** For the rattan panels, gently dust with a soft brush or cloth. Avoid excessive moisture.
- **Hardware:** Periodically check all screws and fittings to ensure they are tight. Retighten if necessary.
- **Placement:** Avoid placing the cabinet in direct sunlight or near heat sources to prevent warping or discoloration of the wood.

7. Troubleshooting

7.1 Shoes Do Not Fit

If larger shoe sizes (e.g., men's size 11 or larger) do not fit comfortably in the flip-down drawers:

- Ensure the internal dividers are adjusted to the lowest setting or completely removed.
- For very large shoes, consider storing them on the bottom open shelf or angling them within the flip drawers if necessary.

7.2 Drawers Do Not Close Smoothly

- Check for any obstructions inside the drawers, such as shoes protruding too far.
- Verify that the flip mechanism hardware is securely fastened and not damaged.
- Ensure the cabinet is on a level surface.

7.3 Cabinet Wobbles

- Confirm that all assembly screws are tightened.
- Ensure the cabinet is placed on a flat and stable floor.
- Verify the anti-tip device is correctly installed and securely anchored to the wall.

8. Specifications

Brand	INNOD
Model	Rattan Shoe Storage Cabinet
Color	Natural Oak
Material	Engineered Wood
Product Dimensions (D x W x H)	10" x 32" x 47" (32"D x 10"W x 47"H)
Number of Doors	2 (flip-down)
Number of Shelves	3 (2 internal, 1 bottom open)
Additional Features	Adjustable Shelf, Top Drawer, Anti-tip Device
Assembly Required	Yes

9. Warranty & Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact INNOD customer service directly. Keep your purchase receipt for warranty claims.

© 2026 INNOD. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7QP98GD

More documents and user manuals: **https://manuals.plus/**