

MERITLINE LT000328AA

MERITLINE Twin Over Full L Shaped Bunk Bed with Slide Instruction Manual

MODEL: LT000328AA

Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your MERITLINE Twin Over Full L Shaped Bunk Bed with Slide. Please read all instructions carefully before assembly and retain this manual for future reference. Proper assembly and use are essential for safety and product longevity.

Important Safety Information

Failure to follow these warnings could result in serious injury.

- **Weight Capacity:** The upper bunk is designed to support a maximum weight of **400 lbs**. The bottom bunk is designed to support a maximum weight of **600 lbs**. Do not exceed these limits.
- **Age Recommendation:** The upper bunk is recommended for children **6 years of age and older**.
- **Guardrails:** Always use the guardrails on the upper bunk. Ensure they are properly installed and secured.
- **Ladder Safety:** Always use the ladder for entering and exiting the upper bunk. Do not use the slide for climbing up.
- **Slide Safety:** Use the slide feet first. Ensure the area around the slide is clear before use.
- **Mattress Thickness:** The recommended mattress thickness for the upper bed is **6 inches**. For the bottom bed, the recommended mattress thickness is **8 inches**. Ensure the mattress on the upper bunk does not exceed the guardrail height.
- **Assembly:** This product requires adult assembly. Ensure all parts are securely fastened before use. Periodically check and tighten all connections.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **No Jumping:** Do not allow jumping on the bed.
- **Flammable Materials:** Keep all flammable materials away from the bed.

Package Contents

Your MERITLINE bunk bed is shipped in **3 separate packages**. Please ensure all packages have arrived before beginning assembly. Carefully unpack all components and verify against the parts list (not provided in this document, refer to your physical manual for a complete list). If any parts are missing or damaged, do not proceed with assembly and contact customer support.

Typical components include:

- Bed frames (upper and lower)
- House structure panels
- Ladder
- Slide
- Guardrails
- Slats for mattress support
- Hardware (screws, bolts, nuts, washers, Allen wrench)

Assembly Instructions

Before You Begin

- Clear a spacious area for assembly.
- Gather necessary tools (e.g., Phillips head screwdriver, hammer, if not included).
- Review all steps before starting.
- Two adults are recommended for assembly.

Step-by-Step Assembly

Follow the numbered steps in your physical instruction manual. The general sequence is outlined below:

1. **Assemble the Lower Bed Frame:** Begin by connecting the headboard, footboard, and side rails for the full-size lower bed. Ensure all connections are finger-tight before fully securing.
2. **Assemble the Upper Bed Frame:** Construct the twin-size upper bed frame, including its headboard, footboard, and side rails.
3. **Attach the House Structure:** Secure the house-shaped panels to the upper bed frame according to the manual's diagrams. This forms the playhouse design.
4. **Connect Upper and Lower Beds:** Carefully lift and position the assembled upper bed frame onto the lower bed frame, aligning the support posts. Secure them using the provided hardware.
5. **Install Ladder and Slide:** Attach the ladder and slide to the bunk bed structure. Note that the ladder and slide are convertible and can be placed on either the left or right side of the bed to suit your room layout. Refer to the manual for specific attachment points and hardware.
6. **Install Slats:** Place and secure the wooden slats onto both the upper and lower bed frames. The upper bed typically has 14 slats, and the bottom bed has 7 slats. Ensure they are evenly spaced and firmly attached to provide proper mattress support.
7. **Final Check:** Once assembly is complete, double-check all bolts, screws, and connections to ensure they are tight and secure. Do not overtighten.



Image: Assembled bunk bed frame, illustrating the L-shaped configuration with the house structure, ladder, and slide.



Image: Another view of the bunk bed frame, showing the structural details and the placement of the upper and lower beds.



Image: Side view detailing the ladder and slide components, which can be configured on either side.



Image: Detailed view of the slide, illustrating its construction and attachment point.



Image: Close-up of the house structure, highlighting its design elements.

Operating Instructions

- **Using the Ladder:** Always face the ladder when climbing up or down. Use both hands to grip the ladder rungs. Ensure the ladder is stable before use.
- **Using the Slide:** Only use the slide in a seated position, feet first. Ensure the landing area is clear of obstructions. Do not climb up the slide.
- **Mattress Placement:** Place the recommended size mattresses on the upper and lower bunks. Ensure the upper

bunk mattress does not extend above the guardrails.

- **General Use:** Avoid rough play on or around the bunk bed. Do not hang items from the bed frame or guardrails.

Care and Maintenance

- **Cleaning:** Wipe the bed frame with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the wood finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) check all bolts, screws, and connections to ensure they remain tight. Tighten if necessary, but do not overtighten.
- **Environmental Conditions:** Avoid placing the bed in direct sunlight or near heat sources, as this can cause wood to dry out or warp. Maintain a stable room temperature and humidity.
- **Moving the Bed:** If you need to move the bed, disassemble it first to prevent damage to the frame and connections. Do not drag the bed.

Troubleshooting

Issue	Possible Cause	Solution
Bed feels wobbly or unstable	Loose hardware connections.	Check and tighten all bolts and screws. Ensure all parts are correctly aligned.
Squeaking noises	Loose connections or friction between wood parts.	Tighten all hardware. Apply a small amount of wax or silicone spray to contact points if necessary.
Parts do not fit together	Incorrect orientation of parts or manufacturing defect.	Review the assembly instructions carefully. Ensure parts are oriented correctly. If parts are defective, contact customer support.
Missing hardware or components	Packaging error.	Do not proceed with assembly. Contact customer support immediately for replacement parts.

Product Specifications

Feature	Detail
Product Type	Bunk Bed
Size	Twin-Over-Full (L Shaped)
Color	Antique Gray
Material	Plywood + MDF + Pinewood
Overall Product Dimensions	82.1"L x 89"W x 82.3"H
Overall Product Weight	Approximately 193.65 lbs
Upper Bed Weight Capacity	400 lbs
Bottom Bed Weight Capacity	600 lbs
Recommended Upper Mattress Thickness	6 inches



Image: The MERITLINE bunk bed fully assembled and furnished.

Warranty and Customer Support

MERITLINE is committed to providing quality products. For any issues regarding your bunk bed, including missing parts, damaged components, or assembly difficulties, please contact our customer service team. We aim to respond to all inquiries within 24 hours to assist you with your concerns.

Please refer to your purchase documentation for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question